




ToofanX Mist

Mini Handheld Mist Fan



User Manual

Product Overview

Thank you for choosing the Portronics ToofanX Mist. This compact handheld mist fan is designed to deliver refreshing airflow along with a cooling mist effect for enhanced comfort during travel, outdoor activities, office work, and everyday use. With multiple speed levels, rechargeable battery support, and portable design, Toofan Mist Pro keeps you cool anytime, anywhere.

Please read this user manual carefully before using the product.

Safety Instructions

- Do not use the product in extremely humid or high-temperature environments.
- Keep away from fire, water, and flammable materials.
- Do not insert fingers or objects into the fan while operating.
- Children should use the product only under adult supervision.
- Stop using the product immediately if liquid enters the device.
- If charging fails, try using another cable or adapter.
- Fully charge the fan before first use.

Package Contents


- ToofanX Mist
- Water Filling Bottle
- Type-C Charging Cable
- User Manual

PRODUCT SPECIFICATIONS

- Charging Input 5V~2A
- Battery - 2000mAh Rechargeable Lithium Battery
- Material - ABS + Electronic Components
- Charging Port - USB Type-C

PRODUCT SPECIFICATIONS

- Water Tank Plug
- Water Tank
- Spray Outlet
- Fan Power Button
- Spray Button
- Fan Working/Charging Indicator
- Spray Working Indicator
- Type-C Charging Port
- Metal Hanging Buckle



HOW TO CHARGE

- Connect the Type-C charging cable to the charging port of the fan.
- Connect the other end to a 5V/2A USB adapter.
- The RED indicator light will blink while charging.
- Once fully charged, the indicator light will stop blinking.

Note: Adapter is not included inside the box.

HOW TO USE

Press the Fan Button to adjust speed levels:

First Press - Turn ON fan - Low Speed
Second Press - Medium-Low Speed
Third Press - Medium Speed
Fourth Press - High Speed
Fifth Press - Maximum Speed
Sixth Press - Turn OFF fan

Mist Spray Function

Press the Spray Button to control mist mode:

Press & Hold - Turn ON Mist Spray
Press & Hold Again - Turn OFF Mist Spray
The spray function automatically turns OFF after 5 minutes for safety and battery optimization.

HOW TO FILL WATER



Open the water tank plug carefully.



Fill clean water using the included water bottle.



Close the tank securely after filling.

Shake the water tank gently if spray performance becomes weak.

TROUBLESHOOTING

- Fan not turning ON - Recharge the battery fully
- Spray not working - Refill water and shake the tank gently
- Charging indicator not lighting - Check charging cable and adapter
- Weak airflow - Recharge battery or clean fan vents



www.portronics.com

For Support

Visit : www.portronics.com

Email : help@portronics.com

Contact No. : +91 9555245245

(Working Hrs. : Monday - Saturday 10:00am - 6:00pm)



E-Waste Management
E: info@3rrecycler.com

For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste