


PRODUCT DESCRIPTION

Sex machine



1. Securely connect the accessory you have chosen to the connector on the main body.
2. Connect the power cord. Check the power indicator light to see if it indicates that the machine is ready.
3. Gently hold the accessory with one hand, and simultaneously operate the remote control to adjust the speed from the lowest to the highest at all speeds, checking the operation of the machine.
4. The required angle can be adjusted freely using an aluminum alloy seatpost clamp.
5. The suction cup of the base is only suitable for use on smooth surfaces such as the ground, chair surface, and marble.

Remote control



- Power button
- Mode key
- Shortcut key
- Deceleration key

1. Connect to the power supply, press the ON/OFF button on the remote control, and the machine will start running.
2. To adjust the propulsion speed, please use the "+" and "-" buttons on the remote control.
3. Press "M" to cycle through 21 different operating modes.
4. Press the power button again to stop the machine.



Positive side facing up

Friendly reminder: The effective range of this remote control is within 10 meters.
Note: This product is not waterproof, please do not wade through water.

REMOTE CONTROL BATTERY SAFETY INSTRUCTIONS

1. This product's remote control requires CR2032 batteries. If the batteries fail, please replace them yourself. The batteries should be inserted into the correct battery compartment. If the product is not used for a long time, please remove the batteries in a timely manner.
2. The battery used in this product is a non-rechargeable battery, which cannot be charged. It is recommended not to mix different types of batteries or batteries of different ages.
3. The battery must not be exposed to environments such as direct sunlight, heat or similar overheated conditions, as

PRECAUTIONS

1. This product is only suitable for adults and is prohibited for use by minors.
2. If you experience any discomfort during use, please discontinue use.
3. Avoid direct sunlight, high temperatures, heavy pressure, moisture, and contamination.
4. Regularly check the product for any damage. If any damage is found, do not use it.
5. Please store it in a place where children cannot reach.

SPECIFICATION

Product Name	F5
Product features	Remote control
Material	Aluminum alloy + ABS + TPE
Rated power	48W
Maximum power	52W
Torque	4.234N.m
Input voltage	100V-240V
Output voltage	24V
Size	25.5x18.2x28.5cm
Advancement speed	292± beats per minute
Thrust length	0-7±cm

MAINTAIN

- ◆ Disassemble and clean the accessories after each use. Use a mild detergent and a damp cloth, or follow the separate instructions provided with the accessories. Unless specifically indicated, do not use harsh chemicals or abrasive cleaning pads.
- ◆ Use a soft cloth dampened with a mild detergent solution to remove any dust or other substances that may have accumulated on the machine. Do not use harsh chemicals or abrasive cleaning pads.
- ◆ Regularly inspect moving and fixed components for signs of wear. Repair, adjust, or replace any parts that may be loose before continuing use.

SAFETY PRECAUTIONS

Before using the product, please read this user manual carefully. And keep it properly for future reference.

⚠ Danger!

This product is not waterproof, so please do not wade through water.

⚠ Warning!

1. This product is suitable for use in China or countries with compatible electrical specifications. Do not use it with incompatible voltage. Please ensure that the machine is well connected to a stable power source before use.
2. If you suffer from high blood pressure, other heart problems, or any other conditions that make you unable to withstand strong stimulation, please do not use this product.

⚠ Attention!

1. Use only on flat, stable surfaces to prevent injury or damage to your machine. Check the machine for proper operation before each use. If your machine does not operate as expected, stop using it immediately and contact our store customer service for assistance.
2. To achieve the best results, use lubricant with accessories as needed.
3. For optimal results, please clean after each use. Do not rinse.
4. Unplug the machine after each use to ensure a longer service life.



F5



AUTO SCALING
MULTI-DIRECTIONAL
ADJUSTMENT

WIRELESS REMOTE-CONTROLLED
RETRACTABLE SEX MACHINE
PRODUCT USER MANUAL

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.