

User Manual

S441A



Chapter I Attentions

Please follow the instructions of this manual to complete the installation the device and go through the attentions below:

Please use the attached power adapter only.

Please plug off the power adapter and all other cables connected to the device in a thunderstorm weather in case of any damages caused by the lightning strike.

Please keep the device under ventilated and dry circumstances, and prevent it from direct sunlight.

Do not place the device near heat or water sources.

Keep the device away from high-intensity magnetic or electric fields emitted by such as microwave oven, refrigerator and so on

Chapter II Accessories List

Item	Q'ty	Unit
Accessories	Router Device	1 pc(s)
	Power Adapter	1 pc(s)
	User Manual	1 pc(s)

Chapter III Introduction

3.1 Product Description

Model	S441A
Description	300 Mbps Wi-Fi @ 2.4GHz
	1* Micro-SIM
	2 * Fast Ethernet ports
	2 * External Antennas

3.2 Product Appearance

(1) Indicator lights' status and specificallons.

Power

Internet

LAN

Wi-Fi

4G

Indicator led	status	Description
Power	on	Device powered on
	off	Device not powered on or broke down
LAN	on	Connect to PC devices or other smart devices
	blink	LAN port transmitting data
	off	LAN port not connected
Internet	on	Internet is available
	off	No internet
Wi-Fi	on	Wi-Fi is on
	blink	Equipment accessed
	off	Wi-Fi is off
4G	off	Not 4G mode, or no signal
	blink	weak signal
	on	Normal signal

1

2

3

(2) Specifications of ports and buttons

Button	Description
Power	Power jack, adapter 12V/1A
Reset	Long press for more than 5s to restore factory configuration, delete user configuration Long press for 2-5s before restarting the device
LAN	Used to connect to PC or other smart devices
WAN	Used to access Ethernet

4

Installation Steps

Installation steps:

1. Connect the PC or smart device to the router, open the browser, and use the IP (192.168.80.1) or (www.ezpoollogin.com) to enter the web configuration

2. Enter the setting wizard page to start configuration:

A. Set the administrator password

5

B. Set LAN port network segment

C. Set Internet access mode, static, DHCP, PPPoE, 4g

D. Set Wi-Fi SSID and encryption method

E. Click finished to save the settings

6

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body

7