

G17



USER MANUAL

The manual is for reference only. Actual product operations should be based on practical product usage

Thank you for buying this MID. Please read and retain all the operating instructions before operating the unit.


I. Note

1. Avoid the unit being dropped. Avoid the display been shake seriously, or the display will be damaged or unusual.
2. Do not use metal object to touch the device to prevent it from short circuit.
3. Please backup your data in case your important data is lost, especially before

you upgrade the firmware.

4. Do not disassemble. Do not wipe the surface of the unit by alcohol, thinner or benzene.
5. Do not disconnect the unit while it is formatting or uploading/downloading, or the procedures may lead to errors.
6. Avoid water or foreign objects enter the unit.
7. Do not use the unit in places that are extremely hot, cold, dusty, or humid.
8. Specifications are subject to change and improvement without notice.

II. Introduction of cover



- | | |
|--------------------------|------------------|
| 1. MIC | 2. TYPE-C |
| 3. TF/SIM card interface | 4. Earphone Jack |
| 5. Power on/off | 6. Volume keys |
| 7. Front Camera | 8. Flashlight |
| 9. Back Camera | 10. Left speaker |
| 11. Right speaker | |

VII. Operation Instruction

1. Basic Operation

1.1. Power on/Power off

Power on Press and hold the power switch for 5 seconds; the unit displays the start-up logo and enters the working mode.

Power off Press and hold the power switch for 5 seconds to turn the unit off.

Sleep

While the device is at working status, press the power switch, it enters the sleeping mode, and the screen will be off then. Press the power switch again, it shift to the normal mode. You may use this function when you don't use the device temporary to save power.

1.2. Charging

When the device prompts low battery, please charge it by provided charger.

Note: To improve the longevity of the battery, you may charge for another 30 minutes after it prompts the battery is full.

1.3. Main menu

Swipe up from bottom to top on the main interface, the main menu is appeared. It including the system setting, Gallery, Chrome and other applications you installed in the main menu.

2. Settings

Click “Settings” in the main interface to enter the setting interface. Click the corresponding setting items to operate.

2.1 Date and Time Setting

Click “System/Date & time” in the setting interface to set the date and time. You may set the date, time zone, time, time format and date format etc. in the menu.

2.2. Brightness

Select “Display” in the setting interface. Click “Brightness level” to enter, and slide the bar to adjust the brightness.

2.3. Screen Timeout

Adjust the delay before the screen automatically turns off.

Select “Display” in the setting interface. Click “Sleep” to enter, and click the time you want.

Note: The setting of screen timeout is unavailable while playing video.

2.4. Enable anti blue light

Select “Display” in the setting interface. Click on the “Night Light” switch to turn on the eye protection mode automatically.

3. Wi-Fi connection

Click “Settings” in the main interface. Click Network and internet to Wi-Fi, turn on the WIFI, it lists the open network it searched. Click the name of the network; it pops up the setting window. You may connect it to WIFI according to the prompts. You need to input the user name and password if networks are encrypted.

3.1 Bluetooth (optional)

Turn on the Connected devices, Click “Pair new device” ,it lists the open devices. Click the name of the devices; it pops up the setting window. choose the device ,pairing it, then you can transfer pictures, music etc with it.

4. Install, Uninstall and Run applications

4.1 Install

There are many ways to install applications under Android™. We introduce installation by Market here.

Select the APK file you want and enter the application installation interface. Click “Install” to install the application automatically. After installation, it prompts “Open” and “Finish” . Click “Open” to open the application. Click “Finish” to exit.

4.2 Uninstall

You may use the corresponding third party software management tool or the installed application management software of the device to install applications. Select “Setting/App and notifications/SEE ALL APPS/” to select the installed applications and check the attribute of it or uninstall it.

5. Connect to internet

5.1. After connecting with WIFI, open the browser and input the web address, you can browse the web then.

5.2. Click the icon  to enter the bookmark to view the browse history.

Click the web page you want to open it.

6. Audio and video playback

6.1. Audio playback

Click the “YT Music” in the main menu to enter the audio playback interface. It lists the audio files in the device, and you may click the file name to play it. in the audio playing interface, click the icons to play/pause/ increase volume/ decrease volume/ FF/ REW...

6.2. Video Playback

Click the “Files” in the main menu to enter the videos interface. It lists the video files in the device, and you may click the file name to play it. in the video playing interface, touch the screen to pop-up the operation icons and click the icons to play/pause/ increase volume/ decrease volume/ skip to next file/skip to previous file...

7. Picture viewing

Click “Gallery” in the main menu to enter the picture folder list. Select and click the folder you want to enter, it displays the . click the thumbnail of the picture to view it.

Touch the screen to pop-up the operation icons while viewing the picture, you may zoom in/zoom out/ skip to next picture/skip to previous picture/ rotate/ delete the picture...

8.1 Camera

Click  to take picture.

Click  to set the scene mode, Picture size, Picture quality etc

Click  to select back or front camera.

Click  to take video

8.2 DV

If the cursor is at  position, the device is at DV mode.

Click  to take picture.

9. Connect with external device

9.1. Connect with PC

You can connect your tablet to a Windows computer through a USB cable. When connected, you can transfer music, pictures, and other files between the computer and your tablet.

When you connect your tablet to the USB port on your computer, its USB storage is mounted as a drive and appears on your computer screen. You can copy files back and forth as you would use any other external device.

9.2. Use of OTG

It supports the movable device with FAT32 format, such as U disk and MP3.

Connect the movable device to the MID.

IV. Troubleshooting

1. What if the device is abnormal during operation?

Answer: 1) Reboot the device to see if it works OK.

2) Charge the device by the charger to activate the battery. Make sure it has power before you operate it.

3) It is suggested to upgrade the OS of the device by professional.

2. Why the standby time is so short sometimes?

Answer: the use time of the battery is all depend on the temperature and use instance. If the temperature is too high or too low, the use time of the battery might be effected. It is suggest using the device in normal temperature. The using time is also affected by increased volume and frequently operation.

VI. Specifications

Display	10.1' inch
OS	Android 16
Capacity	32GB ROM 3GB RAM
Audio	MP3
LCD resolution	800*1280 IPS
Processor	MT8786
Wireless network	802.11 a/b/g/n/ac, 2.4G&5GHz
BT	5.0
TYPE-C	2.0
Temperature	0°C to 45°C
Adaptor	5V 2A
Battery	5000mAh poly-lithium battery
Speaker	8 Ω /1W*2
Ports/Slots	1*USBType-C 2*SIM Slot 1 *3.5 mm Headphone Combo Jack 1*microSD Card Slot(up to 1TB)
2G Network	GMS 850/900/1800/1900
3G Network	WCDMA(B2/4/5)
4G Network	LTE(B2/4/5/12/25/26/41(HPUE)/66/71/7/13/17/28)

*Please note: Capacity might be lower than mentioned on box as device uses storage for preloaded software.

Google, Android, Google Play and other marks are trademarks of Google LLC.

Important safety instructions

- Do not alter, disassemble, open, crush, place pressure or crush the product.
- The product includes lithium - ion battery. Keep away from fire.
- Keep the product dry. Do not make use with wet hands. Moisture can cause electric shock.
- The product may heat up during use - This is normal.
- Do not use or leave the battery near - Fire, Oven, direct exposure to sunlight, car parking in the sun or any other heat source. Doing so may cause the battery to overheat and lead to torching.

- If the product begins to swell or expand, distributor a smell or heats up to the stage you cannot touch it, stop using the product immediately and contact a service laboratory.
- Do not make any changes / corrections independently use help by only by a qualified technician laboratory importer / manufacturer.
- If the battery starts to spread liquid, stop using the product immediately and contact a service laboratory.
- Ensure that the use is in accordance with the manufacturer's instructions.
- Do not leave the unit in charge mode for a long time.
- Do not store the product in a hot or humid environment.
- Use only the specified charger product. Using incorrect charger may result in overheating, fire and explosion of the battery.
- Beware of exposing the battery to water or any other liquid, not for cleaning the contacts and no other purpose.
- Do not insert or place the device in to or next to a microwave, oven or any appliance that generates heat, due to the risk of overheating of the battery.
- If the battery is not charging effectively, please avoid repetition of long, continuous charging excessively. Reload extended without discharging the battery may cause overheating.
- Battery should not spread a strange smell or fluid material if so please call service center.
- The battery contains combustible material and may catch fire.
- Never leave the product in areas with direct exposure to sunlight, a car parked in the sun or in any environment with high temperature.

Lithium Battery Safety Instructions:

- Caution Danger! Experience replacement battery may cause explosion, replace the battery only VIA service laboratory.
- Do not expose the battery or battery pack to high heat such as sunshine, fire and the like.
- Do not dispose of the battery in the trash, but recycling facilities designated.

FCC Statement

This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. The SAR limit of USA (FCC) is 1.6 W/kg averaged. Device types: Tablet PC (FCC ID: 2BCQA-G17) has also been tested against this SAR limit. SAR information can be viewed on-line at <http://www.fcc.gov/oet/ea/fccid/>. Please use the device FCC ID number for search. This device was tested simulation typical 0mm to body. To maintain compliance with FCC RF exposure requirements, use accessories should maintain a separation distance between the user's bodies mentioned above, use accessories should not contain metallic components in its assembly, the use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.