



Wiring Method: A

Accessory switched power source
(Lower light will turn on when the key is turned on)



Wiring Method: B

Constant power source/Battery
(Lower light will turn on only when the switch is turned to the on position)



PIN-TAB OUTS:

8- Upper Light Neg. (-) source
2- Incoming from power

7- Lower Light Neg. (-)
6- Lower Light Pos. (+)

3- Outgoing to relay, accessory or equipment

Pressing down the clips for easy disconnection

