




BEEM 480

Smart LED Projector



User Manual





Before choosing an installation location for your projector, take the following factors into consideration:

- Size and position of your screen
- Electrical outlet location

The projector can be installed in the front-desktop position, as follows:


Select this position with the projector placed at 5 feet height (recommended) in front of the screen. This is the most common way to position the projector for quick setup and portability.



For optimal viewing performance, the projector should be positioned at a height of 5 feet from the ground and at least 5 feet away from the wall or screen in the front.


Starting up the Projector

1. Plug the power cable into the projector and a power outlet. Turn on the power outlet switch, where plugged. The power indicator light on the projector will turn on after the power has been applied.



Please use the supplied power cable to avoid possible dangers such as electric shock and fire.

2. Press the power button on the projector or remote control to start the projector.



Bad



Good!




SIGNAL SELECTION



In the case of connecting the projector to an external device such as a laptop or set-top box, you need to select the correct signal input source before accessing the computer,


There will be a drop-down selection menu as shown below.



CONNECTING HDMI DEVICES




HDMI port supports uncompressed video data transmission between compatible devices like laptops and displays over an HDMI cable (not included). You should use an HDMI cable when making a connection between them. The user first connects to the wifi, and can watch a video after connecting the projector to their device.



CONNECTING AV DEVICES



The AV port allows the projector to be connected to AV devices such as set-top box and gaming consoles.



Set-top Box




Gaming Console

HOME PAGE



YouTube, Netflix, Prime Video, Apps, Settings, etc. are shown on the homepage.



ESHARE & AIRPLAY MIRRORING



These features allow the user to connect their Android or iOS devices wirelessly to the projector and share the device screen as a projection.

Miracast

To connect an Android Mobile/Pad with a Projector Based on WiFi-Display Technology



1. On your Android Mobile/Pad, open the setting menu
2. Access your display settings or screen-mirroring
3. Select your Miracast receiver: projector-970c

Hotacast 

Make sure that your iOS device is connected to the same network as your projector.



1. On your iOS device, open Control Center and tap Screen Mirroring.
2. Looking for devices that can be mirrored on.
3. Select projector-970c from the list.










 "ChinaNet-JYD1"  projector-970c

SETTINGS PANEL



You can access the settings in this panel including network settings, bluetooth settings, projection settings, language settings, date settings, system updates, and more.

Settings

 Network	 Bluetooth	 Projection
 Language	 Date	 System
 Application	 Other Settings	 About

WI-FI SETTINGS




To access the apps on the projector that require the internet, you first need to connect the projector to the wi-fi.



BLUETOOTH SETTINGS





You can connect external bluetooth speakers or headphones using this setting.



PROJECTION SETTINGS



You can adjust the installation mode and four-point corner correction. The automatic keystone correction can be turned on / off.





Please read this manual carefully before use and keep it for future reference.

1. Avoid exposure of the projector to dust, water / moisture and extreme temperatures.
2. This device is not dustproof or waterproof, regularly clean projector vents to avoid cooling malfunction.
3. Please use high quality power cord and under specified rated power supply.
4. When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.
5. Do not cover the vents of projector and ensure it is in a well-ventilated area when in use, positioned at least 2 feet away from the wall from behind. Heating will reduce the life of projector and cause danger.
6. Please cut off the power if the projector is out of use for long time.
7. Users or third-party professionals should not attempt to disassemble the projector for testing and maintenance, in which case, the warranty will be void.
8. For optimal viewing performance, the projector should be positioned at a height of 5 feet from the ground and at least 5 feet away from the wall or screen in the front.
9. Use the remote control from behind the projector for convenient operation.

Note: Any damage caused by physical impact, water/ liquid, fire, etc. caused by the customer or nature shall not be covered under warranty.

Only product design, feature and functionality-related faults can be considered. As per the brand's discretion, the product is eligible for repair and not for replacement, during the warranty period.



Attention:

Please do not look directly into the lens when projecting to prevent the strong light doing harm to your eyes. Kids should use the projector under the supervision of adults.



www.portronics.com

For Support

Visit : www.portronics.com

Email : help@portronics.com

Contact No. : +91 9555245245

(Working Hours : Monday - Saturday, 10:00am - 6:00pm)



E-Waste Management

E: info@3rrecycler.com

For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste