

SerenLife



SLSNGBRN10STN / R1064A

single burner stove

user manual

visit our website



SCAN ME

serenlifehome.com

PLEASE KEEP THIS MANUAL CAREFULLY FOR FUTURE
REFERENCE. FOR HOUSEHOLD USE ONLY.

Table of Contents

Features and Technical Specs 03

Warnings 04

Important Safety Information 04

Additional Safety Warnings 05

Parts List 06

Setup Instructions 06

Care and Maintenance 08

Register Product 09

Important Note

Before beginning assembly of the product, ensure that all parts are present. Compare the parts with the package contents list. If any part is missing or damaged, do not attempt to assemble or use the unit. Contact customer service for replacement parts.

CALIFORNIA PROP 65 WARNING

 **WARNING:**

This product may expose you to chemicals, which is known to the state of California to cause cancer, birth defects and other reproductive harm. Do not ingest.

For more info go to: www.P65warnings.ca.gov



Features:

- Square Heating Plate for Efficient, Even Cooking
- Adjustable Gas Control Valve for Precise Flame Control
- Electroplated Metal Pot Support
- Heat-Resistant and Stable Non-Slip Round Base
- Compact and Travel-Friendly
- Easy-to-Clean Heating Surface
- Quick Start Operation (Ignite and Cook)
- Compatible with Standard Propane Tanks
- Suitable for Most Cookware Types
- Ideal for Camping and Emergency Use

What's in the Box:

- Single Burner Stove

Construction Materials:

- Heating Plate: Steel
- Burner: Stainless Steel
- Base: Plastic
- Control Valve: Zinc-Based Alloy

Technical Specs:

- Fuel Type: Propane
- Power Rating: 10000 BTU
- Gas Control Valve: Adjustable
- Heating Plate Size: 7.5 x 7.5 Inches
- Heating Plate Shape: Square
- Operating Time: 2 Hour
- Maximum Weight Capacity: 8 lbs.
- Item Weight: 1.4 lbs.
- Product Dimensions (L x W x H): 7.5 x 7.5 x 4.5 Inches

Warnings

IMPORTANT

Read these instructions carefully and familiarize yourself with the product before connecting the appliance to the gas cylinder. Review these instructions periodically to maintain awareness. Retain these instructions for future reference.

FOR OUTDOOR USE ONLY!

Use only in well-ventilated areas. Do not use this stove inside a tent or any enclosed or partially enclosed area of any kind.

Important Safety Information

Read these instructions carefully and familiarize yourself with the product before connecting the appliance to the propane cylinder. Review the instructions periodically to maintain awareness. Retain these instructions for future reference.

- Do not modify this appliance.
- Do not misuse the appliance or use it for purposes other than those intended.
- Operate the appliance on a stable, level, hard surface only.
- Never leave the appliance unattended while in operation.
- Always check that the seals between the appliance and the propane cylinder are in place and in good condition before connecting.
- Never cover the stove with wind shields, rocks, or similar objects. Doing so may cause overheating and damage to the stove or propane cylinder.
An overheated cylinder is extremely dangerous.
- Do not use the appliance if it has damaged or worn seals.
- Do not use the appliance if it is leaking, damaged, or does not operate properly.
- This appliance must only be serviced by an authorized service technician.
- Do not move the appliance while in use.
- Ensure the appliance is operated at least 24 in (61 cm) away from combustible materials.
- Always install or replace the propane cylinder outdoors, away from ignition sources such as open flames, pilot lights, or electrical sparks, and away from other people.
- The openings at the base of the burner provide air for combustion and must never be obstructed. If the flame becomes noticeably orange, inspect these openings for blockage.
- If the appliance cannot be adjusted to operate properly, discontinue use until it has been serviced or repaired.

Additional Safety Warnings

- Use only 1 lb (0.45 kg) disposable propane cylinders marked USDOT-39 or TC CAN/CSA B339.
- Use only with propane fuel.
- Do not use the stove as a space heater.
- Always check for gas leaks outdoors.
- Do not check for leaks with an open flame. Use soapy water applied to joints and connections. Bubbles indicate a leak.
- If you hear or smell gas, or if the connection point becomes extremely cold, do not attempt to light the appliance. Disconnect the propane cylinder and contact your local dealer.
- To check if the propane cylinder contains fuel, gently shake it.
A sloshing sound indicates fuel is present.
- Do not allow cookware to boil dry.
- Always disconnect the propane cylinder when the stove is not in use.
- Do not move the appliance while in use.

Discontinue operation and close the valve if:

- Ambient temperature drops below -10°F (-23°C)
- There is no fuel remaining in the propane cylinder
- Combustion becomes unstable
- The stove does not light quickly or easily
- Repeated flameouts occur

CAUTION:

Allow the stove to cool for at least 15 minutes after use.

Parts may remain very hot. Keep children away during and after operation.

Ensure the gas is turned off before moving the stove.


Parts List



A. Burner
(10,000 BTU)
1 pc




B. Spring
1 pc



C. Pot Supports
1 pc




D. Drip Tray/
Wind Guard
1 pc



E. Regulator
1 pc



F. Regulator Knob
1 pc



G. Base Support
1 pc


Tools Required

All stove components (A–G) are fully assembled at the factory.
No tools are required. Hand-tighten the stove to the propane cylinder only.

Setup Instructions

Step 1


Remove the appliance from the packaging and remove all packing materials.



Step 2

Ensure the regulator knob (F) is in the OFF position. Gently screw the stove onto a standard 1 lb (0.45 kg) propane cylinder.


Carefully align the threads to prevent damage. Hand-tighten until the regulator (E) is firmly sealed against the top of the propane cylinder.



Step 3


Firmly insert the bottom of the propane cylinder into the base support (G). Operate the appliance only on a hard, flat, level surface. Keep the area around the stove clear of combustible materials, gasoline, and other flammable vapors or liquids.

Ensure the gas orifices and burner are clean and free of dirt or debris before use. Gas and air flow through the burner openings must not be obstructed.



Step 4 – Lighting and Burner Adjustment

1. Turn the regulator knob (F) approximately one full turn to begin gas flow.
2. While keeping your head and body away from the stove, carefully apply a flame source to the burner (A).
3. The burner should ignite.
4. If ignition does not occur, turn the regulator knob to OFF, wait 5 minutes to allow gas to dissipate, and repeat the steps above.




Step 5

Turn the regulator knob (F) counterclockwise to increase flame intensity.

Turn clockwise to decrease intensity or to extinguish the flame.

Do not open the valve beyond the point of maximum flame, as this may cause flaring and waste fuel.

After use, ensure the regulator knob is fully in the OFF position. Allow the stove to cool for at least 15 minutes before touching.



Care and Maintenance

Annual Maintenance

Clean the stove body with a soft cloth dampened with warm, soapy water.

Do not use abrasive or flammable cleaning products. Use a soft brush to clean the burner. All cleaning agents must be non-combustible and non-corrosive.

Storage

When not in use, store the stove in a dry, well-ventilated area out of reach of children. Ensure the regulator knob is in the OFF position and disconnect the propane cylinder before storage.



Register Product

Thank you for choosing SereneLife. By registering your product, you ensure that you receive the full benefits of our exclusive warranty and personalized customer support. Complete the form to access expert support and to keep your SereneLife purchase in perfect condition.

Start Here



Model Number:
SLSNGBRN10STN

[Serenelifehome.com/pages/register](https://serenelifehome.com/pages/register)



questions? comments?

We are here to help!

Phone: 1.718.535.1800

[serenelifehome.com/contact us](https://serenelifehome.com/contact-us)