

Instructions & User's Manual

Mini Pocket Fan

MODEL: MFP2406B-B MFP2406B-W



READ AND SAVE THESE INSTRUCTIONS

Attention

- Directing the fan at people with a high level of air flow for a long time will cause discomfort, especially for infants and the elderly.
- This product uses lithium-ion batteries and has no memory function. Overcharging or over-discharging will affect the service life of the product. Please charge in time and disconnect the power after fully charged.
- When the fan is working, the fan blades will rotate at high speed. Therefore, it is strictly prohibited to extend foreign objects into the fan, otherwise the fan may be damaged.
- As this product is not a toy for children, children below 14 years old should use it under the care of a guardian.
- Do not use too much force when adjusting the fan manually.
- Do not extrude, disassemble the battery or leave it in a high temperature environment (60°C and above) for a long time, otherwise, there may be a risk of leakage or explosion.
- If the user uses the power adapter to charge, the power adapter should obtain national compulsory certification before it can be used.
- Do not use this product while charging.
- Do not touch the rotating fan blade with hands. For users with long hair, please keep distance to prevent the hair involved.
- Please make the two blades overlapped before putting the front cover back.
- Please pull out the power plug before cleaning the product.
- Do not shine the flashlight into eyes directly for safety.

Supplier's Declaration of Conformity Compliance Information

Unique Identifier:
Product Description: Mini Pocket Fan
Model Number: MFP2406B-B / MFP2406B-W
Trade Name: Mini Pocket Fan

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party - U.S. Contact Information

Company: Walmart Inc.
Address: 702 5th Street Bentonville, AR
Telephone or internet contact information: 1-800-358-6168


Warning: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Class B device:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Product Overview



Operation Instructions

Briefly press power / fan speed button to turn on this fan, the fan has 3 speed settings, use this button to select desired speed.
Long press this button, the flashlight can be turned on/off.

Indicator Status:

- The indicator light flickers slowly when you charge this product.
- The indicator light keeps on when this product is fully recharged and when you unplug the USB cable the indicator light turns off.
- The indicator light will show current battery level by number of lights when you use this product to charge devices like mobile phones.
- The indicator light is not on when this product is work as a flashlight.

Function Description

Under a low battery, this product may not work normally. In order to ensure normal operation, please charge the battery to enough power. The flash light cannot be turned on when the fan is working, and vice versa.

*When the battery is low, it is not enough to support the high speed, the fan will work at the low speed according to the remaining battery level.


*This product has the current detection function, when external obstacles like fingers touch the blades, this product will instantly stop rotating in order to protect you. Then you can remove obstacles and restart the fan.

Product Parameters

Output: DC5.0V 1.0A
Max Input: DC5.0V 1.0A
Max Battery Capacity: 2000mAh
Battery: Lithium-ion
Recharged Time: 2-3 hours
Running time: 21 hours (Lowest speed setting)

Fan Operation Status Description


1. Dig out the fan body with your finger (See Fig.1)



2. It can be handheld when you unfold the cover to 180° (See Fig.2)



3. It can sit on the desk when you unfold the cover to 270° (See Fig.3)



SERVICE AND SUPPORT

We would love to hear from you and what you think of this product. Please consider leaving a review with feedback and rate your experience. If you have any questions, please contact our customer care center.

We are happy to help!
Call toll free: 1-800-358-6168
Monday - Friday 8am - 5pm CST.

WARRANTY INFORMATION

1 year limited warranty.