


Instruction Manual


D50



Please read the instructional manual carefully before using the product.

English


01. Item Checklist



Label Maker*1



Instruction Manual*1



USB Cable*1



NOTE


• The number of label rolls on the checklist is determined by the contents of the shipped package.

02. Specifications

Name	Smart Mini Label Maker
Model	D50
Technology	Thermal Printing
Width of label	20-24mm
Supported Consumables	Black mark thermal Label, Pre-cut Label, Continuous Label
Darkness	Light, Medium, High
Resolution	180dpi
Printhead Lifespan	50KM
Communication Port	Bluetooth / Data wire
Product Dimensions	118.3*52*70.9 mm (4.65*2*2.7 inch)
Power Input	5V== 2A
Power Supply	Data wire
	Lithium Battery
OS Supported	Android
	iOS

03.Product Introduction Parts and Features

01 Label Maker display



02 Features of Labels



Anti-loosening sticker

Various labels are available for purchase





Non-continuous label



Continuous label

03 Features of Continuous Labels

Tear away the base of the label easily with the easy-to-tear line



Gently bend the label along the east-to-tear line to tear the base from the adhesive easily

03. Product Introduction Power and Indicator Light



Indicator light

Power button description


Button	Operation	Functions
Power button	Hold for 3 seconds	Power on/off
	Press once	Output the label
	Press twice	Print diagnostic page

Indicator Light


 Green Light	Normal
 Blinking (slow) Green Light	Powered on & charging
 Blinking (fast) Green Light	Powered off & charging
 Red Light	Error (No Paper, Cover is open, Overheat)
 Blinking (slow) Red Light	10% Power left
 Blinking (fast) Red Light	5% Power left

04. How to Use


- 01** Press the Open Cover Button to open the paper compartment cover.



- 02** Get a roll of label paper and remove the anti-loosening sticker. Install the label paper with the printing side up into the paper compartment.





- 03** Insert the label paper through the clamps.





- 04** Note:


- ① If the width of the label is 16mm, set the clamp lever to "16" and squeeze the clamps inward along the arrows.




- ② If the width of the label is 20mm/24mm, set the clamp lever to "20" and push the clamps outward along the arrows.




- 05** Pull out the label paper and pull it to the mark line at the outlet so that it can be printed normally.




- 06** Close the cover.




- 07** Hold the power button for 3s to start the Label Maker.



- 08** Press the power button once, and the printer will start detecting the position of the label.




- 09** When the label comes out, the positioning of the label is complete



NOTE

- After installing the label roll for the first time or replacing the label roll, remember to reposition the label (Step No. **8**).
- If you do not reposition the label (Step No. **8**), the first label you print will be printed incorrectly (missing contents, not aligning to the center, etc.). You don't need to press the power button once to position the label when using continuous labels. You only need to pull the label to the designated line as in the image below.

05. Downloading the App



NOTE

- You need to connect the Label Maker through the Print Master app.
- In compliance with Google's requirement, Android phones must enable GPS (Location Services) before using Bluetooth.

Method 1:

Use your phone to scan the QR code to install the App.



Method 2:

Search for "Print Master" in the app store on your phone to download the App.



Google Play



App Store




Print Master

06. Connecting the Label Maker

01 Turn on GPS (Location Services)
(Android phones only).




02 Open Print Master.



03 Tap the "**Connect now**" button
to search for your device.



04 Press "Start using".




NOTE

- This product needs to be connected to the printer in the App after the Bluetooth is turned on.
- According to the official requirements of Google, Android mobile phones need to open the GPS permission before they can use the Bluetooth function.
- When connecting the App, please make sure that the printer is turned on and the Bluetooth of the mobile phone is turned on.

07. Identifying the Label Size


Method 1:

Check the anti-loosening sticker. (The label size shown below is just an example. The size of the label roll you have may vary.)




Method 2:

Check your label package.



Method 3:

Measure with a ruler.



Method 4:

Check the tag on your label roll. (Label rolls are being updated, so the actual product you receive may vary.)



08.FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

09.IC Caution

Radio Standards Specification RSS-Gen, issue 5- English:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS (s). Operation is subject to the following two conditions:

This device may not cause interference.

This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

- French:

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

Cet appareil ne doit pas causer d'interférences.

Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

Déclaration d'exposition RF:

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.