







Please read the instructions carefully before using and well keep it for future reference.

**PRODUCT
CONTENT**


1  X1		2  X1		
3  X2		4  X1		
5  X1	6  X1	7  X1	8  X1	
9  X1	10  X1	11  X4	12  X2	
13  X4	14  X5	15  X1	16  X2	17  X1
18  X4	19  X1	20  X1	21  X2	
Battery required: included		X2	not included	
3.7V LITHIUM BATTERY 		+ 1.5V "AA" -	X4	
			Tools Required: not included	
			 #0 Phillips screwdriver	

#0 Phillips screwdriver

-1-

**COMPONENTS DETAIL
ASSEMBLY**

TOWER CRANE




-2-

**BATTERY
INSTALLATION**


REMOTE CONTROLLER

1. Switch to "OFF"
2. Unscrew the battery cover with phillips screwdriver.
3. Insert 2x1.5V "AA" (called LR6 in some countries) batteries with polarities shown in battery compartment.
4. Close the battery cover and screw it.




TOWER CRANE & EXCAVATOR

1. Switch to "OFF"
2. Unscrew the battery cover with phillips screwdriver.
3. Connect the cable and place the battery to the battery box.
4. Close the battery cover and screw it.



TURNS ON

Switch it on and press any button on remote controller, the indicator light keeps flashing which represents its function is normal.



EXCAVATOR

TOWER CRANE

REMOTE CONTROL INFORMATION:

- Frequency: 2.4G
- 9 channels
- Remote control distance: 20-30M
- 2x AA type batteries (not included)

3.7V LITHIUM BATTERY INFORMATION:

- Battery life: 15-20min
- Battery Capacity: 500mah
- Battery charging time: 90-120min
- Charging current and voltage: 3.7V, 500mA

OPERATION GUIDE

Before each use, the remote controllers must be paired with the vehicles. Once pairing is successful, place on a flat surface before use. After use, slide both switches to OFF. Auto sleep mode activates after 3 minutes of inactivity. Press power switch to restart.

Pairing Instructions

1. Slide the remote controller switch to ON. The indicator light flashes—pairing mode is active. Then slide the vehicle switch to ON. The vehicle will automatically pair. When the indicator light stops flashing and turns off, pairing is successful.
2. One remote controller pairs with only one vehicle. Paired vehicles do not interfere with each other.
3. If pairing fails, turn both off and repeat Step 1.

Note:


1. Remote controllers are not universal. Please distinguish between them carefully and do not mix them for use.
2. Do not pair the remote controllers of the excavator and the tower crane at the same time.

Sleep Mode

If no input is made via the remote control within 3 minutes, the model automatically switches to sleep mode. To restart, press the power switch again.

TOWER CRANE

HOW DOES IT WORK?




POWER SWITCH


-3-

-4-

EXCAVATOR




REMOTE CONTROL




HOW DOES IT WORK?


1. push forward lever, the excavator will move forward.




2. push backward lever, the excavator will move backward.




3. push turn right lever, the excavator will move turn right.



4. push turn left lever, the excavator will move turn left.




5. Excavator arm extension mode.



USB CHARGING

(1)Insert the small end of the USB charging cable (included) into the 3.7V lithium-ion battery connector.
(2)Connect the other end of the USB cable into the USB port of your powered computer.
(3)Never charge the battery longer than 12 hours. Failure to follow these instructions may damage your battery.



FCC Statement (United States Only)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:(1)This device may not cause harmful interference, and(2)This device must accept any interference received, including interference that may cause undesired operation.

STORAGE

- 1.After use, please wipe the dust off the and store it and pack the product in a dry and well ventilated place.
- 2.After use, please switch off the power of the product and the remote controller to improve the using life of the battery.
- 3.Before using it again, please check if the product and remote controller have sufficient power.

CAUTIONS

Use this product and its accessories only when fully assembled and in accordance with the instructions in this manual.
WARNINGS!
CHOKING HAZARD. Not suitable for children under 36 months due to small parts. Adult supervision is strongly recommended.
1) Operate the vehicle in a safe location, kept well away from people, pets, and moving vehicles.
2) Do not use on public roads, pavements, or in poorly lit areas.
3) Never attempt to pick up the vehicle while it is moving. Wait for it to come to a complete stop before handling.
4) Keep hands, fingers, hair, and loose clothing clear of the wheels when the vehicle is switched on or the controller is in use.
5) Avoid dropping or subjecting the product and accessories to strong impacts.
6) Do not dismantle or modify the product or its accessories.
7) Always switch off the vehicle and remove batteries when not in use.
8) Always use the product responsibly.
9) Do not touch the operation lever or other buttons on controller while turning on the switch-this will cause the controller to malfunction.
10) Small parts may fall off, posing safety hazards

BATTERY SAFETY INFORMATION

In rare cases, batteries may leak fluids that could cause chemical burns or damage the product. To prevent battery leakage and ensure safe use:
1)Do not attempt to recharge non-rechargeable batteries.
2)Remove rechargeable batteries from the product before charging.
3)Rechargeable batteries should only be charged under adult supervision.
4)Do not mix different types of batteries (e.g., alkaline, carbon-zinc, or rechargeable).
5)Do not mix old and new batteries.
6)Ensure batteries are inserted with the correct polarity (follow the +/- markings).
7)Remove exhausted batteries promptly from the product.
8)Do not short-circuit the battery terminals.
9)Dispose of used batteries safely and in accordance with local regulations.
10)Do not dispose of this product in fire as batteries may leak or explode.
11)Do not expose the product or batteries to water, moisture, or damp conditions.
12)Avoid using the product in rain, puddles, or wet environments, as this may cause malfunction or battery leakage.
13)If applicable, use only a USB power adapter with an output of 5V- 1A to charge this product. Do not use fast chargers or power adapters with higher voltage or current, as this may damage the product or pose a safety risk.

DO NOT RETURN THIS ITEM TO THE STORE

The store does not stock replacement parts. Please contact service center for assistance.

Kalee Global LLC
800 213 6378
support@kaleeproducts.com
1178 Broadway 3rd floor #1059
New York , NY 10001

ATTENTION

Battery must be fully charged before use.