

Quick Start Guide

Attach Clips

Attach 2 clips to each wand.

Mount Wands

Clip the wands to the support poles at a height that targets the area you want to treat.

Face LEDs Inward

Angle the wands so the LED lights face toward you.

Connect Y-Split Cable

Find the Y-split cable and connect the two long ends to each wand.

Connect Controller

Attach the short end of the Y-cable to the cable connected to the controller.

Secure Controller Button

Use the clips to attach the controller button to the side rail of the tent within easy reach.

Press once to start a 30-minute session.

Route Cable Through Tent

Remove the steam nozzle connector, feed the controller cable through the opening, then reattach the nozzle.

Plug in Power

Connect the adapter cable at the back of the tent and plug it into a power source. Connection must remain outside the tent.

Safety

Protective eyewear is available and recommended. Do not expose power connections to moisture.

