


材质：80g书写纸
印刷：单黑印刷，风琴折
展开尺寸：527.5*148mm 折后尺寸：105.5*148mm

148mm

105.5mm



PORTRONICS



140W
HD SOUND

PURE SOUND 110

USER MANUAL

1 ACCESSORIES LIST

- Subwoofer
- Soundbar
- Power Adapter
- 3.5mm to 3.5mm Audio Cable
- User Manual
- Digital Optical Cable
- Remote Control
- Wall Mounted Kit

2 SOUNDBAR CONTROLS

Control Panel

- Power Button**: Long press to power on / Hold for 3 seconds to power off. Short press to switch channels: ARC-OPT-AUX-BT (Press to switch to Bluetooth channel and enter pairing mode, see led showing "Blue" use mobile phone to searching (Pure Sound) 110 to connect device).
- Previous/Next Song/Short Press Volume Down**
- Short Press to Play/Pause**
- Long Press Next Song / Short Press Volume Up**

3 CONNECT TO SUBWOOFER



4 CONNECT TO TV VIA HDMI ARC




5 CONNECT VIA OPTICAL/AUX



6 CONNECT TO BLUETOOTH



8 WALL MOUNT INSTALLATION



9 SPECIFICATIONS

Input	AC 110-240V ~50/60HZ
Sound Output	100W
Adapter	24V3A
Soundbar Drivers	1.2"/3.75"(25mm)x1 5.25"(135mm)
Frequency Response	45Hz-18kHz
Standby Power	< 0.5W
Operating Temperature	0 ~45°C (32°F~113°F)
Bluetooth Version	5.3
Soundbar	W 400xH 80xD 78mm (MM)
Subwoofer	W 270xH 170xD 130mm
Packaging	1.380xH 175xW 440mm (MM)
Net Weight	3.3kg/7.28lbs
Gross Weight	4.2kg/9.26lbs

IMPORTANT SAFETY INSTRUCTIONS

CAUTION: To reduce the risk of electric shock, do not operate device, there is no part inside for the user. Refer all servicing to qualified personnel.

- The lightning with the arrow symbol in the triangle is a warning sign alerting the user to dangerous voltage "inside" the unit.
- The exclamation point in the triangle is a warning sign alerting the user of important instructions accompanying the product.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

IMPORTANT

- The use of appliances in moderate climates.
- The warning label is located on the bottom of unit.
- Make sure to have a minimum distance of 5 cm around the unit for sufficient ventilation.
- Ensure that the ventilation openings is not covered with items such as newspapers, tablecloths, curtains, etc.
- Do not place related home sources, such as lit candles on the appliance.
- Do not expose this appliance to dripping or splashing water.
- Do not place objects filled with liquids, such as glass, near or on the device.



PORTRONICS

www.portronics.com

For Support
Visit: www.portronics.com
Email: help@portronics.com
Contact No.: +91 9555245425

(Working Hrs.: Monday - Saturday 10:00am - 6:00pm)

E-Waste Management
E: info@3recycler.com

For E-Waste & ROHS compliance
refer to www.portronics.com/ewaste