

AVIOT WS-Q1

Bluetooth Speaker Quick Start Guide

Charging

Please charge the device before first use. Connect the USB Type-C® cable to the charging port for charging. It takes approximately 1 hour and 30 minutes to fully charge the battery from 0% remaining power.

Reset (If malfunctions occur during operation)

1. Delete the Bluetooth settings of the connected device.
2. With the power ON, press and hold the Volume - button and Power button simultaneously for 2 seconds.

Cover Removal and Attachment

The cover can be attached or removed by aligning the recess of the speaker with the protrusion of the cover. You can adjust the angle by standing the speaker with the corner of the main unit bottom aligned with the groove of the cover.

Power ON/OFF

Power OFF: Press and hold the Power button for 2-6 seconds.

Pairing (For initial setup)

1. Press and hold the Power button to turn on the power, and confirm that the device is in pairing mode.
2. Connect to "AVIOT WS-Q1" or "AVIOT WS-Q1-PNK" from the Bluetooth settings screen of your connected device.

Note: The connected device settings screen display is only an example. For details, please refer to the instruction manual of your connected device. Do not select the display of "APP WS-Q1" or "WS-Q1-PNK". If pairing fails, please try resetting the device.

Safety Precautions

WARNING

- Use the device in an environment where you can ensure your safety, as warning sounds and other ambient sounds may be difficult to hear.

- Do not use, store or leave the device in humid, dusty, smoky, steamy areas, near fire, in direct sunlight, or in high-temperature places such as inside a car.
- Never use the device while driving a car, motorcycle, ship, bicycle or other vehicles. Pay attention to the surrounding environment when using.
- Do not insert water or foreign objects into the device. Water or foreign objects may cause fire or electric shock. If water or foreign objects enter the device, stop using it immediately and consult your retailer.
- Do not use the device while it is covered with a blanket or other similar items.
- Never insert the USB plug when the device or USB cable is wet. Inserting a USB plug into a wet device or cable may cause a short circuit due to liquids (tap water, seawater, soft drinks, etc.) or foreign objects attached to the device or USB cable, leading to abnormal overheating or malfunction.
- If the battery leaks or emits an unusual odor, immediately move the device away from fire and stop using it.
- Use the included USB cable for charging.

CAUTION

- Be careful with high volume and prolonged use, as it may adversely affect your hearing. To protect your ears, do not turn the volume up too high. Regardless of the volume level, prolonged use will burden your ears. Please rest your ears about once an hour. Consult a doctor if symptoms do not improve.
- Do not use the device near medical equipment.
- Do not touch the device for a long time while it is charging, as it may cause low-temperature burns.
- Follow the instructions of the cabin crew when using the device on an aircraft. Radio waves may cause malfunctions and lead to accidents.
- When using Bluetooth® devices in certain locations, noise, audio dropouts, or disconnections may occur due to surrounding radio wave conditions, such as areas with wireless LAN or near electromagnetic cookers like induction stoves.
- The effective communication range of Bluetooth® varies greatly depending on obstacles (human body, metal, walls, etc.) and surrounding radio wave conditions.
- Radio waves generated by Bluetooth® devices may affect the operation of other electronic devices and may cause accidents in some cases. Therefore, please turn off the power of this device and other Bluetooth® devices in the following locations: Hospitals / Near priority seats on trains / Locations where flammable gases are generated such as gas stations / Near fire alarms.

Warranty Terms

We will repair or replace the product free of charge for natural failures caused by normal use. When contacting our company, please prepare documents or electronic data proving your purchase and the purchase date, such as the receipt or delivery note from your retailer.

The warranty period is 12 months from the date of purchase. The warranty is only valid in the country of purchase. Only the speaker is covered by the warranty. Damage to accessories or outer boxes during inspection or replacement cannot be covered by the warranty.

※ Even if the product is replaced free of charge or for a fee within the warranty period, the warranty period remains 12 months from the date of purchase and will not be extended after replacement, whether free of charge or for a fee.

This product may be modified without prior notice for improvements and other reasons.

Please note that the warranty does not apply in the following cases in principle:

- a. If the product has not been registered through our dedicated registration form.
- b. If there are no documents or electronic data proving the purchase, such as a receipt or delivery note from an authorized retailer.
- c. If the product has been repaired or modified by anyone other than our service center.
- d. If the product has deteriorated or been damaged due to customer negligence such as misuse (including damage or burnout from excessive input), dropping, impact, etc., or improper storage. Also, if scratches or signs of misuse are found on the faulty headphone regardless of when the symptoms occurred.
- e. If the product was used with a power supply and voltage outside the specified standards.
- f. For consumable parts.
- g. If the cause of the failure is in other devices other than this product, such as mobile terminals.
- h. Exterior damage such as scratches or stains on the main unit exterior or plug (occurred after purchase).
- i. If the date of contact is after the warranty period, even if the date of failure or malfunction is within the warranty period.

We cannot provide warranty for products not handled by our company.

We do not lend replacement devices during the repair or replacement period.

In the unlikely event that the product is determined to be outside the warranty coverage, we may charge you for the round-trip shipping costs.

Due to production, inventory conditions and other circumstances, we may not be able to replace the product with the same model.

Disclaimer

We do not guarantee connection and operation with all Bluetooth® compatible devices and applications. Our company shall not be liable for any failure, trouble, data loss or damage of other connected devices caused by the use of this product. In addition, our company shall not be liable for any damages caused by failure, trouble, data damage or loss of headphones, OS, other software, compatible devices, etc. Please note this in advance.

Rechargeable Battery Disposal

The rechargeable battery built into this device is a recyclable resource. When disposing of this device, do not disassemble it by yourself under any circumstances, and dispose of it in accordance with the garbage disposal rules of your municipality.

For Long-Term Use

- Beware of over-discharging: Rechargeable batteries may deteriorate due to over-discharging if left uncharged for a long period of time. For long-term storage, please charge the battery about once a month to prevent over-discharging.
- Beware of deformation, damage and impact: The device may deform or be damaged if force is applied to it for a long time. Please store it carefully. In addition, since the device uses precision electronic components, do not subject it to strong impact such as dropping or hitting it.
- Cleaning instructions: Do not use chemicals such as benzene, thinner, or alcohol for cleaning, as this may cause deterioration or malfunction.

Wired Connection

(No specific instructions provided in the original manual)

Dedicated Application

Using the "AVIOT Connect" application, you can make settings such as customizing the main unit button operations and adjusting sound quality.

Trademarks

• Bluetooth® word mark and logo are registered trademarks owned by Bluetooth SIG, Inc. Auracast™ word mark and logo are registered trademarks owned by Bluetooth SIG, Inc. Precede Japan Co., Ltd. uses these marks and logos under license. • USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum. • LDAC and the LDAC logo are trademarks of Sony Corporation. • Hi-Res Audio Wireless logo is a registered trademark or trademark of the Japan Audio Society. • All other trademarks and registered trademarks are the property of their respective owners.

FAQs / Inquiries

For frequently asked questions and inquiries, please contact our customer service center.

FCC ID: 2A9B6WS-Q1

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are

designed to provide reasonable protection against harmful interference in a

residential installation. This equipment generates, uses and can radiate radio

frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.