


Fan


Product ID. QUCYN



Scan for Support
support@garvee.com



GARVEE.com



24 INCH DRUM FAN

MODEL :FT-24 PLUS

PRODUCT USE GUIDE

INTRODUCTION

Thank you for choosing our fan.
This owner's manual will provide you with valuable
information necessary for the proper care and
maintenance of your new product.
Please take a few minutes to read it.

TABLE OF CONTENTS

SECTION 1

IMPORTANT INSTRUCTIONS	PAGES 3-4
------------------------	-----------

SECTION 2

TECHNICAL PARAMETERS	PAGES 4
PRODUCT DIAGRAM	PAGES 4
PACKAGE INCLUDES	PAGES 5

SECTION 3

ASSEMBLY INSTRUCTIONS	PAGES 5-7
OPERATION INSTRUCTIONS	PAGES 8

SECTION 4

STORAGE MAINTENANCE GUIDELINES	PAGES 8
--------------------------------	---------



IMPORTANT INSTRUCTIONS


PLEASE READ CAREFULLY- ALWAYS MAINTAIN SAFETY WHEN WORKING WITH ANY APPLIANCE.

1. Check that the mains voltage corresponds with the rating of the appliance before operating.
2. To protect against electric shock. Do not immerse cords plugs or appliances in water or any other liquid.
3. Do not leave any appliance unattended while it is operating.
4. Close supervision is necessary when any appliance is used by or near children or infirm persons.
5. Unplug from the outlet when not in use or before cleaning. Allow cooling before taking off any parts.
6. Do not operate the appliance with damaged power cords or plugs, and do not use a damaged appliance. If the power cord or appliance is damaged, it must be replaced by the manufacturer, service agent, or similarly qualified professional to avoid a hazard
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors.
9. Do not let the cord hang over the edge of a table or counter or let it come into contact with any hot surfaces
10. To disconnect-remove the plug from the outlet. Do not pull the plug out by the cord.
11. Do not use this product for anything other than its intended use. This appliance is for household use only.
12. No liability can be accepted for any damage caused by non-compliance with these instructions or any other improper use or mishandling.
13. Do not use the appliance without the protective grills.
14. Do not attempt to force the grill to make the fan turn or stop.
15. Never put objects into the grills when the appliance is connected to the mains.
16. It is not advisable to expose people(esp.. Babies or older people) to a continuous cold air stream for a long time.

TECHNICAL PARAMETERS

Model No.	FT-24 PLUS
Item Name	DRUM FAN
Rated Voltage	120V (60Hz)
Rated Power	320W
3 Mode Fan Speeds	Low / Medium / High
Max Oscillation	360 Degrees
Fan Blade Diameter	24 Inch
Package Size	27.2×8.07×27.6 Inch


PRODUCT DIAGRAM



A — Product Body*1	D — Fixed Crossbeam*1	G — Plum Knob*2
B — U-Shaped Rod*2	E — Support Frame*4	H — Silicone Gasket*2
C — Wheel Crossbeam*1	F — Wheel*2	I — Crossbeam Screw*2

Note: For the convenience of transportation, two sets of plum knobs and silicone gaskets will be locked on the main body of the product. Please dismantle in advance when assembling the product.


PACKAGE INCLUDE



1 × Drum Fan




1 × Screwdriver



1 × Owner's Manual


ASSEMBLY INSTRUCTIONS

Step 1: Rotate and remove the two plum knobs and silicone gasket on the product.



- A — Product Body
- G — Plum Knob
- H — Silicone Gasket


Step 2: Install the two support frames as the figure shows. Repeat once, and install the other side.




Step 3: Rotate and remove the screws and gasket on the left and right sides of the wheel crossbeam.



Step 4: Install the two U-shaped rods and wheels as the figure shows.




Step 5: Fasten the fixed crossbeam with screws.



Step 6: Remove the four screws on the support frames, put the support frames on the U-shaped rods, and lock it with the screws.

NOTE : If the angle of the support frame is not enough, loosen the plum knob to adjust.



OPERATION INSTRUCTIONS

1. Plug the power cord into 120V the volt AC wall outlet.
2. You can turn the switch to 1, 2, or 3 to select low / medium / high speed(Figure A)
3. You can loosen the plum knobs and adjust the vertical oscillation of the fan, max 360 degrees (Figure B)

NOTE : After the product body angle is adjusted to 180°, the handle will rotate to the bottom of the fan. If you want to use the handle, please adjust it by another 180°.




Figure A




Figure B

STORAGE & MAINTENANCE GUIDELINES

1. Turn the control OFF and unplug the fan before cleaning.
2. Use only a soft damp cloth to clean the fan.
3. Do not place the fan in water and never allow water to drip into the Motor Housing.
4. Do not use gasoline, paint thinner or other chemicals to clean the fan.
5. To clean the fan blade, remove the front grill and wipe the blade and grills.
6. Store the fan in its original box or cover the fan to protect it from dust.
7. Store it in a cool and dry place.



Limited Liability & Warning

No Unauthorized Modifications/Repairs: Do not modify or attempt to repair this product unless you are an authorized technician. Unauthorized actions may create hazards and void all warranties

Misuse & Non-Compliance: We are not liable for any injury, damage, or loss resulting from:

- (a) misuse, abuse, neglect, or improper installation;
- (b) failure to follow instructions or safety precautions;
- (c) use of unauthorized parts/accessories;
- (d) unauthorized modifications/repairs;
- (e) accidents, natural disasters, or external causes.

If you doubt any step of installation or operation, stop using the product and contact authorized service or the customer support.

LIMITACIÓN DE RESPONSABILIDAD Y ADVERTENCIA

Modificaciones o Reparaciones No Autorizadas: NO modifique ni intente reparar este producto a menos que sea un técnico autorizado. Las acciones no autorizadas pueden generar riesgos y anularán todas las garantías.

Uso Indebido e Incumplimiento: No asumimos responsabilidad alguna por lesiones, daños o pérdidas que resulten de:

- (a) uso indebido, abuso, negligencia o instalación incorrecta;
- (b) incumplimiento de las instrucciones o precauciones de seguridad;
- (c) uso de piezas o accesorios no autorizados;
- (d) modificaciones o reparaciones no autorizadas;
- (e) accidentes, desastres naturales o causas externas.

Si tiene dudas sobre algún paso de la instalación o el funcionamiento, deje de usar el producto y póngase en contacto con el servicio técnico autorizado o con atención al cliente.

GARVEE
support@garvee.com