


INTRODUCTION

The robotic pool cleaner comes with a handheld remote controller.

Turn on/off the button of the pool cleaning robot. Turn on the switch on the right side of the remote control and pull out the antenna of the remote control so that it can normally control the cleaning robot.

REMOTE CONTROL USER INTERFACE

1	LED Indicator
2	Forward
3	Left
4	Pause
5	Right
6	Backward
7	Auto Clean
8	Up Wall
9	Bottom Clean
10	Down Wall
11	Wall Clean
12	Pull Aside
13	Buoy ON
14	Buoy OFF
15	Clear



WARM REMINDER

- The remote control is a free accessory included in the standard configuration.
- Please match a 9V battery by yourself before use.
- To ensure that the robot receives the signal and sends instructions in time, please keep the remote control at a 45-degree angle with the ground.

INSTRUCTIONS

Turn on remote control

1. Turn on the robotic pool cleaner.
2. Slide the switch on the right side of the remote control to turn it on.
3. Pull out the antenna of the remote control.

Move robotic pool cleaner

1. Press any of the following buttons to navigate the device manually in its corresponding direction.

MUMBER	BUTTON	FUNCTION
2	FORWARD	Move device forward
3	LEFT	Turn device to the left
5	RIGHT	Turn device to the right
6	BACKWARD	Move backward

2. Press PAUSE button to stop the device.

Automatic cleaning modes

1. Press and hold any of the following buttons to activate the corresponding cleaning mode

MUMBER	BUTTON	FUNCTION
7	AUTO CLEAN	Activates <i>Full Cleaning</i> mode
9	BOTTOM CLEAN	Activates <i>Floor Cleaning</i> mode
11	WALL CLEAN	Activates <i>Wall Cleaning</i> mode

2. Press **CLEAR (15)** to stop any of the cleaning modes.

Climb walls automatically

1. Press **UP WALL (8)** to make the device climb up the pool wall.
2. Press **DOWN WALL (10)** to make the device climb DOWN the pool wall.

Park robot at waterline

1. Press **PULL ASIDE (12)** to navigate the robotic pool cleaner to the edge of the pool floor.
2. Press **UP WALL (8)** to park the robotic pool cleaner at the waterline level.

Turn on/off suction motor of Cleaning Buoy

With Cleaning Buoy is connected to the robotic pool cleaner:

1. Press **BUOY ON (13)** to turn on the suction motor of Cleaning Buoy.
2. Press **BUOY OFF (14)** to turn off the suction motor of Cleaning Buoy.

FCC Statement

1.This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference.

(2)This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:This equipment has been tested and found to comply with the limits for a class B digital device,pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and,if not installed and used in accordance with the instructions,may cause harmful interference to radio communications.However,there is no guarantee that interference will not occur in a particular installation.if this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on,the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.