

USER MANUAL

Bluetooth Speaker



Model : Cooler Bag 123


Dear Customer, Thank you very much for your purchasing, Please

read this user manual carefully and keep it for future reference.

Warnings and Cautions:

1. Do not drop, apply excessive force to the controls, or put heavy objects on top of the speaker.
2. Do not attempt to repair, disassemble or modify the product.
3. If you do not use the speaker for long periods; be sure to store it in a dry place, free from the extreme temperature, humidity and dust.
4. Keep speaker away from any heat source.

Instruction of keys



- ① Power On/Off : Turn on/off the speaker device.
- ② Play / RGB button: Long press the button to play or pause music ; Short press to cycle through lighting effects.
- ③ + : Long press to increase volume; short press to skip to the next track.
- ④ - : Long press to decrease volume; short press to skip to the previous track.
- ⑤ DC 5V Type- C charging port

Operation

1. Turn on the speaker device. Bluetooth mode is enabled by default. Bluetooth Name: Cooler Bag 123, A tone will sound when Bluetooth is connected successfully.
2. TWS Function: Double press ④ " – " to enter TWS pairing mode — a beep confirms successful connection, and three short beeps indicate disconnection. After pairing, the master unit can turn off the slave unit and adjust its volume.

Inside Package

Speaker 1pc

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.