



Portable wireless speaker

HD-360


User's Manual

Please read this manual
before using the product

Thank you for choosing TREBLAB HD-360!

This speaker provides superior sound quality and portability, combined with entertaining features and the convenience of hands-free wireless operation.


WHAT'S IN THE BOX



HD-360

1. TREBLAB HD-360 speaker
2. User's manual and quick start guide
3. Type-C to Type-C charging cable
4. Type-C to Type-A charging cable
5. 3.5mm AUX cable
6. TREBLAB sticker

BUTTONS AND PARTS



BUTTONS AND PARTS

1	CHARGING INDICATOR
2	AUX INDICATOR
3	STATUS INDICATOR
4	NFC CHIP AREA
5	PAIRING BUTTON
6	PHONE BUTTON
7	EQ MODE INDICATOR
8	PLAY BUTTON
9	VOLUME - / PREVIOUS
10	VOLUME + / NEXT
11	VOLUME LEVEL INDICATOR
12	MICROPHONE
13	TYPE-C CHARGING PORT
14	POWER BUTTON
15	AUX PORT

SPEAKER FUNCTION

Function	Operation
Power ON	Press and hold the POWER button for 2 seconds.
Power OFF	Press and hold the POWER button for 3 seconds.
NFC connection	Approach the NFC module of your device to the NFC icon on the speaker.
EQ modes	Touch and hold the PLAY/PAUSE button for 3 seconds.
Play/Pause	Touch the PLAY/PAUSE button.
Volume +	Touch the VOLUME + button.
Volume -	Touch the VOLUME - button.
Next track	Touch and hold the VOLUME + button for 2 seconds.
Previous track	Press and hold the VOLUME - button for 2 seconds.

Answer a phone call	Touch the PHONE button during incoming call.
Reject a phone call	Touch and hold the PHONE button for 2 seconds during incoming call.
End a phone call	Touch and hold the PHONE button for 2 seconds when on call.
Voice assistant activation	Touch and hold the PHONE button for 3 seconds.
TWS mode	Take two HD-360 , connect one speaker to the device and double-touch the PAIRING button on it while the slave speaker is turned ON and in pairing.
Disconnect	Press and hold the PAIRING button for 2 seconds when connected to a device.
Factory reset	Press and hold the PAIRING button for 2 seconds when disconnected from a device.
Enable/disable sound prompts	Touch and hold the VOLUME + and VOLUME - buttons simultaneously for 2 seconds.

SETTING UP YOUR HD-360

Turn ON

Press and hold the **POWER** button for 2 seconds. You will hear the sound cue, the touch panel will light up and the BLUE state indicator will start flashing.

Turn OFF

Press and hold the **POWER** button for 3 seconds. You will hear the sound cue and all the lights will go off.

WIRELESS PAIRING

- Make sure **TREBLAB HD-360** is fully charged.
- Turn on your speaker. You will see the BLUE state indicator flashing, meaning that the speaker is in pairing mode.
- Activate the wireless communication function on the source device (smartphone, tablet, laptop).
- Select **TREBLAB HD-360** from the available devices list. Keep the speaker within 3 feet / 1 meter from the source device while pairing.
- If prompted to connect by your device, select Yes.
- If requested a passcode, enter 0000.
- Once **HD-360** is successfully paired and connected, the BLUE state indicator will stop flashing and stay BLUE.

RE-CONNECTING

After the initial pairing, the speaker will automatically connect to the previously paired device when turned on again. If reconnection does not happen automatically, the speaker will start looking for any other previously paired device within the effective distance range. **TREBLAB HD-360** can remember up to 6 recently paired devices.

TRUE WIRELESS STEREO (TWS) - PAIRING TWO SPEAKERS

The TWS technology allows you to use two speakers paired wirelessly to create a wireless dual-channel system, delivering a true stereo sound effect. While using this function, one speaker (Master) is paired with a source device, the other (Slave) speaker is paired with the Master speaker.

- Select which speaker will be the Master one, power it on and connect to the source device.
- Power on the second speaker and make sure it is in pairing mode (BLUE status indicator is flashing).
- Double-press the **PAIRING** button on the Master speakers to enter the TWS mode. You will hear the sound prompt, and see the BLUE status indicator and WHITE AUX indicator flashing alternatively.
- Once the speakers are paired in TWS, you will hear the sound prompt and see the steady BLUE state indicator on both speakers.

- Now you can use the speakers in stereo mode. Kindly note that the maximum distance between speakers should not exceed 33 feet | 10 meters.

There are a few ways to disable the TWS function:

- When the speakers are connected to the source device, touch and hold the **PAIRING** button for 2 seconds on the Master speaker - the connection with the source device will interrupt, but the speakers will remain in the TWS mode. This way you can connect another source device.
- When the speakers are connected to the source device, double-touch the **PAIRING** button on the Slave speaker – the Master speaker remains connected to the source device, but the Slave speaker will disconnect and enter the pairing mode.
- When the speakers are NOT connected to the source device, double-touch the **PAIRING** button on either speaker – TWS connection between them will be interrupted.

NOTE:

1. When connected in TWS mode, the calling feature is available on the Master speaker only.
2. Once both speakers are turned back on, they will try to reestablish the TWS connection. If you need to use only one speaker separately, make sure that the second speaker is turned off.

AUDIO PLAYBACK

- To pause and resume playback when connected wirelessly, touch the **PLAY / PAUSE** button.
- To adjust the volume, touch the **VOLUME +** or the **VOLUME -** button while listening to music.
- To change the track on the **HD-360**, touch and hold the **VOLUME +** or the **VOLUME -** button for 2 seconds.

AUX MODE

You can connect **TREBLAB HD-360** to compatible devices using the supplied 3.5mm AUX cable.

- Turn the speaker ON.
- Plug one end of the supplied 3.5mm AUX cable into the 3.5mm AUX cable port on the back of the speaker (under the rubber cover). Plug the other end into the 3.5mm jack on your device.
- The WHITE AUX indicator will light up. Now you can play music and audio.

NOTE: On-device control is not supported for the NEXT, PREVIOUS and PAUSE functions when using the 3.5 mm AUX cable. Phone calls management using the **PLAY / PAUSE** button is not supported as well. You will need to make adjustments using your smart device.

EQ modes

HD-360 provides three EQ presets: Balanced (**BAL** LED indicator on the control panel), 3D-Surround (**3D** LED indicator on the control panel) and Bass boost (**BASS** LED indicator on the control panel). To switch between the modes, touch and hold the **PLAY/PAUSE** button for 3 seconds.

NOTE: After turning on, the speaker will remember the EQ mode it was in before turning off.

PHONE CALLS

TREBLAB HD-360 can be used to make and receive phone calls when connected wirelessly. Audio playback will be paused during calls.

To answer:	Touch the PHONE button during an incoming call.
End a call:	Touch and hold the PHONE button for 2 seconds when on call.
To reject a call:	Touch and hold the PHONE button for 2 seconds.

NOTE: For better call quality, face the microphone when you speak.

CHARGING

When the battery is running low, you will hear a sound prompt (similar to a busy tone).

To charge the speaker, plug one end of the supplied cable into the Type-C charging port under the rubber cover on the back of the speaker. Plug the other end of the charging cable into the USB Type-C or USB Type-A port (depending on the cable used) of the charging device. Once the charging process starts, you will see the RED charging indicator, when the speaker is fully charged, the RED charging indicator will turn GREEN. It takes up to 3 hours to fully charge the speaker.

Unplug **HD-360** from the charging cable and the cable itself from the power source when not in use.

If the speaker is left unused, even the fully charged battery will lose

TROUBLESHOOTING

Problem	Solution
Not powering on	Make sure the speaker is fully charged. Charge for 2 hours, if necessary. Press and hold the POWER button for 2 seconds.
Not charging	Clean the charging port using a soft brush. Try charging the case with another Type-C cable, power source, adaptor (if available).
Not pairing	Make sure the speaker is in the wireless mode. Make sure the speaker is not paired with any other device, as it can only pair with one device at a time. Touch and hold the PAIRING button for 2 seconds. This will force the speaker to forget previously paired devices. Repeat the steps for pairing as previously described.

Not finding a wireless driver on your laptop

Make sure your laptop supports wireless connections. If it doesn't, you will need an external wireless USB adapter compatible with your laptop. For further details, consult with your laptop manufacturer.

Frequent disconnection and noise

Ensure that the distance between your device and the speaker is less than 33 feet/10 meters.

Ensure that nothing is blocking the signal between your device and the **HD-360**.

Check if the speaker is running out of power.

SAFETY RULES

- Don't disassemble or modify your speaker for any reason. Doing this may cause the speaker to malfunction or become combustible. The damage to your device can void the manufacturer's warranty.
- Make sure the speaker is completely dry before charging.
- Clean only with a dry cloth.

- Avoid exposing **TREBLAB HD-360** to extreme temperatures (below 37°F / 3°C or above 112°F / 45°C). Extreme temperatures can cause the deformation of the **HD-360** components and reduce the battery life and the lifespan of your new speaker.
- Don't put the device's LED lights close to humans' or animals' eyes.
- Do not use **HD-360** during a thunderstorm. Thunderstorms can cause serious malfunction and increase the risk of electric shock.

FCC STATEMENTS

FCC Compliance Statement - Part 15

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement - Part 15

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20cm during normal operation.

SPECIFICATIONS

Speaker size:	4 tweeters x 40mm , 1 bass driver x 75mm
Charging port:	TYPE-C
Audio port:	3.5mm jack
Dimensions:	5.51 x 5.51 x 7.67in / 140 x 140 x 195mm
Weight:	5.01lbs / 2274g

RECYCLING

The speakers can be recycled, and they should be in order to keep our planet clean. Where should you bring them?

In the **US**, there are a couple of options:

<https://www.call2recycle.org>

<https://search.earth911.com>

<https://recyclenation.com/find>

<https://www.cta.tech/Consumer-Resources/Greener-Gadgets>

In **Canada**, please visit the links below:

<https://thinkreuse.net>

<https://www.call2recycle.ca>

In the **UK**, please visit the links below:

<https://www.recycle-more.co.uk/>

<https://www.recyclenow.com/local-recycling>

THANK YOU

We truly appreciate that you chose **TREBLAB** as your trusted brand of wireless speakers and sincerely hope you enjoy the great sound and seamless usability **TREBLAB HD-360** provides.

We love making our customers happy by providing true value with our products. If for any reason you are not completely satisfied with your purchase or have any questions, please visit https://treblab.com/contact_us.

We care about our customers most of all and are always here to help you.



TREBLAB

1 YEAR WARRANTY

Parts and Labor Warranty

Please visit www.treblab.com to register
YOUR product.

Manufactured by Productech

Portable wireless speaker

HD-360



Made in China



WARNING: Cancer and Reproductive
Harm - www.P65Warnings.ca.gov

