




75 mm		110 mm			
User Manual Harry Potter Figural Mouse Model# HPX009A		CONTROLS  SPECIFICATION Material: ABS Plastic Connection Distance:33 ft±6.6ft/10M±2M Adjustable Resolution(DPI): 800-1200-1600 Button: 4 Function Buttons Requires Two (2) 1.5 V AAA Alkaline Batteries (not included) Minimum System Requirements: Windows 11, 10, 8, 7 macOS 10 or higher Package Contents: * Harry Potter Figural Mouse * 1 USB Dongle * User Manual		 Mouse Diagram: 1. Left Button 2. Right Button 3. Scroll Wheel 4. DPI Switch Button Battery Installation: * This mouse requires two AAA batteries (not included). * Locate the battery compartment on the bottom of the mouse. * Remove the cover and Insert the batteries, ensuring correct polarity (+/-). * Replace the cover securely.  AAA x 2 How to Use 1. Insert Batteries Open the battery cover on the bottom of the mouse and insert the required batteries (usually AA or AAA), ensuring correct polarity. 2. Plug in the USB Dongle Insert the USB Dongle into an available USB port on your computer. 3. Automatic Power On & Connection The mouse will automatically power on and connect once the batteries are installed and the USB receiver is plugged in.	
P1		P2		P3	
4. Automatic Pairing The mouse will pair with the USB receiver within a few seconds. No driver installation is required. 5. Adjust DPI (If Applicable) Press the DPI button to switch between different sensitivity levels for better control. 6. Start Using Once connected, the mouse is ready to use. Notes * If the mouse does not respond, try reinserting the USB Dongle or replacing the batteries. * Use the mouse within an effective range of up to 10 meters (32 feet). * Avoid using the mouse on reflective or glass surfaces for best performance.		WARNING: TO AVOID BATTERY LEAKAGE Requires 2 (Two) 1.5V AAA Batteries (Not included) The batteries used with this product are small parts and should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone American Association of Poison Control Centers (1-800-222-1222). Always purchase the correct size and grade of battery most suitable for intended use. Do not mix old and new batteries, alkaline, standard (Carbon-Zinc) or rechargeable (Nickel-cadmium) batteries. Clean the battery contacts and those of the device prior to battery installation. Ensure the batteries are installed correctly with the regard to polarity (+ and -) Always remove batteries if depleted or if product is to be left unused for a long time. -If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children. -Recycle or dispose of depleted batteries according to local regulations. WARNINGS • This is not a toy keep away from children under 6 years of age. • Keep away from heat and open flames. • Do not attempt to disassemble or reassemble this device. • Please pay attention to the anode and the cathode of the battery install. Questions? Comments? Contact: contact@culturefly.com		FCC STATEMENT NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Mouse FCC ID: 2A2WN-SCSB02 Dongle FCC ID: 2A2WN-SCJSQ01 FRN: 0031270333	
P4		P5		P6	

FRONT

BACK