



FOLDABLE LEATHER WIRELESS MOUSE



Hereby declare that item Foldable Leather Wireless Mouse is in Compliance with the essential requirements and other relevant conditions of Directive 2014/53/EU.


Instructions for Fold



Package includes

- Wireless Mouse - - - - - 1pc
- USB-C Charging cable - - - 1pc

Product Description




Instructions for Use

The switch located at the bottom of the mouse allows users to choose Bluetooth

1/Use Bluetooth version


- (1) Pull the switch button UP to the Bluetooth setting.



- (2) On the computer, start by finding the settings to add a Bluetooth device.

Adding Bluetooth or another device
Search for **AP2434** Mouse to connect.

AP2434 ... Bluetooth ...



Specification

Foldable Leather Wireless Mouse for Laptop/desktop	
Wireless frequency	2.405GHz-2.483Hz; Bluetooth 5.0
Product material	PU leather+ABS
Working distance	10meters
Interface	USB
Rating working voltage/current	5V/100mA
Resolution	800-1200-1600DPI
Button life	5,000,000 times
Power:	Polymer Li-battery 80mAh

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna.

NOTED:

1. Please charge the Mouse before use it.
2. Please turn off the power when not in use.

Warning

1. Keep your Wireless Mouse dry and away from moisture and corrosive materials.
2. Do not clean your Wireless Mouse with harsh chemicals, soaps or detergents. Just wipe it with a soft cloth.
3. The device can be used in locations with an ambient temperature of 0°C to 45°C.

