


80x120mm

Assembly Instruction

Tabletop Smokeless Fire pit

Menards® SKU: 2595278/2595279



Parts List:

No.	Description	Qty.
A	Body	1
B	Guide Ring	1
C	Removable Grate	1
D	Pellet Chimney	1
E	Heat Shield Plate	1

1. Removable grate (C) and Pellet Chimney (D) are placed inside the fire pit shown in the picture.
2. Put the Guide Ring (B) on top of the fire pit.
3. Spread out the three support legs to protect the table top from excessive heat.
4. The Heat Shield Plate (E) acts as a non-slip barrier while keeping out heat.
5. Put the wood or pellets between Removable Grate(C) and Pellet Chimney (D).
6. Put the Kindling block into Pellet Chimney (D).
7. Ignite the kindling block until the wood burns.

Note: Pellet or wood can be placed inside the fire to use.

WARNINGS

- Never leave the hot fire pit unwatched.
- Do not move the unit during use.
- Do not put away the fire pit until it has cooled down.
- The fire pit should be used together with Heat Shield Plate to avoid scalding table top surface.
- It is very hot! Keep the children and pets away when the fire pit during use.
- After completely cooling naturally, take off the Guide Ring and extinguish the ash after burning. Install the internal parts of the fire pit, fold three legs and place it in the carry bag, which can be used directly next time.