

U NANO SPEAKER
User Manual

1. Speaker Grille
2. RGB LED Indicator
3. Microphone
4. Charging LED Indicator
5. USB-C Charging Port
6. Power / Multifunction Button
7. Lanyard Attachment Hole

Charging the Battery:

- Connect the USB-C cable to the speaker and plug the USB-A end into a 5 V USB power source. The charging LED indicator will light up.
- When charging is complete, the charging LED indicator will turn off.
- When you hear the "Di-Di" warning tone or notice reduced volume, recharge the speaker.

Bluetooth Pairing:

- Press and hold the Power button to turn on the speaker. You will hear a voice prompt, and the LED indicator will begin flashing to indicate pairing mode.
- Enable Bluetooth on your device and search for "U SPEAKER-NANO".
- Select "U SPEAKER-NANO" to pair.
- A voice prompt will confirm successful pairing.
- Once paired, the speaker will automatically reconnect to your device when Bluetooth is enabled and the speaker is powered on.

True Wireless Stereo (TWS) Pairing:

- Turn on both speakers.
- Double-press the Power button on either speaker.
- The speakers will automatically pair with each other within approximately 3 seconds.

Enable Bluetooth on your device.

- Select "U SPEAKER-NANO" from the Bluetooth menu.
- A voice prompt will confirm successful pairing.

Music Playback & Calls:

- Open your preferred music app on your Bluetooth device.
- Use the multifunction button to:
 - Play/Pause music
 - Skip tracks
 - Answer calls
 - End calls
- To turn off the speaker, press and hold the Power button for 2 seconds.

Usage Notes:

- Bluetooth performance may be affected by obstacles such as walls, metal objects, trees, or other materials. These may reduce the effective operating range.
- Fully charge the speaker before first use for optimal performance. Low battery power may affect sound quality.
- Do not expose the speaker to high temperatures or excessive moisture.

Specifications:

Power Output	3W
Frequency Response	20 Hz-20 kHz
THD	< 1%
Signal-to-Noise Ratio	≥ 80 dB
Speaker Driver	Ø36 mm, 4 Ω, 3 W
Battery	3.7 V / 300 mAh
Bluetooth Version	Bluetooth® 5.3
Product Size	Ø50 × 33 mm
Product Weight	70 g

www.uspeaker.com
© 2026 I&O Designs and Logistics, DBA Fashionist. All rights reserved.
FCC RoHS

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.