


HD285 LAMBORGHINI RC PKG
GLOSSY FINISH

FACTORY PLEASE
ADD DATE CODE
NEAR BARCODE
AS INDICATED



HD285 LAMBORGHINI INSTRUCTIONS (1 color) 8.267 x 11.22

5+

HURACAN STO RC

INSTRUCTIONS MANUAL

To load battery on controller
(Please use it under guidance of adult)

Open the battery cover on controller in the direction as shown in .

Set 2X1.5V battery in the correct direction.

Replace the battery cover on controller in the direction as shown in .

Installation of car body batteries group
(Please use it under guidance of adult)

Unscrew the battery cover with a plus driver, press the buckle and open the cover.

Set 4X1.5V batteries in the correct direction.

Replace the battery cover and fix with screw.

Operating Instruction

THINAIR BRANDS

www.ThinAirBrands.com
© 2026 Thin Air Brands, LLC.
Parker, Colorado 80134 USA
MADE IN CHINA

PRODUCT COLOR(S) MAY VARY FROM SHOWN ON PACKAGE. Please retain packaging for future reference as it contains important information. All materials for fastening or packing purposes are not part of the toy and should be discarded for children's safety.

FOR BEST PERFORMANCE:
Do not use rechargeable batteries. Do not mix battery types. Do not mix old and new batteries. Do not mix alkaline, standard (carbon zinc) or rechargeable batteries. Do not dispose of batteries in fire, they may leak or explode. Remove batteries from toy when not in use. Non-rechargeable batteries are not to be recharged. Exhausted batteries are to be removed from the toy. The supply terminals are not to be short-circuited. Only batteries of the same or equivalent type as recommended are to be used. Dispose of batteries properly, be environmentally aware: do not burn or bury old batteries. Rechargeable batteries are to be removed from the toy before being charged. Rechargeable batteries are only to be charged under adult supervision. The battery chargers are to be regularly examined for damage to the cord, plug, enclosure and other parts, and in the event of such damage, they must not be used until the damage has been repaired. Batteries are only to be charged by adults or by children at least 8 years of age. The rechargeable lithium-ion battery is not replaceable.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and, (2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encourage to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and the receiver.
• Connect the equipment into an outlet on a circuit different from that which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

PRODUCT COLOR(S) MAY VARY FROM SHOWN ON PACKAGE. Please retain packaging for future reference as it contains important information. All materials for fastening or packing purposes are not part of the toy and should be discarded for children's safety.

FOR BEST PERFORMANCE:
Do not use rechargeable batteries. Do not mix battery types. Do not mix old and new batteries. Do not mix alkaline, standard (carbon zinc) or rechargeable batteries. Do not dispose of batteries in fire, they may leak or explode. Remove batteries from toy when not in use. Non-rechargeable batteries are not to be recharged. Batteries are to be inserted with the correct polarity. Exhausted batteries are to be removed from the toy.
The supply terminals are not to be short-circuited. Only batteries of the same or equivalent type as recommended are to be used. Dispose of batteries properly, be environmentally aware: do not burn or bury old batteries. Rechargeable batteries are to be removed from the toy before being charged. Rechargeable batteries are only to be charged under adult supervision. The battery chargers are to be regularly examined for damage to the cord, plug, enclosure and other parts, and in the event of such damage, they must not be used until the damage has been repaired. Batteries are only to be charged by adults or by children at least 8 years of age. The rechargeable lithium-ion battery is not replaceable.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and, (2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encourage to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and the receiver.
• Connect the equipment into an outlet on a circuit different from that which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.