



# ROKU REPLACEMENT REMOTE


## SM-ROKU-104



# EMERALD<sup>®</sup>




- 1**  **TV MUTE:** Cuts off the sound temporarily.

 **TV POWER:** Turn on/off the TV.

 **BACK:** Goes back to previous menu/screen.  
Home screen tile: Moves highlight back to the Home screen option.  
Watching Antenna TV or a TV input: Returns to Home screen.  
Playing streaming content: Stops playing stream and returns to the previous menu or screen.  
Browsing streaming content: Goes to the previous level in the content tree.

 **HOME:** Immediately returns to the Home screen.
- 2**  **INSTANT/REPLAY:** Select models Streaming programs that support this feature and broadcast TV if Live TV Pause is enabled, jumps back a few seconds with each press and resumes playing.  
Broadcast TV if live tv pause is disabled, jumps to previous channel.  
When using an on-screen keyboard, backspaces in the text you are entering.

 **OPTIONS:** Displays additional options when available.
- 3** **Accesses to your favorite channel**  
NETFLIX, hulu, raio,  
vudu, YouTube (Spotify), MGO (SHOWTIME),  
Google (HBO NOW), CINERPLEX (CBS NEWS), amazon, sling