

INSTRUCTION MANUAL SPEAKER (VT-4000W)



INTRODUCTION

Thank you for selecting and buying V-TAC Product. V-TAC will serve you the best. Please read these instructions carefully & keep this user manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best.



Multi-Language Manual QR CODE

Please scan the QR code to access the manual in multiple languages.

TECHNICAL SPECIFICATIONS

- Input Power: 5V == 1A
- Output Power: 20W
- Woofer: 2x6.5 inches
- Speaker: 3Ω 10Wx2
- Frequent Effect: 100Hz - 18KHz
- BT version: 5.0
- S/N: ≥80dB
- FM Radio Frequency: 87.5-108MHz
- P.M.P.O: 400
- Rechargeable Battery: 3.7V 2400mAh
- Working time: Playtime 2-4 hours
- Charging Time: 5-6 hours
- Dimensions: 27x25x53.5cm
- Supporting: USB/TF card play
- Speaker weight: 3500g

ATTENTION

1. To maintain battery life, please charge the battery every time the power is completely depleted. Damage may occur if the battery is not charged for longer periods, so please use and charge the battery at regular intervals.
2. Our company reserves the right to update the product without any notice.
3. If you have any issue with the product, kindly contact a professional technician. Do not open the unit yourself.
4. For safety reasons, keep the device away from children.

INSTRUCTIONS

1. This unit uses a rechargeable battery. When the battery power is depleted, please plug the device to an electric socket with the correct input voltage.
2. When the unit is charging, please make sure to switch on the AC/DC option, then safely unplug when finished.
3. On first use, the battery must be charged for 10 to 12 hours.
4. The unit's battery working time lasts up to 3 to 6 hours, depending on the usage.

BLUETOOTH FUNCTION

When you turn on the speaker, Bluetooth function will be activated. Search for the Bluetooth "V-TAC VT-4000W" on your device and connect

Bluetooth connection status, press and hold the "TWS" key, and then turn on another audio, press and hold the "TWS" key for the same time, at this time, the two audio will automatically pair. Successfully connected to 2.0 sound effect. Some products do not have this function


PACKAGE INCLUDED

- Speaker (1Pc)
- User Manual (1Pc)
- USB Cable (1Pc)

CHARGING INDICATOR

Connect the charging cable to the DC: 5V == 1A adapter, plug it into the charging port after the machine is turned off; red light will be on when charging, red light will be off when it is fully charged. The time of full charge is about 6 hours.

PANEL FUNCTION



1. TF card,U Disk reader function(Max support 64G), MP3 format can be play. (Some products do not have TF card holder, please buy USB card reader).
2. The speaker will automatically read the first input media device.
3. Press "PREV I◀◀" key is last song, long press it is Volume decrease.
4. Press "NEXT ▶▶" is next song, Long press it is Volume increase.
5. Long Press "LED off/on" LED power switch off.
6. Long Press "TWS" True Wireless Stereo, Connect another speaker.
7. Press "MODE" choose "BLUE", "USB" and "TF" play state.
8. Press the "REC/Del" key to enter the recording mode, and then press "REC/Del" key to exit recording and play recording content. (Some machines do not have this function).
9. Long Press "REC/Del" key to delete the recording file. (Some machines do not have this function).
10. Press the "MIC priority" key to insert the microphone when the music is playing. The microphone has the priority function.
11. In AUX State, connect 3.5mm stereo audio cable to the socket "AUX" you can enjoy the music from mobile phone, MP3, MP4, Mp5, PC, IPOD, and other audio devices.