



# DASH7

Wireless Microphone with 8 Pin Receiver



User Manual

## Packing List

Microphone Transmitter x 1 N

8 Pin Receiver x 1 N


Type C Charging Cable x 1 N

User Manual x 1 N

## Thanks for choosing our product

This product is a smart wireless microphone that provides professional-grade recording output. Plug and play, no app required. Multiple uses: It can be used in online live broadcast, video Vlog shooting, program interview, recording, video teaching and other occasions.


The wireless Microphone consists of two parts, one is Microphone transmitter, the other one is 8 Pin receiver. (See as below picture




1. Windproof net
2. Microphone indicator
3. Microphone 8 Pin charging port
4. Microphone clip
5. Switch key
6. Microphone reset key
7. 8 Pin port to connect phone
8. Receiver indicator
9. Reset button
10. Type C port of receiver

## How To Use:


Step 1: Connect the 8 Pin receiver to phone with 8 Pin port. The connection is successful if the phone displays a small icon.



Step 2: Press switch key of microphone, the indicator light turns green, and then power is turned on.




Step 3: The indicator red light of receiver keeps always on, then open the phone camera, live App or other Apps, and then to use the microphone to receive sound.



## Special Note:

For the use of 8 Pin port: there is no battery in 8 Pin receiver, and no need to recharge during live. If the phone is low power during Live, it can be recharged directly through 8 Pin port.



**Note:** Can only listen to video or recording effect after the receiver is pulled out of the device

## About UI

### Type C Receiver :

<b>Function</b>	<b>How To Use</b>	<b>Light</b>
Power on	Plug in the device	Red light on
Power off	Plug off the device	light off
Pairing		Red light flashes slowly
Paired		Red light on
Clear pairing	Press the reset key twice quickly	Red light flashes slowly

### Microphone Transmitter :

<b>Function</b>	<b>How To Use</b>	<b>Light</b>
Power On	Press switch key once	Green light on
Power off	Press switch key about 3-4 seconds/Auto power off if no reconnection in 10 min	Green light on for 1 second
Charging	Charging with Type C cable	Red light keeps on when charging, & light off when fully charged
Pairing		Green light flashes slowly
Paired		Green light keeps on
Battery alarm	Battery is below 20%	Blue light flashes slowly
Reset	Press reset key for 3 seconds	
Pause	Press switch key once	Blue light keeps on
Clear Pairing	Press the reset key twice quickly	Green light flashes quickly

### **Microphone Specification :**

Frequency : 2.4 GHz

Input Voltage : DC 4.8~5.4V

Working Time : 6 Hours

Batter Capacity : 70mAh (button cell)

Type : Digital Mic

Sensitivity : -26dBFS

S/N Ratio : 64 dB(A)

Frequency Range : 20~20KHZ

Transmission Latency : 28 ms

Indicator Light : Red/Green/Blue

Charging : Type C

Weight : 6.7gm

Size : 58.7 x 22.8 x 25 mm

### **Type-C Receiver Specification :**

Frequency : 2.4 GHz

Input Voltage : DC 4.8~5.4V

Charging : Plug In Device

Indicator Light : Red

Size : 44.34 x 26.42 x 9.52 mm

**Note:** If you encounter connectivity issues with any mobile phones, access your device settings, search for "OTG" and enable the OTG power supply. Certain phones, which cannot use their own camera to shoot audio, may need to install the "Open Camera" app for recording. If you encounter further connection problems, feel free to reach out to us directly for assistance.



[www.portronics.com](http://www.portronics.com)

**For Support**

**Visit :** [www.portronics.com](http://www.portronics.com)

**Email :** [help@portronics.com](mailto:help@portronics.com)

**Contact No. :** +91 9555245245, 011-42413131

**(Working Hrs. : Monday – Saturday 10:00am – 6:00pm)**



E-Waste Management  
E: [info@3rrecycler.com](mailto:info@3rrecycler.com)

For E-Waste & ROHS compliance  
refer to [www.portronics.com/ewaste](http://www.portronics.com/ewaste)