

XTREME [®] DIGITAL LIFESTYLE ACCESSORIES		PRINTER SLUG FOR TECH PACK	
BRAND: XTREME CATEGORY: Audio FILE NAME: XBE9-1043_UserManual ITEM NUMBER: XBE9-1043		ADDITIONAL PRINTING PROCESSES: UV SPOT: GLOSS METALLIC FOIL: DEBOSS: EMBOSS: VARNISHING TECHNIQUE: MATTE LAMINATION	
PRESS WORK: PRINT 1/1. TRIM TO SIZE, SCORE, FOLD WHEN SPECIFIED SCALE: 100% ASSEMBLED PACKAGE DIMENSIONS (in Inches) WIDTH: 3" HEIGHT: 4.9" DEPTH: DIELINE OVERALL DIMENSIONS (in Millimeters) WIDTH: 78.065mm HEIGHT: 124.873mm		PRESS SPEC COLOR REFERENCES DIELINE GLOSS UV SPOT EMBOSSING (RELIEF) DEBOSSING (SUNKEN) FOLDING LINE PRODUCT PLACEMENT FOILING GLUE FOLD Ø20mm SECURITY STICKERS PLACEMENT BLISTER OR INNER TRAY PLACEMENT CLOTH LIFT TAG	
MANUAL MATERIAL, THICKNESS & SIZE SUBSTRATE TYPE: MATTE ART PAPER C2S, 100gsm WINDOW: INNER TRAY: BLISTER: PLASTIC BAG: MAGNET: VELCRO: SECURITY STICKERS: HANG TAB COLOR/ MATERIAL/SIZE: FOAM CORRUGATED BOARD: PAPERBOARD: USER MANUAL: PRINT 1/1 IN BLACK ONLY		ADDITIONAL PANTONE COLORS (NOT CMYK) SOLID COLOR NAME: NEON COLOR NAME: METALLIC COLORS: VENDOR'S FOIL NAME/NUMBER:	
PACKAGING TYPES FOLDING CARTON: FOLDING CARTON WITH DOOR PANEL: RIGIT GIFT BOX: CLAMSHELL: SLIDING/SLIPCASE: TRAPPED BLISTER CARD BLISTER CARD: OTHER:		FILE SAVED AS: .ai = FULLY EDITABLE -OUT.ai = OUTLINED .pdf = Acrobat .jpg = Flat image .png = DIGITAL (transparent background)	
		APPROVAL CHECKLIST: PRIMARY DESIGNER: Rita Manukyan DATE: 12/08/2025 SECONDARY DESIGNER: DATE: PROOF READ: DATE: APPROVED BY: DATE: AUTHORIZATION SIGNATURES:	

Press Ready Artwork.
DO NOT PRINT THIS LAYER:
Printer Slug

PRINTABLE LAYER:
Manual Artwork

OPERATIONS		FCC STATEMENT		ONE YEAR LIMITED WARRANTY	
POWER ON: To turn on the earbuds, simply remove them from the charging case. They will power on automatically, enter Bluetooth search mode, and provide a voice prompt "Power On" with lights flashing. Alternatively, if the earbuds are off and outside the case, press and hold the button for 5 seconds. The same voice prompt and LED indicator pattern will confirm they are powering on. POWER OFF: The earbuds can be turned off in the following ways: Return to Case or Hold button for 5s. NOTE: When powering off, both earbuds will turn off but when powering on, you have to turn on each earbud individually. BLUETOOTH PAIRING The earbuds first pair with each other when powered on, then go into pairing mode (The main earbud indicated light fast flash, while the secondary ears have no lights.) Turn on Bluetooth on your phone and connect to "Xtreme XBE9-0143-BLK" or "Xtreme XBE9-0142-RSG". NOTE: • Earbuds will automatically reconnect to the device if back within effective range within ~5 minutes. If not, manual connection is required. Earbuds auto power off after 5 minutes of disconnection. • The earbuds will enter the disconnected state if they move out of Bluetooth range or if Bluetooth is manually turned off on the phone. In this state, the earbuds will go back into Bluetooth pairing mode. MUSIC MODE Play/Pause: Double-press left or right touch control area. Previous Track: Triple-press left touch control area. Next Track: Triple-press right touch control area. CALL MODE Answer/End: Double-press left or right touch control area. Reject Call: Press and hold left or right touch control area for 2 seconds, with an audible prompt. Voice Assistant / Siri: Quadruple press left or right touch control area. You will hear a tone to confirm the activation.		Any changes or modifications not expressly approved by the party responsible for compliance could void this user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct interference by one or more of the following measures: • Reorient or relocate the receiving antenna • Increase the separation between the equipment and receiver • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected • Consult the dealer or an experienced radio/TV technician for help FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. FCC ID: 2AHAS-XBE90143ER FCC ID: 2AHAS-XBE90143EL		Xtreme warrants its products for one year against defects in manufacturing under regular consumer use with original receipt of retail purchase. We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt. *Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied. Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property. For instructions about how to obtain warranty service for your product, please contact Customer Service: customerservice@xtremecables.com Scan the QR code below, or on the front of this manual to extend your warranty from 1 Year to 2 Year Limited. Scan to Extend Your Warranty	
5		6		7	

BACK PAGE

SAFETY AND CARE INSTRUCTIONS		INTRODUCTION		PRODUCT DESCRIPTION	
Read all the instructions before using the product and then store them for future reference: • Noise is measured in decibels (dB). Long-term exposure to noise levels of 85 dB or higher can gradually cause hearing loss. To protect your hearing, monitor your usage: the louder the sound, the shorter the time you should be exposed to it. Conversely, the softer the sound, the longer you can listen safely. For more information on safe listening levels and other important safety guidelines, please visit the Consumer Electronics Association website at www.ce.org. For detailed information on preventing noise-induced hearing loss (NIHL) and a comprehensive list of harmful noise levels, visit the Foundation for the Study of the Hearing Impairment at www.drf.org. • Turn down the volume on the earbuds before turning on audio playback. • This product is not a toy. Do not allow children or others who require supervision to use the product unsupervised. This product contains a non-replaceable rechargeable lithium-polymer battery. When discarding, follow your local/state guidelines. • Do not use abrasive cleaning solvents to clean the unit. • Disconnect the USB cable once the product is fully charged. • Do not expose to heat sources or leave in a location that is likely to get excessively hot. • Do not let the product get wet. • Do not disassemble. • Performance can be affected by the environment or when the product becomes discharged. • Interruption can be caused by obstacles between the product and the Bluetooth device, by Wi-Fi or other high frequency signals, or if the product is brought out of range of the Bluetooth device. • Charge fully before storing for a long period. Note: Lithium-polymer batteries will self-discharge over time. To ensure battery life, do not store the product in an uncharged state for a length of time. If left in a discharged state for too long a lithium-polymer battery will no longer have the ability to be recharged.		Thank you for choosing the Xtreme STRYD Open-Ear Buds. Designed for active lifestyles, they keep you aware of your surroundings while delivering crisp, immersive sound. With all-day comfort, intuitive controls, and a sleek charging case, your music moves with you—anywhere. FEATURES • Open ear design sits securely and comfortable outside your ear • Listen to music and take calls without blocking the ambient noise around you • One touch control to play, pause and answer calls • Travel-friendly charging case to recharge your buds on the go SPECIFICATIONS Material: ABS Earbuds Battery capacity: 28mAh Charging Specification: 5W/0.2A Charging Case: 200mAh Speaker Specification: F14.2mm, 32Ω, 105dB±3dB Bluetooth Range: 33ft Playback Time: 6-10 hours (at 70% volume) Charging Time: 2 hours USB Charging Cable Length: 11.8in WHAT'S INSIDE • Open Ear Buds • Charging Case • USB-C Charging Cable • User Manual		LED Light USB-C Charging Port Charging Pins LED Light Speaker Touch Control Area Outer Ear Hook • Carefully remove the components from the packaging. • Remove the earbuds from the charging case to power them on. • Remove the protective tape from the charging pins before first use. • Your earbuds come fully charged so you can use them immediately. HOW TO CHARGE Charging Case: To charge your earbuds, you must first make sure the case is fully charged. Insert the USB-C end of the included charging cable into the USB-C port on the charging case. Plug the other end into an appropriate power source. The LED indicator light will blink to indicate it is charging. Earbuds: Your earbuds will automatically charge when placed correctly in the included charging case. The LED indicator light on the earbuds will glow to indicate they are charging.	
1		2		3	

XTREME[™]
SOUND

TRUE WIRELESS STEREO
STRYD
OPEN-EAR BUDS
WITH CHARGING CASE




XBE9-0143-BLK
User Manual V1.0 1225
855.999.8041 | WWW.XTREMECABLES.COM




Scan to Extend
Your Warranty

HOW TO WEAR YOUR EARBUDS



TIP: When placing your earbuds in the charging case, they must be positioned correctly as shown:

These earbuds feature an open-ear design with a tail that hooks around your outer ear for security and comfort. Use the following diagram to fit them correctly:



Identify the earphones using the inner L and R labels.

Place the main bud against your inner ear and hook the tail around your outer ear as shown.



Once the tail is securely hooked around your outer ear, you can gently reposition the bud as needed for comfort and improved sound quality.