

Diagram illustrating the components of the HUAWEI FreeBuds 4i charging case and earbuds:

- 多功能键 (Multi-function button)
- 电量显示 (Battery level display)

接听电话：来电时电话号码播报，短按任意（R,L耳）耳机都能键接听电话

挂断电话：短按任意（R,L耳）耳机多功能键挂断电话

拒接来电：长秒耳机多功能2秒键“嘟”拒接

操作耳机具有语音播报提示：开机、关机、连接成功、连接断开、低电报警等。

答：可更换一条充电线尝试一下，或接口没插好

这对所有可充电电子产品来说都是正常的。

备 注



multiple use key

multiple use key

Power display

Rejecting Calls: Press and hold the earphone's multifunctional button for 2 seconds, and a "beep" sound will indicate rejection of the incoming call.

Launch Voice Assistant (Siri): In standby mode, long-press the touch key for 1.5 seconds and release to activate the voice assistant (requires phone support).

Use the included charging cable and insert it into the charging case's port. The red light will flash during charging. After the charging case is fully charged, its indicator light will stay on.

Operating the earphones is equipped with voice prompts for: power on, power off, successful connection, connection disconnected, low battery alert, etc.

Supported Devices: Bluetooth devices such as mobile phones

Q: The charging case cannot charge the earphones.

the battery performance over time, which is normal for all rechargeable electronic products.

Notes _____



FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.