

PRODUCT SPECIFICATIONS

- Charging: USB5V
- Battery capacity: 1,200 mah
- Battery charging current: 500 mA
- Hands-free power amplifier: 5W

- Keys: 0,1,2,3,4,5,6,7,8,9, *, #, hands-free, redial, power button

WORKING MODE:

- Music mode
- Hands-free phone mode (press the hands-free button to enter)
- Handle phone mode (pick up the phone handle to enter)

KEY PRESS TONE

1. English
2. Chinese
3. DTMF key tone

- voice control:
- In music mode, press * (star key) to increase volume, press # (pound key) to decrease volume
 - Chinese and English switch press and hold the * key to switch
 - Key tone and human voice switch double-press the # key to switch
 - Press and hold the # key to switch the ringtone

BLUETOOTH CONNECTION:

- **Bluetooth Pairing:** After turning on the device, turn on the Bluetooth search of the mobilephone, click the Bluetooth pairing name: "Throwback Phone" to connect;
- **Turn on the speaker**, it enters the automatic connection state.
- If the 3 attempts are unsuccessful, the waiting connection state is entered.
- If there is no connection within 2 minutes, the device will enter the low power mode, and the device can be woken up by pressing any key or the handle.

THROWBACK

HELLO THERE!

VOICE PHONE WITH WIRELESS SPEAKER



TB-RTVNTPH INSTRUCTIONS MANUAL

PLAY AUDIO:

- In the music mode, the hands-free speaker of the device can be used to play audio.
- When there is an incoming call, or when the hands-free mode is entered or the handle is picked up, the audio playback will pause.
- To continue playing the audio, manual operation on the connected external device is required.
- The volume can be adjusted through the connected external device, or via the * key or # key.

HAND-FREE CALL:

- Press the hands-free button to enter the hands-free call mode.
- Press the corresponding buttons to dial;
- Once the call is connected, hands-free communication can be carried out.
- During the call, pressing the hands-free button again can end the current call.

- If the handset is picked up during the call, it will enter the handset call mode;
- If the handset is put down at this time (handset on-hook), the call will end.

HANDLE CALL:

- Pick up the handset to enter the handset call mode. Dial correctly, and once the call is connected, you can enter the call state.
- During the call, placing the handset on-hook will end the call.

- If the hands-free button is pressed during the call, it will switch to the hands-free call mode;
- Even if the handset is put back on the phone base, the call can still continue.
- Pressing the hands-free button again will end the call.

REDIAL :

- After pressing the hands-free button or picking up the handset, press the redial key to access the last record in the redial call log.

FCC WARNING STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

ThrowBack® COPYRIGHT ALL RIGHTS RESERVED. ThrowBack® is an innovative brand of BH Brand Holding LLC. No portion of this design may be reproduced without express written permission. Other trademarks and trade names are those of their respective owners. All rights reserved. Distributed by Truststone Group LLC, New York, NY 10018.

Visit our Website at www.truststonegroup.com

WARNING: Cancer risk from Lead Exposure-www.P65Warnings.ca.gov
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



MADE IN CHINA