

User Manual of the Remote Control (HP012)

Thank you for purchasing the remote control. The remote control can be programmed to TOPENS/CASAR/ALEKO gate opener directly.

⚠ The remote control *MUST* be programmed to the opener *BEFORE OPERATING*. Please follow the steps to program the remote control. More detailed instruction refers to the gate/door opener user manual.

⚠ If you lose one of any remote control, please erase and reprogram all other remote controls to have a new code for safety.

⚠ Max. 8 remotes can be programmed for the opener.

⚠ Please turn off the power of the remote control to extend the battery life. (The power switch is on the right side of the case)

1. How to Program the Remote Control to the Opener

Press and release the **remote control programming button (CODE SW button, LNSW button, Learn button, etc.)** on the control board, the **CODELED (REMLED, LEARN LED, LCD, etc.)** will be ON or indicate the programming display, then press the key on the remote **two times** in 2 seconds, **between the two times HOLD ON FOR A MOMENT**, the **CODELED (REMLED, LEARN LED, LCD, etc.)** will flash for 3 seconds and then to OFF or standby display. Now the remote control has been programmed successfully.

2. How to Erase All the Remote Codes

Press and hold the **remote control programming button (CODE SW button, LNSW button, Learn button, etc.)** on the control board until the **(REMLED, LEARN LED, etc.)** from ON to OFF or LCD display “dL”, and then release the button. Now all remote codes have been erased.

3. How to Replace the Batteries

9V Carbon battery are used to power the remote control. You can replace the batteries as the following steps.


Step 1: Remove the battery cover and replace the batteries with a new one.

Step 2: Re-install the battery cover .

4. How to Extend the Remote Control Range

You can pull the antenna out of the control box or the receiver to extend the remote control range.

Also you can try to replace the batteries with new ones when the range is reduced too much.



FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment

oes cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-

Consult the dealer or an experienced radio/TV technician for help important announcement

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.