


# How to add SmartThings drivers for THIRDDREALITY Smart Blind/Smart Button/Smart Switch/Contact Sensor/T&H Sensor/Multi-Function Night Light

1. Open this link in your PC browser. <https://bestow-regional.api.smarthings.com/invite/adMKr50EXzj9>
2. Log in your SmartThings Account.



4. Click "Enroll" --"Available Drivers" -- "Install" to install the device driver as needed.  
Install "Zigbee Switch" for Zigbee Multi-function Night Light.

- Name  
Zigbee Window Treatment
- Description  
ThirdReality window treatment devices drivers
- Permissions
  - zigbee: Enable full access to Zigbee actions

**Install**

- Name  
Zigbee Button
- Description  
SmartThings driver for Zigbee button devices
- Permissions
  - zigbee: Enable full access to Zigbee actions

**Install**

- Name  
Zigbee Switch
- Description  
SmartThings driver for Zigbee switch devices
- Permissions
  - zigbee: Enable full access to Zigbee actions

**Install**

- Name  
Zigbee Contact
- Description  
SmartThings driver for Zigbee contact devices
- Permissions
  - zigbee: Enable full access to Zigbee actions

**Install**

- Name  
ThirdReality Humidity Sensor
- Description  
ThirdReality Temperature and Humidity sensor drivers
- Permissions
  - zigbee: Enable full access to Zigbee actions

**Install**

5. Reboot your SmartThings hub by powering it off and power it on again.

6. "Scan for Nearby Devices" in SmartThings App to pair the THIRRELAITY devices with your SmartThings hub.