品名：说明书
尺寸：75*95mm
材质：105G双胶
双面单色印刷，风琴折

4C+1专

Model: BS12317

BUGANi

BUGANi Rove Go 5




用户手册

本产品外包装不含塑料公司承诺
可完全回收，如回收！

CN

产品概述



1.指示灯
2.上至六TWS
3.音量减/上一曲
4.播放/暂停
5.音量加/下一曲
6.蓝牙广播
7.开/关机
8.TF卡
9.USB-C充电接口

CN

充电



红色指示灯长亮	充电中
红色指示灯熄灭	充满电

首次使用充电前已有完全干燥时，请勿插入充电线，将音响放在
每空气流通的干燥区域，让充电口自然风干。

CN

开机/关机



按住电源开 / 关机键 2 秒即可开启音响。
再次按住电源开 / 关机键 2 秒即可关闭音响。

长按2秒	开机
自行点亮	
长按2秒	关机
自行熄灭	

开机后即没有连接到蓝牙设备，音响大约在 15 分钟后关闭。

CN

蓝牙配对

• 首次使用并开机时，音响将自动进入配对模式。
• 如已连上蓝牙设备，按按 " ⏻ " 键，即可断开当前连接以便与其它设备进行配对。
• 对没有连上蓝牙设备，音响也会自动进入配对模式。
配对时，此指示灯的蓝牙功能，搜索 " **BUGANi Rove Go 5** " 进行连接，连接成功后会自动退出蓝色，蓝牙自己指示灯会不亮。



长按2秒	开机后自动进入蓝牙配对模式
自色指示灯闪烁	蓝牙配对
自色指示灯长亮	蓝牙已连接

说明：○ 表示指示灯长亮
● 表示指示灯闪烁
✹ 表示指示灯闪烁

CN

音乐控制

短按 " ▷ " 键播放或暂停音乐。
长按 " ▷ " 键转到下一首歌曲。
长按 " ◁ " 键转到上一首歌曲。

音量控制

短按 " + " 键调高音量。
短按 " - " 键调低音量。

通话控制

接听来电：短按 " ▷ " 键
拒接来电：长按 " ▷ " 键。
结束通话：短按 " ▷ " 键。

语音助手

已连接蓝牙状态，双击 " ▷ " 键启用 / 关闭语音助手。

CN

TF CARD 模式播放


将包含可播放音频内容的 TF 卡存储设备插入音响的 TF 卡接口。
• 音响自动切换到 TF 卡模式。
• 自动播放所有内容。



TWS (无线立体声) 模式

您可以在 TWS 模式中将两个相同的 " **BUGANi Rove Go 5** " 连接在一起。
1. 确保音响没有连接到手机。
2. 将连在音源中的上的 " ⏻ " 按钮，音响将自动配对。配对成功后，主音响蓝牙指示灯闪烁，副音响蓝牙指示灯长亮。
3. 开启手机蓝牙功能，搜索 " **BUGANi Rove Go 5** " 进行连接。连接成功后，您会听到音响音量，主音响蓝牙指示灯长亮，副音响蓝牙指示灯长亮。
4. 退出 TWS 模式：双击任意主音响上的 " ⏻ " 键，音响自动退出 TWS 模式。

CN




白色指示灯闪烁	TWS配对
白色指示灯闪烁 (音响1)	TWS连接
白色指示灯长亮 (音响2)	

CN

蓝牙广播模式

设置一个 " **Rove Go 5** " 为主音响，可连接 100+ " **Rove Go 5** " 副音响作制派对。
1. 首先，将其中一个 " **Rove Go 5** " 音响连接到您的蓝牙设备 (例如手机) 作为主音响并播放音乐。
2. 短按主音响其它 " **Rove Go 5** " 音响上的 " ⏻ " 键，进入蓝牙广播连接模式并自动连接。
3. 连接成功后，主音响上的绿色 LED 指示灯继续闪烁，副音响上的绿色 LED 指示灯由闪烁变为长亮。


成功进入蓝牙广播模式后：
• 您可以通过控制主音响来调用有音响，调节音量等。
• 您可以分别来调每个音音响的电源。
• 如要退出蓝牙广播模式，请再次短按任意音响上的 " ⏻ " 键。



绿色指示灯闪烁	蓝牙广播配对
绿色指示灯闪烁 (音响1)	蓝牙广播连接
绿色指示灯长亮 (音响2 / 3.....)	

CN

按键控制



⁘	短按	蓝牙连接/断开
	双击	TWS连接/断开
⁘	长按3秒	清除设备配对记录
—	短按	降低音量
	长按	上一曲
▷	短按	播放/暂停/接听电话/结束电话
	长按	拒接电话
+	短按	调高音量
	长按	下一曲
⏻	短按	蓝牙广播连接/断开
	短按	切换模式
⏻	长按2秒	开/关机

CN

复位

在开机的情况下，长按 6 秒 " ⏻ " 键至音响重新开机，即可复位音响。



注意

1. 不建议未经许可私下更换电池。
2. 电池 (电池组或电池组合) 不得暴露在诸如日照、火烤或类似过热环境中。



CN



CN

Model: BS12317

BUGANi

BUGANi Rove Go 5




USER MANUAL

SLEEK, MIGHTY, ON-THE-GO

EN


PRODUCT OVERVIEW



1. Indicator light
2. Bluetooth
3. Volume Down / Previous Song
4. Play/Pause
5. Volume Up / Next Song
6. Bluetooth Broadcast
7. Power On/Off
8. TF Card
9. USB-C

EN

CHARGING



Red indicator light stays on	Charging
Red indicator light off	Fully charged

Don't plug the cable in when your speaker and the charging port are not completely dry. Leave your speaker in a dry area with some airflow to let the port air dry naturally.

EN

POWER ON / OFF



Hold down the power button for 2 seconds to power on.
Hold down the power button again for 2 seconds to power off.

	Press for two seconds	Power on
	White lights up	
	Press for two seconds	Power off
	White lights off	

This speaker will power off automatically after 15 minutes if no device is connected.

EN

BLUETOOTH CONNECTION

• When first used and turned on, the speaker will automatically enter a pairing mode for connection.
• If the Bluetooth device is already connected, press " ⏻ " button to disconnect the current connection and connect with other devices.
• The speaker will automatically enter pairing mode if it is not connected to a Bluetooth device.
When pairing, enable the Bluetooth function of the phone and search for " **BUGANi Rove Go 5** " to connect. When the connection is successful, you will hear a prompt tone and the Bluetooth indicator will turn from blinking to long on.



Press for two seconds	Automatically enter Bluetooth pairing mode after boot
White light flashing	Bluetooth pairing
White light keeps on	Bluetooth connected

Description: ○ Indicator light on
● Indicate that the light is off
✹ Indicate that the light is flashing

EN

MUSIC CONTROL

Short Press the " ▷ " button to play or pause music.
Long press the " ▷ " button to go to the next song.
Long press the " ◁ " button to go to the previous song.

VOLUME CONTROL

Short press the " + " button to turn up the volume.
Short press the " - " button to turn down the volume.

CALL MODE

Answer a call: Short press the " ▷ " button.
Reject a call: Long press the " ▷ " button.
End the call: Short press the " ▷ " button.

VOICE ASSISTANT

When Bluetooth is connected, double-click the " ▷ " button to enable/disable the voice assistant.

EN

TF CARD

Plug a TF card storage device that contains playable audio contents into the TF card port of the speaker.
• The speaker switches to the TF card source automatically.
• Audio playback will start automatically.



TWS (TRUE WIRELESS STEREO) MODE

You can connect two of the same Brief Pro models together in TWS Mode.
1. Make sure the speakers are not connected to the mobile phone.
2. Double-click the " ⏻ " button on any speaker. The speakers are automatically paired. After pairing, the main speaker Bluetooth indicator will blink, and the secondary speaker Bluetooth indicator will turn long on.
3. Enable the Bluetooth function on the phone, search for " **BUGANi Rove Go 5** " to connect. After the successful connection, you will hear a prompt tone and the main speaker Bluetooth indicator light will become solid. Also, the Bluetooth indicator light on the secondary speaker will remain solid.
4. Exit TWS mode: Double-click the " ⏻ " button on the main speaker, and the speaker will automatically exit TWS mode.

EN



White light flashing	TWS pairing
White light flashing (speaker 1)	TWS connected
White light keeps on (speaker 2)	

EN

BLUETOOTH BROADCAST MODE

Set one " **Rove Go 5** " as the main speaker, and you can connect it to more than 100 auxiliary " **Rove Go 5** " speakers to control their functions.
1.First, connect one of the " **Rove Go 5** " speakers to your Bluetooth device (such as a mobile phone) as the main speaker and play music.
2.Press the " ⏻ " button twice on the main speaker and other " **Rove Go 5** " speakers to enter Bluetooth broadcast connection mode and connect automatically.
3.After successful connection, the green LED indicator on the main speaker will continue to flash, and the green LED indicator on the auxiliary speaker will change from flashing to long light.

After successfully entering Bluetooth broadcast mode
• You can turn off all speakers, adjust the volume, etc. by controlling the main speaker.
• You can turn off the power of each auxiliary speaker separately.
• To exit Bluetooth broadcast mode, press the " ⏻ " button on any speaker twice.



Green light flashing	Bluetooth broadcast mode
Green light flashing (speaker 1)	
Green light keeps on (speaker 2/3.....)	Bluetooth broadcast connected

EN

BUTTON CONTROLS



⁘	Short press	Bluetooth connection/Disconnect
	Double click	TWS connection/Disconnect
⁘	Press and hold for 5 seconds	Clear Bluetooth pairing list
—	Short press	Volume down
	Long press	Previous song
▷	Short press	Play/Pause/Answer a call/ End the call
	Long press	Reject a call
	Double click	Enable/disable the voice assistant
+	Short press	Volume up
	Long press	Next song
⏻	Short press	Bluetooth broadcast connection /Disconnect
	Short press	Switch between sound card and Bluetooth modes
⏻	Press and hold for 2 seconds	Turn On/Off

EN

RESET

When the speaker is turned on, press and hold the " ⏻ " button for 6 seconds.



Caution

•It is not recommended to replace the battery privately.
•The battery (battery pack or battery pack combination) must not be exposed to sunshine, fire or similar overheated environments.



EN

BUGANI LIMITED WARRANTY

BUGANI Corporation ("BUGANI") warrants your product against defects in materials and workmanship when purchased directly from BUGANI or a BUGANI authorized reseller. This warranty is extended only to the original end-use purchaser or the person receiving the product as a gift and shall not be extended to any other person or transferee. The warranty is valid from the date of retail purchase for a period of 1 year. BUGANI will provide the Warranty Services in accordance with the relevant laws and regulations of local government.
This warranty does not cover defects or damage arising from improper use or maintenance, normal wear and tear, commercial use, accident or external causes. Unauthorized repairs, modifications or customization of your product voids this warranty.
For warranty service on covered defects during the warranty period, contact BUGANI using the contact information at worldwide. Prior to providing warranty service, BUGANI may require you to provide proof of purchase details, including but not limited to a receipt or sales invoice.
For more information, please visit www.bugani-global.com

Please contact: care@bugani-global.com

EN

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off
and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
This device has been tested to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
FCC ID: 2BYAR-BS12317

EN