


版本	描述	设计	内容审核	日期	单位 ▶ mm	项目名 ▶	IGRS闪联 深圳市闪联信息技术有限公司 IGRS Engineering Lab(Shenzhen)Ltd.
V1.0.1		Liliang					
					比例 ▶ 1:1	文件名 ▶	
规格要求	尺寸：340×100mm±5 折叠后尺寸：85×100mm ±5 材质：80g铜板纸 双面印刷风琴页 英文：微软雅黑 ● CMYK:0/0/0/80	折后底页 折后首页					



First-Time Setup

- Before you begin, make sure your computer or phone is on the same local network as AgentBox P1.
- Open a browser and go to: <http://agentbox.local>

Step 1:Network
Select your Wi-Fi network or connect with an Ethernet cable to your Internet AgentBox P1

Step 2: AI Model
Configure your AI model — choose between local models or cloud-based providers (API key required).

Step 3:Skills
Select the skills you want to install. You can skip this and install skills later.

Step 4: Messaging Channels
Connect your preferred messaging platforms (e.g., Telegram, WhatsApp, Discord) to interact with AgentBox P1.

Step 5: Health Check
The system runs a self-check. Once passed, your AgentBox P1 is ready to use.

Daily Use

Access <http://agentbox.local> anytime to:

- Modify configuration
- Monitor system status
- Install or manage skills
- View logs and activity

Tips

- Keep AgentBox P1 connected to power and network for 24/7 availability.
- For best performance, use a wired Ethernet connection.
- Update skills and firmware regularly via the web dashboard.

FCC ID: 28WLB-P1 (prefix must be capitalized "FCC ID").
FCC regulations stipulate that the height of the logo must not be less than 0.35 inches (approximately 8.9 millimeters)

FC

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

IC Statement

This device complies with Innovation, Science and Economic Development Canada's licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

French:"Le présent appareil est conforme aux CNR d'innovation, sciences et développement @conomiqueCanada applicables aux appareils radio exempts de licence exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement."

IC Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

折线

折线

折线