

Hurtle

USER MANUAL

HUTBB19RD - HUTBB19YL - HUTBB19PK

Toddler Balance Bike

Visit Our Website



SCAN ME
hurtleusa.com



Read all instructions carefully before using this product.
Retain this owner's manual for future reference.

Features

- Designed for ages 18–36 months to promote fun, simple, and engaging playtime
- Light-up handlebars with motion detection (batteries not included)
- Pedal-free design with fully enclosed, wide wheels for added safety
- 135° steering limit to prevent tipping and ensure stable turning
- Smooth, rounded edges with no sharp parts for safe play
- Lightweight, shock-absorbing wheels for a smooth, stable ride
- Feet stay on the ground for easy control of speed and stops
- Strong PP + EVA frame built for durability
- Non-slip handlebars and cushioned seat for comfort and grip
- Scratch-resistant, wear-resistant wheels safe for indoor floors
- Easy for toddlers to ride independently and lightweight for parents to carry
- Suitable for indoor floors or smooth outdoor pavement
- Supports up to 55 lbs.
- Helps toddlers develop balance, coordination, and motor skills

What's in the Box

- Toddler Balance Bike
- Allen Key

Technical Specs

- Construction Materials: PP + EVA
- Handlebar Material: PP
- Wheel Material: EVA
- Seat Material: EVA
- Age Recommendation: 18 to 36 Months Old
- Maximum Weight Capacity: 55 lbs.
- Safety Features: Smooth Edges, Shock-absorbing Wheels, 135° Steering Limit
- Battery-Operated Light-Up Handlebars: Requires 2 x 'AAA' Batteries, Not Included
- Wheel Diameter: 6 Inches
- Seat Height: 9.5 Inches
- Wheelbase (distance between front & rear wheels): 14.17 Inches
- Handlebar Width: 9.65 Inches
- Handlebar Height: 14.57 Inches
- Handlebar Diameter: 1.2 Inches
- Steering Limit: 135°
- Assembly Required: Yes
- Assembly Time: Approx. 3 minutes
- Item Weight: 3.86 lbs.
- Product Dimensions (L x W x H): 19.7 x 9.6 x 14.2 Inches

California Prop 65 Warning



WARNING:

This product may expose you to chemicals, which is known to the state of California to cause cancer, birth defects and other reproductive harm. Do not ingest.


For more info go to: www.P65warnings.ca.gov

WARNINGS

1. This bike is designed for children ages 1 to 5 years and weighing up to 55 lb (25 kg).
Warning: Do not use if the child is over 60 months (5 years) or exceeds the maximum weight limit.
2. This bike is designed for one person only.
3. Children using the bike should always be under adult supervision.
4. Keep plastic packaging away from children as it poses a risk of suffocation.
5. The bike should be assembled, disassembled, and adjusted only by an adult and away from children.
6. Protective equipment (helmet, pads) should be worn while using the product.
7. The product should be used with caution. Skills enabling the user to avoid falls or collisions that may cause injury to the user or others are necessary.
8. The safest areas for riding the bike are places with limited or no traffic, such as private recreational areas, playgrounds, and schoolyards.
9. Do not use the bike near traffic.
10. Do not use the bike on sloping or uneven surfaces.
11. Do not use the bike near potentially dangerous places (e.g., swimming pools).
12. The product should not be used during unfavorable weather conditions (e.g., frost, rain, snow, ice).
13. Do not allow a child to stand on the seat or handlebars.
14. A child using the bike should wear shoes. The product does not have brakes, so caution should be exercised when using it.
15. Before each use, check for damage, loose connections, or missing parts. Do not use the product if any components are missing or damaged. In such a case, contact an authorized manufacturer's service center.
16. Do not tow the bike behind a car or any other vehicle.
17. Keep the product away from heat sources, high temperatures, hot surfaces, sparks, open flames, oil, and sharp edges.
18. Store the bike in a dry place.




PARTS LIST

1. Handlebar
2. Battery compartment
3. Disassembly hole
4. Saddle
5. Body
6. Front fork of the bike
7. Front wheels
8. Rear wheels





BATTERY INSTALLATION

1. Use a screwdriver to unscrew the battery cover screw and remove the battery cover (Fig. 1).
2. Insert two AAA 1.5 V batteries, paying special attention to the correct polarity (Fig. 2).
3. Replace the cover and tighten the screw using a screwdriver (Fig. 3).



ASSEMBLY

4. Attach the body to the front fork of the bike (Fig. 4), then insert the handlebar into the appropriate hole (Fig. 5).
5. Make sure the handlebar is inserted correctly and locked in place to prevent it from being pulled out. Ensure the wheels are facing forward.



USAGE

- Sit on the saddle, grip both handlebars firmly, and push off alternately with your feet.
- After gaining momentum, lift your feet to ride freely.
- To turn, twist the handlebar in the desired direction while balancing your body.
- To brake, touch the ground with your feet.

DISASSEMBLY




Using a thin, elongated object (such as a pencil), press the release button (Fig. 6), then pull the handlebar up and the front fork of the bike down (Fig. 7).

LIGHT EFFECT

The handlebar light effect is available after installing the batteries in the battery compartment (Part 2, Fig. A). The effect is activated by touching the product.

LIGHT MODE

After the batteries are installed, the handlebars can be tapped to light up.
Leave the product for a moment, and the lights will turn off automatically (Fig. 8).



BATTERY WARNINGS

1. Disposable batteries not designed for charging must not be charged.
2. Do not insert different types of batteries or mix new and used batteries.
3. Insert batteries with the correct polarity.
4. Remove exhausted batteries from the toy.
5. Do not short-circuit the power terminals.
6. If the product is not used for an extended period, remove the batteries from the compartment.

CLEANING AND MAINTENANCE

- Clean the product regularly to remove dirt or debris that may accumulate during use.
- Use a damp cloth and mild cleaning agents to clean the bike.
- Do not use abrasive or harsh cleaning agents.
- Wipe the product dry before the next use.



HUTBB19RD



HUTBB19YL



HUTBB19PK

Pictures are for illustrative purposes only.

The actual appearance of the product may differ from what is shown.

Register Product

Thank you for choosing PyleUSA. By registering your product, you ensure that you receive the full benefits of our exclusive warranty and personalized customer support. Complete the form to access expert support and to keep your PyleUSA purchase in perfect condition.

Start Here



PyleUSA.com/pages/register

Hurtle

Find your fast



Questions? Comments?

We are here to help!

Phone: (1) 718-535-1800

PyleUSA.com/ContactUs