


NB: Use key only for initial set up or changing batteries

GB Installing the batteries

ES Instalación de las pilas


FR Installer les batteries



GB Set / re-set your user code

ES Inserte / re-inserte su código de usuario

FR Définir / redéfinir votre code d'utilisateur





-BEEP-
-BEEP-
-BEEP-
✓
- ARMED -

GB Activating the alarm tamper function

ES Activación de la alarma por manipulación

FR Activer la fonction autoprotection d'alarme




✓
- DISARMED -

GB De-activating the alarm tamper function

ES Desactivación de la alarma por manipulación


FR Désactiver la fonction d'autoprotection d'alarme



GB Closing the door

ES Cierre de la puerta


FR Fermeture de la porte



GB Opening the door

ES Apertura de la puerta


FR Ouverture de la porte



GB Low battery warning

ES Aviso de batería baja

FR Notifications du niveau de la batterie



GB Fitting Guide

ES Guía de Instalación

FR Guide d'installation