


JUGUETE ACUÁTICO ELÉCTRICO ELECTRIC WATER TOY



USER MANUAL

KEY FEATURES



1. Press the trigger button to spray water.
 2. Insert the muzzle into the water and push the water pumping button forward to automatically pump water. When the storage tank is full, it will eject water and stop pump.
 3. Excess water is discharged and can be sprayed normally after.
 4. Do not soak the water gun in water!
-
1. Presione el botón del gatillo para rociar agua.
 2. Introduzca la boquilla en el agua y empuje hacia adelante el botón de bombeo para bombear agua automáticamente. Cuando el tanque de almacenamiento esté lleno, expulsará el agua y detendrá la bomba.
 3. El exceso de agua se descarga y, posteriormente, se puede pulverizar con normalidad.
 4. ¡No sumerja la pistola de agua en agua!

BATTERY USAGE



PRECAUTIONS

Battery Use Precautions:

1. The water toy uses 1 3.7V rechargeable battery pack.
2. The battery should be taken out and loaded in accordance with the polarity and voltage marks on the battery compartment, to prevent a short circuit.
3. Only use the recommended battery.
4. Do not leave the battery in the water toy if not being used for a long time, or the battery is dead.
5. Rechargeable batteries should be charged under adult supervision.
6. Do not connect to more than the recommended amount of power supply.
7. Check the battery charger, wires, plugs, and other parts regularly. If damaged, don't use until it's repaired.

Precauciones para el uso de la batería:

1. El juguete acuático utiliza un paquete de baterías recargables de 3.7 V.
2. La batería debe extraerse e insertarse de acuerdo con las marcas de polaridad y voltaje del compartimento de la batería, para evitar un cortocircuito.
3. Utilice únicamente la batería recomendada.
4. No deje la batería en el juguete acuático si no se va a utilizar durante un periodo prolongado o si la batería está agotada.
5. Las baterías recargables deben cargarse bajo la supervisión de un adulto.
6. No conecte una fuente de alimentación superior a la cantidad recomendada.
7. Revise regularmente el cargador de batería, los cables, los enchufes y otras piezas. Si están dañados, no los utilice hasta que hayan sido reparados.