




EB-W05B/EB-W05W TWS Wireless Bluetooth Earphones  User Manual ※Please scan the code for the Electronic Product Manual	Specifications Product Name: TWS Wireless Bluetooth Earphones Bluetooth version: 6.0 Color: Black/White Bluetooth effective distance: ≤ 8 meters (straight-line distance) Battery: Earphone battery: 3.7V 28mAh; Charging compartment lithium battery: 350mAh Charging time: About 2 hours Music duration: approximately 4.5 hours (80% volume) Talk time: approximately 2.5 hours (80% volume) Headphone standby time: approximately 28H 	Product Usage (1) LED indicator status  • Headphones on: No light effect • Left/right interconnection: No lighting effect • Earphone charging: Earphones have no light effect, the white light on the high battery compartment stays on, and the orange light on the low battery compartment stays on • Headphones fully charged:The compartment indicator light goes out • Charging compartment charging: orange light flashing • Warehouse fully charged: Orange light on continuously	(2) Functional Operations • Power on: Open the compartment cover and start automatically • Power off : The earphones will shut down after being placed in the compartment and covered (automatically shuts down after 3 minutes without connection) • Connect phone: After turning on the earphones, connect the corresponding device name: EB-W05B/EB-W05W • Restore factory settings: When the earphones are not connected to the phone, quickly press any earphone Touch key 5 times to successfully shut down the earphones .(clearing the connection record between the earphones and the phone, as well as the TWS teaming record of the left and right earphones)
 • Play/pause music: Click any Touch key • Previous song: Triple-click any touch key while music is playing • Next track: Double click any Touch key while music is playing • Answering phone calls: Click on any headphone Touch button • Hanging up the phone: Double click any headphone Touch button • Reject call: Long press and hold the Touch button on any earphone for 2 seconds • Open Siri: Long press and hold for 2 seconds on any headphone Touch button • Cancel Siri: Press and hold the Touch button on any earphone for 2 seconds after start up	(3) Reminder sound • Power on: Power on • Shut down: Power off • Connect Bluetooth: Deng Piano Sound • Disconnect Bluetooth: Dudu Equipment adaptation ① Mobile phones ② Computers ③ Laptops ④ Tablets ⑤ Other devices that support Bluetooth headphone connections	Safety Precautions 1. Do not use abrasive cleaning agents to clean this product. 2. Do not allow this product to be heated or placed near a fire source, such as a cooking stove. 3. Do not expose this product to direct sunlight for extended periods of time. 4. Do not dispose of this product in fire to avoid explosion. 5. Do not attempt to disassemble this product for any modifications, as it does not contain any repair components. 6. Do not use this product in the rain. 7.If you do not plan to use this product for a long time, please store it in a dry environment and charge the headphones at least once a month to extend their lifespan, avoiding extreme temperatures and dust.	Troubleshooting If the operation is incorrect, please follow these steps: 1. Check the integrity of Bluetooth earphone products; 2. Check the connection between the Bluetooth earphones and the device; 3. Check your device settings; 4. Disconnect and reconnect the device; Restart the connection. If the problem persists, please contact the seller.  Learn more about this and other products on www.eseekgo.com

FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.