105mm

315mm

GiDues

JUPITER 67

Unlock Your Universe

TRI-MODE CONNECTION

USB • 2.4GHz • Bluetooth

CONNECTION MODES

USB WIRED MODE

1. Switch the side switch to OFF.
2. Connect the keyboard using the USB cable.

2.4GHz WIRELESS

1. Switch the side switch to 2.4G.
2. Insert the 2.4GHz wireless receiver.

BLUETOOTH MODE

1. Switch the side switch to BT.
2. Short press Fn + Q/W/E to select a Bluetooth devices.
3. Press and hold Fn + Q/W/E for 3 seconds to enter pairing mode.

COMPATIBLE WITH Windows macOS Android Linux

PACKAGE CONTENTS

- Keyboard ×1
- USB-C Cable ×1
- 2.4GHz Wireless Receiver ×1
- User Manual ×1

PRODUCT SPECIFICATIONS

Model: KG18

Layout: 67 Keys + Rotary Knob

Connection: USB / 2.4GHz / Bluetooth

Keycap: ABS Double-shot Side Printed Keycaps

Great value. Innovation. Dependability. simple to USE.

JOIN #MYGIDUES

SHARE YOUR EXPERIENCE ON SOCIAL MEDIA

Gidues Gidues1 Gidues Gidues Gidues

SAFETY INFORMATION

⚠ Safety Instructions:
- Keep the keyboard away from water and moisture.
- Do not disassemble the product.
- Do not expose the battery to fire or extreme temperatures.
- Stop using the product if the battery is damaged.
- Do not use damaged charging cables.
- Keep away from children under 3 years old.

Battery Disposal:
Dispose of batteries according to local regulations.

Download the VIA JSON file from our official website to customize your keyboard.

www.gidues.com

COMPLIANCE & SUPPORT

FCC Statement:
This device complies with Part 15 of the FCC Rules.
Operation is subject to:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

Environmental Compliance:
- RoHS compliant
- Follow local recycling regulations

Wireless Specifications
Bluetooth Frequency Range: 2402-2480MHz
2.4 GHz Wireless Frequency Range: 2404-2476MHz
Maximum RF Output Power: 0.83dBi

Customer Support:
We provide after-sales support for this product.If you need assistance, feel free to contact us:
✉ Email: support@gidues.com
🌐 Website: www.gidues.com

210mm

KEY FUNCTIONS

		Windows	Mac
Fn+Esc	~`	Fn+L_Shift	Brightness -
Fn+L_Win	WINLOCK indicator on, locks the WIN key (WIN lock unavailable on Mac)	Fn+Z	Brightness +
Fn+ |	Switch between 16 backlight effects	Fn+X	Mission Control
Fn+Space Key	Keyboard Backlight On/Off	Fn+C	Keyboard Backlight Brightness -
Fn + ↑	Increase Backlight Brightness	Fn+V	Keyboard Backlight Brightness +
Fn + ↓	Decrease Backlight Brightness	Fn+B	Previous Track
Fn + ←	Decrease Backlight Speed	Fn+N	Play/Pause
Fn + →	Increase Backlight Speed	Fn+M	Next Track
Fn+TAB (Hold for 3 seconds)	Restore Factory Settings	Fn+< ,	Mute
		Fn+> .	Volume -
		Fn+? /	Volume +

	Windows	Mac
Fn + 1	F1	F1
Fn + 2	F2	F2
Fn + 3	F3	F3
Fn + 4	F4	F4
Fn + 5	F5	F5
Fn + 6	F6	F6
Fn + 7	F7	F7
Fn + 8	F8	F8
Fn + 9	F9	F9
Fn + 0	F10	F10
Fn + -_	F11	F11
Fn + =+	F12	F12



Fn + Q/W/E

Fn+Q/W/E: Switch between Bluetooth devices 1/2/3.
Bluetooth names: Gidues Jupiter - 1/2/3.
Short press to switch Bluetooth devices 1/2/3.
Long press for 3 seconds to enter pairing mode.
The key indicator flashes when disconnected and stops flashing after connection.
(Note: The side switch must be set to BT mode to freely switch between the three Bluetooth devices.)

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.