



公司生产的智能数码产品,我们随机配备了内容详细
您从中可以获得产品的使用介绍等,在您开始使用本
本阅读说明书,以便您能准确地使用本产品。

数据线 ×1

说明书 ×1

收藏卡 ×1

长按3秒开/关机,按键透光开机成功,熄灭设备关机;连续可进入配网状态。

位于头部和下巴处,轻触可触发随机语音互动。

配网成功后该设备可进入配网状态。

若需要重新配网,长按3秒开/关机,按键透光开机成功,熄灭设备关机;连续可进入配网状态。

位于头部和下巴处,轻触可触发随机语音互动。

进入重置状态。

智能语音交互
支持自然对话与多语言交流

常用

需要什么帮助?

又见面了, 欢迎和我聊天~

AI 安全守护

添加设备

创建场景

添加常用卡片

扫一扫

设备收藏

多模态 AI 智能集成



(4)选择手机已连接的WiFi进行配对

已联网，让我们开始对话吧”
态下，连续点击开关键3次，听到提示音后
网。

成长系统,可记忆用户偏好、
同、讲段子、情绪安慰等功能,
完成词汇、短句基础学习,将
乐的早教效果。

近头部或下巴部1厘米内时，

、Gemini、ChatGPT 等)。

/ 生气等多维度情绪。

卖留存长期交互信息,形成连

情,设备可根据实时对话内容
状态,提升拟人化交互体验。

“摇晃”、“抚摸”可重新开启对

节：“你声音太大 / 小了”“音量调到 80%”
 询：“现在音量 / 电量是多少”
 音色切换：“换一种声音对话”“切换角色”

按：可以英语和我对话吗

按：“语速调到 50/80”

按：“退下”“闭嘴”“不想聊了”

按：“关闭 / 开启屏幕”“睁开 / 闭上眼睛”

按：“给我讲个故事”“放首歌”“暂停 / 停止播放”

按：“我今天好伤心 / 生气 / 开心”

管理
音量调节、电量查看、聊天记录浏览等基础操作。

系统	1. 为确保
切换：可一键切换老友、老师、心理医生等不同 AI 角色，快	2. 证的正
同陪伴场景。	2. 满电
色创建：支持设置角色头像、名称、智能体设定与专属知识	2. 充满电
高度个性化的 AI 伙伴。	3. 充电

功能

(部分场景需付费开通):支持录入个人声音或上传音频文件,生成专属语音,让 AI 伙伴以你的声音与你互动。

(需付费开通):开通服务并绑定网易云音乐平台会员账号,通过语音指令播放试听片段或会员曲库内的完整内容。

醒词悠米悠米/YumiYumi, 唤醒设备听到“呜哇”以后, 进行 于阴凉干

进入睡眠模式需要“摇晃”或者“抚摸”遥控器。此时需要单击背部的按键进行唤醒。

在编辑页面右上角点击设置菜单键，下滑至最下方	产品尺寸
内容后点击更新，更新时长 3~10 分钟，过程中请勿	产品重量
后设备提示“已是最新版本”。	

[illegible]

钟, 充电过程中接口右侧亮红灯, 充满灯灭。(180分 于设备实验室数据, 可能因多种因素而略有不同。) 及时拔掉电源, 避免长时间过度充电影响电池寿命,	最大功
	电池种

未使用或电池电量耗尽,再次充电时可能无法立即充电。外出或长时间离开时断开电源。	电池容量
充电一段时间后再开机使用。	电池电量
超过8小时,充电时须确保有人在场,外出或长时间未使用,充电时须断开电源。	产地

AI 毛绒公仔挂件

SCPF-PURPLE001

工测量存在 $\sim 3\text{mm}$ 误差,以实物为准)	4.请勿将电池置于低气 发可燃气体泄漏。
约133g	5.切勿在开机或充电过
	6.切勿使用盐水、热水、

14岁及以上	体(例如:汽油或丙酮)清
--------	--------------

3W	9.请务必定期检查本产品,否则有漏电、短路或
锂电池	清洗办法

1000mAh	1.本产品不防水,切勿 强酸碱等腐蚀性液体。 2.请先关机再进行清洁 柔擦拭表面;清洁完毕
3.7V	
中国 东莞	

身清洁。

防爆炸。

请勿在浴缸或浴室附近使用充电器为本产品充电。

请勿在0°C范围内使用本设备，请勿将本产品置于0°C以下的环境中。

4. 产品的售后服务条款
service@mobuddy.ai。

为婴幼儿接触引发窒息意外。

当拆卸时使用，切勿在开机或充电过程中

见充电或充电线异常，请立即停止使用的风险。

1.超过保修期的期限。

2.人为原因造成的损坏如物理

3.未经产品授权的人员私自拆

4.不可抗拒因素造成的损坏。

5.转售您的产品。

8.其他保外条款请参考售后保

用蘸有自来水的软布，完全拧干后轻用干纸巾轻轻压干多余水分，待自然口、缝隙。

放回原包装。

人，请用柔软的干布轻轻擦拭，保持机

电池特别说明

1. 内置3.7V的电池，不可拆卸及
2. 充电器由成人或在成人监护下
3. 定期检查充电器的电线、插头
4. 损坏时应停止使用，直至修复完好
5. 产品清洁时需关机并与充电器

免责声明

售后服务中心检测确认后,为感谢您购买芯萌智能科技有限公司(以下简称芯萌)产品,偶,本文所提及的相关内容关系到您的安全。一旦使用本产品,即视为您已经仔细阅读并理解、认可和接受本免责声明及安全指南全部内容。您同意在适当的环境中、以正当的目的正确使用本产品,芯萌及其经销商不承担任何可能带来的后果及全部责任。您同意

液等。

须知等内容存在冲突,以本免责声明、

情况下,公司均不应被认为是第三方内

作出任何声明或担保,或对第三方内

担任任何责任或义务。

产品。

导致的故障和损坏。

损坏应联系服务并进行维修。

用户信息	
姓名：	
联系地址：	
联系电话：	
Email：	

第三方的相关政策、规定与本免责声明、安全提示等内容为准。在任何情况下，不就第三方内容的任何内容或功能承担任何责任。	S/N:	
	购买地:	
	购买时间:	
	备注:	




Foreword

Thank you for choosing our smart digital product. We have included a detailed user manual to help you learn about the product's functions and usage. Please read this manual carefully before operating the device to ensure correct and safe use.

Product List



Product Description




Power Button: Press and hold for 3 seconds to power on, indicator lights up when powered on and turns green. Quickly short-press the button three times


consecutively to enter Wi-Fi pairing mode.
Touch Sensor Area: Touch sensors are located on the head and chin. Light taps will trigger random voice interactions.

Network Connection

Please ensure your phone is connected to a 2.4GHz band WiFi. After powering on the device, short press the power key three times consecutively to enter network configuration mode, then follow the steps below to log in or register an account.



(1) Scan the QR code or search for the "Tuya" app in the app store to download it.



(2) Open the app and tap the "+" icon in the top-right corner to add a device.



(3) Select your device from the list.

Power & Pair Key: Press and hold for 3 seconds to power on/off; short-press three times consecutively to enter network pairing mode.
Sensor Area: Yellow touch pads are located on the head and chin, which will respond to user's touches and movements.

Basic Functions

Intelligent Voice Interaction
Supports natural conversation and multilingual communication. Built-in dynamic growth system that remembers user preferences to develop a unique personality. It also features fun Q&A, emotional venting, joke-telling and mood soothing, delivering companionship, stress relief and interactive fun.
Multilingual Learning Assistance
Processes real-time translation for over 60 languages. It guides children to learn basic vocabulary and short sentences by combining language cognition with playful interaction for entertaining early education.

Touch-Sensing Function
The touch sensor activates automatically after the device powers on. When your hand approaches within 1 centimeter of the head or chin area, the touch trigger will activate and play a random preset audio clip.
Note: The touch function will not respond during voice conversation.

Integrated Multi-Model AI
Compatible with domestic and international large language models, including Doubao, Qianwen, DeepSeek, Gemini, ChatGPT, etc.

Emotion Recognition
Detects multi-dimensional user emotions such as joy, sadness and anger through every conversation.
Character Memory
Functions including conversation summarization and formatted

memory enable the device to retain long-term interaction records, building consistent, personalized chat memory.

battery level check and chat history viewing.

Character Management System
Preset Character Switching
One-click switch between various AI roles such as old friend, teacher and psychological counselor to quickly match different companion scenarios.
Custom Character Creation
Allows configuration of character avatar, name, agent settings and exclusive knowledge base to build highly personalized AI companions.

Value-Added Services

Voice Cloning (Paid service for certain scenarios)
You can record your voice or upload audio files to generate exclusive timbre, enabling the AI companion to interact with you using your voice.
Music Playback (Paid service required)
After activating the service and binding member accounts of mainstream platforms such as NetEase Cloud Music and QQ Music, you can play preview clips or full tracks from the member library via voice commands.

Sleep & Wake-up

1. Wake up the device by saying the wake word "YumiYumi". After you hear the response "Wooah", you may start a conversation.
2. Once the device connects to the network, free conversation mode is activated. You can interrupt it anytime to start a new topic. Tap the rear button to mute with one click; tap it again, shake the plush or touch its sensor to resume conversation.
3. The device enters sleep mode after 1 minute of inactivity. Wake it up by shaking or touching it.
4. The screen turns off after 6 minutes of inactivity. At this point, tap the rear button to wake the device.

APP Functions

Basic Device Management
Supports basic operations including device volume adjustment,

battery level check and chat history viewing.

Character Management System
Preset Character Switching
One-click switch between various AI roles such as old friend, teacher and psychological counselor to quickly match different companion scenarios.
Custom Character Creation
Allows configuration of character avatar, name, agent settings and exclusive knowledge base to build highly personalized AI companions.

Charging Instructions

1. For safety, only charge with a nationally certified 5V 1A charger (charger not included).
2. Full charging takes about 180 minutes. A red indicator next to the port lights up while charging and turns off once fully charged. The 180-minute charging time is based on lab test data and may vary due to different conditions.
3. Unplug the power promptly after full charge to prevent overcharging that shortens battery life. Do not leave it unattended while charging; disconnect power before going out or leaving for long periods.
4. If the battery is drained or left unused for a long time, the device may not power on immediately when charging. Keep charging for a while before turning it on.
5. Do not charge continuously for over 8 hours. Never charge unattended; stop charging before you go out or stay away long.

Storage Precautions
Do not use, store, or charge the device in direct sunlight, near heat sources, or in high-temperature environments. Store in a cool, dry place.

Basic Device Management
Supports basic operations including device volume adjustment,

battery level check and chat history viewing.

Character Management System
Preset Character Switching
One-click switch between various AI roles such as old friend, teacher and psychological counselor to quickly match different companion scenarios.
Custom Character Creation
Allows configuration of character avatar, name, agent settings and exclusive knowledge base to build highly personalized AI companions.

Charging Instructions

1. For safety, only charge with a nationally certified 5V 1A charger (charger not included).
2. Full charging takes about 180 minutes. A red indicator next to the port lights up while charging and turns off once fully charged. The 180-minute charging time is based on lab test data and may vary due to different conditions.
3. Unplug the power promptly after full charge to prevent overcharging that shortens battery life. Do not leave it unattended while charging; disconnect power before going out or leaving for long periods.
4. If the battery is drained or left unused for a long time, the device may not power on immediately when charging. Keep charging for a while before turning it on.
5. Do not charge continuously for over 8 hours. Never charge unattended; stop charging before you go out or stay away long.

Storage Precautions
Do not use, store, or charge the device in direct sunlight, near heat sources, or in high-temperature environments. Store in a cool, dry place.

Basic Device Management
Supports basic operations including device volume adjustment,

battery level check and chat history viewing.

Character Management System
Preset Character Switching
One-click switch between various AI roles such as old friend, teacher and psychological counselor to quickly match different companion scenarios.
Custom Character Creation
Allows configuration of character avatar, name, agent settings and exclusive knowledge base to build highly personalized AI companions.

Charging Instructions

1. For safety, only charge with a nationally certified 5V 1A charger (charger not included).
2. Full charging takes about 180 minutes. A red indicator next to the port lights up while charging and turns off once fully charged. The 180-minute charging time is based on lab test data and may vary due to different conditions.
3. Unplug the power promptly after full charge to prevent overcharging that shortens battery life. Do not leave it unattended while charging; disconnect power before going out or leaving for long periods.
4. If the battery is drained or left unused for a long time, the device may not power on immediately when charging. Keep charging for a while before turning it on.
5. Do not charge continuously for over 8 hours. Never charge unattended; stop charging before you go out or stay away long.

Storage Precautions
Do not use, store, or charge the device in direct sunlight, near heat sources, or in high-temperature environments. Store in a cool, dry place.

Basic Device Management
Supports basic operations including device volume adjustment,

completely, and gently wipe the surface. After cleaning, use a dry paper towel to gently press out excess moisture, and let it air dry naturally before use. Do not allow liquid to seep into the interfaces or gaps.
3.To protect the product, it is recommended to return it to its original packaging after use.
4.If there is dust or water splashes on the product surface, gently wipe it with a soft dry cloth to keep the body clean.
5.For stubborn stains, please contact official customer service for more cleaning guidelines.

Warranty Information

1.This product is manufactured under strict quality control. Within one year from the date of purchase and acceptance, free in-warranty repair services are provided by the after-sales service center for non-human-induced performance failures, upon verification and confirmation.
2>Returns/exchanges only at the point of purchase.
3.Please keep this warranty card safe and avoid smudging or altering it.
4.For the after-sales service terms of the product, please contact the official after-sales service of mobuddy at:service@mobuddy.ai.

Exclusions from Warranty Coverage

1.Expiry of the warranty period.
2.Damage caused by human factors, such as physical damage or liquid ingress.
3.Unauthorized disassembly or modification (including rooting/flash operations) by non-authorized personnel.
4.Damage caused by force majeure.
5.Resale of the product.
6.Use of the product in violation of any laws or our user agreement.

7.Malfunctions or damage resulting from issues unrelated to the product's inherent design, manufacturing, or quality.
8.For additional exclusions, refer to the official after-sales warranty policy.

Special Battery Notice

1.Built-in 3.7V battery (non-removable). Contact service if damaged.
2.The charger must be used by an adult or under adult supervision.
3.Regularly inspect the charger's cable, plug, casing, and other components. Stop use immediately if any damage is found, and do not resume use until repaired.
4.Power off the device and disconnect it from the charger before cleaning.
5.This product is sold without a power adapter. If using a power adapter, purchase a CCC-certified adapter that meets standard requirements for use with this device.

Special Notice

Thank you for purchasing the AI Talking Plush Toy from MOBUDDY Intelligent Technology Co., Ltd. (hereinafter referred to as "the Company"). The content herein relates to your safety, legitimate rights and responsibilities.
By using this product, you are deemed to have carefully read, understood, acknowledged and accepted all terms and content of this Disclaimer and Safety Guidelines. You undertake to use this product correctly in a proper environment and for legitimate purposes, and you assume full responsibility for any consequences arising from your use of the product. You agree to comply with these terms, including health and safety notices, as well as any relevant terms, policies and guidelines formulated by the Company. Otherwise, the Company shall not be liable for any

Product Information	
S/N (Serial Number):	
Place of Purchase:	
Date of Purchase:	
Remarks column:	

Warranty Card

User Information	
Email :	
User Name:	
Address:	
Phone Number :	

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.