

成品尺寸：85*111
展开尺寸：170*111

80g双胶纸+双面单黑+对折

Adjustable Headband

Hold headband and pull/push each earphone downwards/upwards to adjust size.

Care Tip: Periodically wipe clean with soft cloth. Never use abrasive cleaning agent or get wet.

WARNING! IMPORTANT CARE AND SAFEGUARDS

Failure to follow safety instructions can lead to fire, shock, personal injury or property damage and damage to product.

The product contains small parts and is not suitable for children

Do not use this device for anything other than its intended use

Device must be Bluetooth® enabled to connect wirelessly

Device must be compatible with 3.5mm AUX cable for wired connection

Individuals with pacemakers or medical implants should consult a physician before using this product

The headphones are not waterproof

Do not expose this product to rain, water or excessive humidity

Do not store this product next to heat sources or in direct sunlight

Do not handle headphones with wet hands

Extreme hot and/or cold weather may damage headphones

Always use this product in operating temperatures of 32°F(0°C) - 95°F(35°C)

Never take this device apart and always get repaired by a qualified technician

Do not use headphones if they have been damaged in any way

This product contains one or more internal batteries, please dispose responsibly

STOP

Charge with 5V / 1A USB power source (not included). Not compatible with USB-C PD fast charger. Charge completely prior to initial use.

Coleman

ALPINE AIR

WIRELESS HEADPHONES

CLBHP206 Instruction Manual

Please read carefully prior to use.

Adjustable Headband

USB Power Cord

+Volume Up/Next Track
-Volume Down/Previous Track
Power On/Off / Play /
Pause / Answer / End Call /
Voice Assistant

LED Indicator Light

Microphone

AUX Port
USB-C Port

*Approximate play/talk time depends on use and may be more or less than the time specified.

Charging Headphones

Connect USB cable to USB port on headphones and USB power source (not included).

LED indicator will light up red while charging and will turn off when complete.

Pair and Connect

Press and hold play/pause button for 3 seconds to turn headphones on and off.

LED light will flash red and blue in an alternating sequence while in pairing mode.

Open Bluetooth® menu on your smartphone and search for new devices.

Connect to **COLEMAN-CLBHP206**. An alert will sound indicating headphones are connected.

Headphones will reconnect to smartphone automatically after initial pairing. If auto-reconnect does not occur then repeat the steps above.

Play Music / Voice Calls

Use control buttons to play/pause music, answer/end calls, adjust volume and select track.

Short press play/pause to play/pause music and answer/end calls.

Short press + or - button to increase or decrease volume.

Press and hold + or - button to select next or last track.

Double press play/pause button to redial last call.

AUX Wired Connection

Connect 3.5mm audio cable (not included) to AUX port for wired connection and unlimited playback time.

Connect wirelessly with Bluetooth® or connect to AUX port for wired connection.

FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

M