

VAUNO 2053-3

Wireless Meat Thermometer

Quick Start User Manual



READY-TO-GO - 4 Simple Steps to Get Started

Monitor 2 Kinds of Meat under Your Control


Step 1

Press the **MODE** button to select Probe 1 or Probe 2




Step 2

Press the **MEAT** button to select Meat Type (8 Types - BEEF, LAMB, VEAL, etc.,)



Step 3

Press the **TASTE** button to select Taste Level (5 Taste Level from RARE to WELL)



Step 4

Press the **((•••)) / °C / °F** button to Turn on /off Alarm function

Measure meat temperature to set your **SPECIFIC TASTE**

Step 1

Press the **MODE** button to select Probe 1/2



Step 2

Press the **MEAT** button to select Meat Type – **PROGM**



Step 3

Press and Hold the **MODE** button until the temperature value blinks



Step 4

Press **UP** (increase) or **DOWN** (decrease) to set your desired temperature




Step 5

Press the **MODE** button to confirm the temperature setting.



Step 6

Press the **((•••)) / °C / °F** button to Turn on /off Alarm function



Monitor the High and Low Temp inside the Grill / Oven / Smoker



Step 1

Press the **MODE** button to select Probe 3



Step 2

Press and Hold the **MODE** button until the high temperature value blinks



Step 3

Press **UP** (increase) or **DOWN** (decrease) to set your desired high temperature



Step 4

Press the **MODE** button to confirm the high temperature setting.



Step 5

Press **UP** (increase) or **DOWN** (decrease) to set your desired low temperature




Step 6

Press the **MODE** button to confirm the low temperature setting.



Step 7

Press the **Speaker Icon / °C/°F** button to Turn on /off Alarm function




Count Down Timer

Step 1

Press the **UP** (Minute) / **DOWN** (Second) button to adjust time setting

Step 2

Press **ST/SP/CLEAR** button to start Count Down timer



Count UP Timer

Press **ST/SP/CLEAR** button to start Count UP timer

Stop Timer

- Press **ST/SP/CLEAR** button to stop the timer.

Clear the timer setting

- After stopping the timer, press and hold **ST/SP/CLEAR** button for 2 seconds to clear the timer setting.