


ROKU[®]


Select Series




What's included



Roku Select Series TV



TV power cord
included for 50" - 85"
models only



x 4 screws

Stand screws



TV stands




Roku TV Remote

What you need



Phillips head
screwdriver




Laptop or mobile
phone for activation



Internet connection

STEP 1: Set up your TV



A Prepare a surface

Put a soft covering like a blanket down onto a clean, flat surface (make sure it's larger than the TV) and place the TV on it.

B Attach the stands


Use a screwdriver and included screws to attach the stands.

C Set TV upright


Place your TV on a stable, flat surface.

Mounting your TV?

For instructions, skip these steps and visit go.roku.com/tvmount



STEP 2: Plug TV in and power your remote



A Connect your TV


Plug your TV into a power outlet. It should turn on automatically. If it doesn't, press the power button.



B Power your remote

See the remote features card on how to use your Roku TV remote.

STEP 3: Activate your TV



Connect your TV

Follow the instructions on your TV screen. Activate your TV by using your computer or smartphone to link a Roku account.



IMPORTANT

Roku never charges for activation support.

Frequently asked questions

Why do I need an internet connection?

You'll need an internet connection to set up your TV, stream your favorite channels and for automatic software updates.

Why should I enter a payment method?

Saving a payment method makes it easy to rent or buy movies, subscribe to popular channels, and start free trials in just a click. No charges will be made without your authorization.

Get to know your TV



HDMI - Game consoles, DVD players



Composite (available on some models) - Analog devices, older game consoles



Antenna/Cable - Digital antenna, cable connection

Audio connections



HDMI ARC or eARC (recommended) - AV receivers, soundbars



Optical (S/PDIF) - AV receivers, soundbars



Headphone Jack (available on some models) - Wired headphones

Other connections




USB - Flash drive for media playback



Ethernet (available on some models) - Wired internet connection

ROKU Remote features



Power your remote

Includes pre-installed batteries. Pull out the tab on the back of your remote. It will pair to your TV automatically.



Voice search & control

Quickly search across thousands of apps, play entertainment, control your streaming, and more with your voice.



Find your lost remote

Use the Roku mobile app or press the TV's power button to bring up the options menu.



Live TV in a click

Start watching free live TV and local news with just one press.



Save your faves

Personalize shortcuts to open any app, turn on closed captions, and more with the quick launch button.

ROKU

© 2026 Roku, Inc. All Rights Reserved. Roku, the Roku logo, and the purple d-pad and purple fabric tag designs are trademarks or registered trademarks of Roku, Inc.

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Confidential unpublished works. Copyright 1992-2019 Dolby Laboratories. All rights reserved.

Need help?

For setup help or support, visit or call

go.roku.com/TV

1-816-272-8106

4:00 am - 10:00 pm PT

