# SPF- C系列智能喂食器

# 使用说明书
# User Manual




使用产品前请仔细阅读使用说明书，并妥善保管
Please read the user manual carefully before using the product and keep it properly.

## 目录 Table of Contents


产品清单 product list ..... 1
产品简介 Product Introduction ..... 2
产品安装 Product Installation ..... 3,4,5,6,7
产品使用 Product Usage ..... 8
清洁维护 Cleaning and Maintenance ..... 9
基本参数信息 Basic Parameter Information ..... 9
产品有毒有害物质名称及含量 Product Usage ..... 10
敬告用户 Important Notice to Users ..... 10,11
使用安全指导 Safety Instructions for Use ..... 11
售后服务 After-sales Service ..... 12
合格证 Certificate of Conformity ..... 12



## 01 产品清单 Product list

*在安装使用前，请先做好配件确认。
*Before installation and use, please first confirm the accessories.






## 02 产品简介 Product Introduction






扫码下载智能宝宝App，体验更多功能。
Scan to download the SmartLife App for more features.

① 通过App内定时功能可以设置喂食计划，喂食器会按照设置的计划，每天定时出粮，主人能及时查看喂食记录，及时掌握给宠宝物资食状态。
The feeder can be scheduled via the app's timer to dispense food daily as set. Owners can check feeding records and monitor dispensing and eating status in real time.

② 有疑问请点击「我的」进入帮助中心查询
For questions, tap "Me" to enter the Help Center and search.

• 短接说置
Pairing Settings
连接好APP以后，可直接通过手机控制，点击喂食按键投喂，一次最多可投喂12份；
After connecting the app, you can directly select the copies and click the feed button to feed, with a maximum of 12 portions at a time;
点击定时按键可设定定时按键时间和份数；
Click the timer button to set the feeding time and portion.
点击喂食记录按键可查看历史喂食记录。
Click the feeding record button to view historical feeding records.

• 手动投喂
Manual feeding
无论是否配网，短按 WiFi 按键可投喂1份宠粮。
Regardless of whether it is connected to the network, a short press of the WiFi button can dispense one serving of pet food.




### 4.3 WiFi 数据传说明 WiFi model operation instructions




• 连接手机APP
Connect mobile app

下载安装App：扫码安装APP或从App Store或安卓应用市场下载“智能生活”，
进入App“首页”，点击界面右上角“+”添加对应设备，根据提示绑定设备，注册并登入。
Download the App: Scan to install or get "SmartLife" from App Store or Android Market.
Enter the App 'Home' page, click the "+" in the upper right corner of the interface to add the corresponding device, bind the device according to the prompts, then register and log in.



• 储粮桶清洁实后，务必将各部件完全晾干，进一袋回高进行使用。
After cleaning the grain storage bin, let all parts dry completely before reassembling and using.
• 如您暂时不使用本机，请将电源插头拔出，并清洁本机干后保存。
If you want to stop using it, please unplug the power cord, clean and dry it, and then store it.
• 如遇移动本产品，请提前将电源线
Unplug the power cord if you need to move the product.
• 宠物儿童使用前应会备，请确保在在成人引导下使用。
If children are using this device, ensure that they are supervised by an adult.
• 除非他人具有此类使用本产品进行指导或父母监视喂养指导，否则，本产品不得被儿童或身体、感官或智力能力减弱的人士使用。
Only qualified service personnel should perform maintenance or repairs on this product to avoid potential injury.

## 售后服务 After-sales Service

保修条例 Warranty Terms

在保障期内出现非人为损坏造成的产品性能故障可以享受下列三包服务：
During the warranty period, if the product experiences performance issues due to non-human-induced damage, the following three guaranteed policies (repair, replacement, refund) are available:

1.自购机之日7天内，产品出现质量问题，消费者可以选择按照购买价格一次性退款退货
Within 7 days from the date of purchase, if a product has quality issues, the consumer can choose to receive a one-time refund at the purchase price or replace it with the same model and specification.

2.自购机之日15天内，产品出现质量问题，消费者可以选择更换同型号同规格产品；
2. Within 15 days from the date of purchase, if a product has quality issues, the consumer can choose to replace it with the same model and specification.

3.本产品三包责任不包含：
3. The warranty period for this product is one year.

非保修条例 Non-warranty Terms

基于下列情况给您不在保修下列维修义务（三包”范围之外）：
The following situations (but not limited to these) are not covered by the warranty service:

1.超过“三包”服务有效期限；
1. Beyond the validity period of the "three Guarantees" service;

2.未按照用户手册要求使用,维修协商要收费造成的损失；
2. Damage caused by failure to use, maintain, or store the product according to the user manual.

3.超出买票点,未交换不可抗力造成的损坏。
3. Damage caused by force majeure, such as fire, flood, lightning strike, or flood.

4.保修卡上的产品型号或编号与实物不相符合；
4. The product model or serial number on the warranty card does not match the actual product.

5.自非授权服务者拆修造成损坏的；
5. Damage caused by disassembly or repair by non-authorized service providers.

6.产品使用过程中正常的磨损,易损和消耗,不是保修范围内的故障
7. Normal fading, wear and tear and consumption during product use are not malfunctions covered under the warranty.



## 05 清洁维护 Cleaning and Maintenance

1、主机不可用水冲洗或浸水，可用湿巾擦拭。
The host cannot be rinsed with water or soaked. It can be cleaned with a wet wipe.
2、上盖、不锈钢碗、单/双食盆，建议加入适量洗涤剂，并冲洗干净，清洗完毕，待各部件完全晾干后进一装回。
For the upper cover, stainless steel bowl, and single/double feeding bowls, it is recommended to add an appropriate amount of detergent and rinse thoroughly. After cleaning, reassemble each part one by one once they are completely dry.
3、清洁本产品时请务必将电源线拔有电源清洁，避免用材质较硬的清洁工具，以免造成塑料件的刮花。
3. When cleaning this product, be sure to use a sponge or soft cloth, and avoid using cleaning tools made of harder materials to prevent scratching the plastic parts.
4、喂食器及适合干燥的宠粮，请勿放入潮湿或易腐烂的食物；
4. The feeder is only suitable for dry pet food; do not put in moist or perishable food.
5、为了保持喂食器的清洁卫生，建议每周清洁一次；
5. In order to maintain the cleanliness and hygiene of the feeder, it is recommended to clean it once a week.
6、如喂食器出现故障或异常情况，请立即停用，并及时联系售后服务。
6. If the feeder malfunctions or shows abnormal conditions, please stop using it immediately and contact after-sales service promptly.

清洁时请务必将电源或软有电清洗,避免用材质较硬的清洁工具,以免造成塑料件的刮花。
主机不可浸水或洗水,可用湿纸巾擦拭。
When cleaning, be sure to use a sponge or soft cloth, and avoid using cleaning tools that are too hard to prevent scratching the plastic parts.
The main unit must not be immersed or soaked in water, and can be wiped with a damp cloth.



## 基本参数信息 Basic Parameter Information

| | | | |
|---|---|---|---|
| 产品名称 Product Model | 小智智能喂食器 Smart Feeder | 额定输入 Rated Input | 5V⎓1A |
| 产品型号 Product Model | SPF-C | 额定功率 Rated Power | 5W |
| 产品尺寸 Product Size | 320*185*360mm(S/SL)<br>350*340*360mm(D/SL)<br>320*185*475mm(S/XL)<br>350*340*475mm(D/XL) | 连接方式 Connection Method | Wi-Fi连接(wifi版) Wi-Fi connection(wifi version) |
| 储粮桶容量 Capacity | 3L/4L | 适用范围 Applicable Range | 猫和小型犬 Cats and small dogs |

## 产品有毒有害物质名称及含量 Toxics & contents

| 部件名称 Component Name | 有害物质或元素 Hazardous substances or elements | | | | | |
|---|---|---|---|---|---|---|
| | 铅 Lead (Pb) | 汞 Mercury (Hg) | 镉 Cadmium (Cd) | 六价铬 Hexavalent chromium (Cr6+) | 多溴联苯 Polybrominated biphenyls (PBB) | 多溴二苯醚 Polybrominated diphenyl ethers (PBDE) |
| 印刷电路板组件 Printed Circuit Board Assembly | X | ○ | ○ | ○ | ○ | ○ |
| 塑料 plastic | ○ | ○ | ○ | ○ | ○ | ○ |
| 金属 metal | ○ | ○ | ○ | ○ | ○ | ○ |
| 附件 Accessories | ○ | ○ | ○ | ○ | ○ | ○ |

本表格依据 SJ/T 11364 的规定编制。
O:表示该产品所有均质材料中的含量均在 GB/T26572 规定的限量要求以下。
X:表示该有害物质至少在该部件某一均质材料中的含量超出 GB/T26572 规定的限量要求以下。
This table is prepared in accordance with SJ/T 11364.
O: Indicates that the content of all homogeneous materials in the product is below the limit specified in GB/T26572.
X: Indicates that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit specified in GB/T 26572.



## 敬告用户 Warning to Users

• 感谢您选购智能喂食器SPF-C系列产品,本产品致力于具有科技为您和您的爱宠创造更好的生活。
Thank you for purchasing the SPF-C series smart feeder. This product is dedicated to using technology to create a better life for you and your beloved pet.
• 使用前请仔细阅读本产品说明书，一经安装或使用,即表示已经仔细阅读并接受下列安全指导。
Please read the product manual carefully before use, by installing or using this product, you acknowledge that you have read and accepted the following safety instructions.
• 由于违规操作而导致的任何意外事故及财物损失我们将不承担责任。
The company shall not be responsible for any accidents or losses caused by improper operation, nor shall it bear any liability for them.
• 本声明的解释权和修改权归本公司所有。
The right of interpretation and amendment of this statement belongs to our company.

## 使用安全指导 Safety Instructions for Use

*不通过下列条款,可能导致产品无法正常使用,甚至其他损失。
*Failure to comply with the following terms may result in the product not functioning properly or other unexpected losses.


• 请严格按照说明书安装和使用设备。
Please install and use the device strictly in accordance with the instructions.
• 请在室内环境使用,请勿放置在阳光可以照射到的地方使用,会影响设备功能;放置位置请远离火源。
Please use the device indoors and avoid placing it in areas exposed to direct sunlight, as this may affect its functionality. Also, keep it away from sources of fire.
• 本产品为安全性电压供电,但发物体仍有电存在导致漏电风险，请注意在使用产品时固定和隐藏电源线，避免被宠物撕咬的可能,发现宠物咬线行为，请及时制止。
Although this device operates on safe voltage, there is still a risk of electrical leakage. Please ensure the power cord is fixed and concealed during use to prevent it from being chewed by pets.Immediately stop if you notice your pet chewing on the cord.
• 请使用原装电源线,否则会损坏设备或引起安全隐患。
Please use the original power cord, otherwise it may damage the device or cause safety hazards.
• 保持水平放置,请勿打翻设备,否则可能导致设备失法正常工作。
Keep the device level and avoid tipping it over, as this may cause it to malfunction.
• 请勿将宠粮以外的物品落入储粮桶中,否则会造成设备使用异常,甚至造成宠物安全问题。
Avoid putting anything other than pet food into the storage bin to prevent abnormal device malfunction and pet safety issues.
• 为防止宠物扑倒误产品,建议设置角落或者墙角处。
To prevent pets from knocking over the product, it is recommended to place it in a corner or against a wall.
• 请勿将本产品放置于高处,防止产品跌落造成产品损坏或宠物安全问题。
Do not place the product on high surfaces to prevent damage or pet safety issues from falls.
• 本产品主机禁止浸水或洗水,配有防水盖清洁储粮桶。
Do not immerse or use the device in damp environments.



## 03 产品安装 Product installation

打开主机底部电池仓盖，嵌入电池，将电源线插入电池仓内的电源插座，并将电源线卡入电线卡槽内，把单/双碗与主机连接。
Open the battery compartment cover at the bottom of the main unit, insert the batteries, plug the power cord into the power socket in the battery compartment, and snap the power cord into the cord holder. Then connect the single or double bowl to the main unit.

(注意:请使用产品指导电源线，以避免电击和火灾风险，电池仓可装填4节5号电池，电池需用户自备，双碗电使用可自备外传电存储持续食盆正常工作。)
(Note:Please use the power cord supplied with the product to avoid motor damage and fire hazards. The battery compartment can hold 4 AA batteries, which need to be provided by the user. Dual power supply can keep the feeder working normally in case of a power outage.)





## 04 产品使用 Product Usage

### 4.1添加宠粮 Add pet food

① 打开上盖，加入宠粮，请勿超过MAX线。
Open the lid, add pet food, do not exceed the MAX line.

*建议宠粮尺寸在12mm以下，
Suggest the size of pet food is 12mm or less than 5mm.



② 盖好上盖
Cover it with the lid.




### 4.2按键款操作说明 Button Model Operating Instructions









• 设置当前时间
按键模式喂食：点时复间环是总时间为00:00，长按START进入，进入设置模式，进入设置菜单显示第一个设置项（时钟），当前设置项数字00(小时)闪烁提示，此时按ADD按键使数值+1，按5s按键数值-1，连续数值。
按键START键，自动保存，跳转至下一数字项，此时闪烁小时设置数值完成，同时设置项数字00（分钟）闪烁提示，此时按ADD按键数值+1，按5s按键数值-1，连续数值。
按键START键，自动保存，跳转至下一设置项，此时闪烁分钟设置数值完成，同时设置项数字00（分钟）闪烁提示，此时按ADD按键数值+1，按5s按键数值-1，连续数值。
Set the Current Clock
Turn the dial, and the time display shows 00:00. Press and hold the START button to enter the setting mode. Once entered, the screen will display the first setting item (clock). The current setting digit (00/hour) will flash as a prompt. Press the ADD button to increase the value by 1 minute. Press and hold the button to increase the value by 5 minutes for continuous setting. Press the START button to save and jump to the next digit. At this time, the hour setting value is completed, and the minute digit (00 ● flash as a prompt. Press the ADD button once and jump to the next digit. At this time, the hour setting value is completed, and the minute digit (00 ● flash as a prompt. Press the ADD button to increase the value by 1. After selecting the desired value, do not press any buttons. The digit will flash 5 times and then automatically save. The digital screen will display the current time, and the current time setting is completed.

• 设置定时喂食计划
按键喂粮食盘，可以设置每天6餐自动定时投喂，在设置时钟完成后，长按START按键，进入设置模式，数码屏数值闪烁，此时开始设置第1餐。
Set a scheduled feeding plan
Button-type feeder, can set up to 6 automatic meals per day. After setting the clock, long press the START button to enter the setting mode. The digital screen value will flash, indicating that you can start the setting operation.

步骤1：当前设置项为第1餐(小时)闪烁提示，此时按ADD按键数值+1，按5s按键数值-1，连续数值。
按START键，自动保存，跳转到下一数字项；
Step 1: The current setting number 00(hour) flashes to indicate it's active. At this point, press the ADD button to increase the value by 1 or press the SUB button to decrease the value by 1. After selecting the desired value, press the START button briefly to save automatically and move to the next number.

步骤2：当前设置项为第1餐(分钟)闪烁提示，此时按ADD按键数值+1，按5s按键数值-1，连续数值。
自动保存，跳转到下一数字项；
Step 2: The current setting digit 00 (minutes) flashes as a prompt. At this time, press the ADD button to increase the value by 1, press the SUB button to decrease the value by 1, and short press the START button to automatically save and move to the next digit.

步骤3：按喂份数设置，喂码屏显示1P-20，其中1P表示第一份，数字0为代表份数，设置按键单次0份投喂，此时按ADD键数值+1，5S按键数值-1，连续数值。
设置完成后，长按START键，自动保存，退出设置，此时屏幕恢复至当前时间显示，设置完成。
Step 3: Set the feeding portions. The screen displays 1P-20, where 1P represents the first portion, and the number 0 represents the portion quantity. When the setting number is 0 flashes, it indicates that the value can be adjusted. Press the ADD button to increase the value by 1, press the SUB button to decrease the value by 1, and short press the START button to automatically save and move to the next digit. Press and press to the second interval setting. A value of 0 means no feeding for this meal while values 1-10 represent 1 portion to 10 portions with 1 being the minimum and 5 being the maximum. For example, setting 1P-3 means feeding 3 portions at the first meal, and setting 2P-0 means no feeding for the second meal. After completing the parameter setting, long press the START button to save and exit the setting mode. The screen will restore to the current time display, indicating that the parameters for the remaining 5 meals. After completing the parameter setting, the digital screen will return to normal time display. The feeder will execute the automatic timed feeding mode according to the set times and portions, repeating every day.



## 合格证 Certificate of Conformity

智能宠物喂食器
Smart pet feeder

合格证
Certificate of Conformity

生产日期：2026年8月
Production Date: August,2026

检验人员：
Inspector:

QC 01

## FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.