




产品介绍

感谢您选择我们的产品

本产品为智能无线领夹麦克风，可提供专业级别录音输出，即插即用，无需APP，多种用途：可实现网络直播、视频Vlog拍摄、节目访谈、采访录音、视频教学等场合的使用。

无线领夹麦克风有三部分构成，充电仓，麦克风发射端，接收端。（如下图所示）

(充电仓) (发射端) (接收端)



使用方法

第一步：首先先把接收端从充电仓拿出来，然后一头插入手机充电的接口。

注：OPPO/VIVO/iQOO/Realme品牌的手机要到设置里面（搜索“OTG”-打开OTG供电）才能正常使用。

第二步：接着充电仓拿出发射端麦克风就会自动连接。

第三步：接收端和发射端连接指示灯常亮，即连接成功，可以打开手机相机、直播视频等APP即可使用麦克风收音。

特别说明：
第⑩的使用方法如下：如果直播时，手机电量不足的情况下，直接通过接收端的接口给予手机充电。

UI功能

功能/状态	操作	灯效
开机	长按25开机关键	连接指示灯交替闪
关机	长按25开机关键	指示灯熄灭
与TX配对	开机自动配对	指示灯常亮
断开连接	长按RX或者TX关机	指示灯熄灭
AI降噪	单击功能键开启AI降噪/关闭降噪（默认AI降噪）	开启：连接指示灯亮 关闭：连接指示灯呼吸灯
静音	双击功能键开启静音/单次双击关闭静音	开启：指示灯常亮 关闭：恢复之前状态
低电报警	当电池电压低于3.3V	红灯5秒闪烁一次
低电关机	当电池电压低于3.1V时	红灯5秒闪烁一次
充电	放入充电仓	充电红灯，充满天灯

接收端

功能/状态	操作	灯效
开机	插入手机充电端口即可开机	指示灯常亮
关机	从手机上拔出接收端	指示灯熄灭
与TX配对	开机自动配对	指示灯常亮
断开连接	TX关机或者长按RX关机	指示灯熄灭
音量	按一下功能键	一档：指示灯闪一下 二档：指示灯闪两下 三档：指示灯闪三下

使用须知

苹果手机和华为手机即插即用VIVO/OPPO等部分手机需要手动打开OTG功能！

VIVO手机：打开设置 找到更多设置 找到OTG点击右边开关开启即可

OPPO手机：打开设置 找到更多设置 找到OTG点击右边开关开启即可


部分手机：打开设置 找到其他网络与连接进入找到OTG点击右边开关开启即可

注：OTG在不使用情况下5-10分钟手机会自动关闭！
录制完视频 不需要拔掉 接收器方可播放视频！

包装清单

包装清单内容

(1) 充电仓
(2) 麦克风发射端
(4) 接收端
(5) 充电线
(7) 用户说明书




Introduction

Thank you for choosing our product.

This product is an intelligent wireless lavalier microphone, which can provide professional-level recording output. It is plug-and-play, no APP is required. It has multiple uses: it can be used in live streaming, video Vlog shooting, program interviews, interview recording, video teaching and other scenarios.

The wireless lavalier microphone consists of three parts: charging case, microphone transmitter, receiver. (As shown in the figure below)

(power case) (transmitter) (receiver)



How to use

Step 1: First, take the receiver out of the charging case, and then plug one end into the charging port of the mobile phone.

Note: oppo / vivo / iqoo / realm brand mobile phones can be used normally only when they go to the settings (search "OTG" - turn on OTG power supply)

Step 2: Then take the transmitter microphone out of the charging case, and it will connect automatically.

Step 3: The connection indicator lights of the receiver and the transmitter stay on, which means the connection is successful. You can open apps such as the mobile phone camera and live video apps to use the microphone for audio recording.

Special Note:
For the use of ⑩ port: If the phone is low power during Live, it can be recharged directly through ⑩ port.

About UI

Function	How to use	Light
Power on	Press and hold the power button for 2 seconds	Connection indicator flashes alternately
Power Off	Press and hold the power button for 3 seconds	Indicator light turns off
Disconnect	Auto power off if disconnected from RX for 3 minutes	No light flash
Pair with RX	Auto-pairs when powered on	Connection indicator stays steadily lit
Disconnect	Unplug RX or power off TX	Connection indicator flashes alternately
AINoise Reduction	Single-press function key to toggle AI noise reduction (default: on)	Enabled: Connection indicator stays on Disabled: Connection indicator breathes
Mute	Double-press the function key to enable mute; double-press again to disable	Enabled: Indicator stays steadily lit Disabled: Reverts to previous state
Low Battery Alert	When battery voltage drops below 3.3V	Red light flashes once every 5 seconds
Low Battery Shutdown	Auto power off when battery voltage drops below 3.1V	Red light flashes once every 5 seconds
Charging	Place into the charging case	Red light on while charging; turns off when fully charged

Receiver

Function	How to use	Light
Power on	plug into phone	flashing
Power off	unplug	off
Connect mic	auto-pairing	remains on
Disconnect	unplug or power off	Indicator flashes slowly
Volume	Press the function key once	Level 1: The indicator light flashes once Level 2: The indicator light flashes twice Level 3: The indicator light flashes three times

Use the information

iPhone and Huawei phones plug and play VIVO/OPPO and other mobile phones need to manually open the OTG function!

VIVO mobile phone: Open Settings find more Settings find OTG click on the right switch to open

OPPO mobile phone: Open the Settings to find other Settings to find OTG and click the switch on the right

Partial phones: Open Settings to find other networks and connect to find OTG Click the switch on the right to open it

Note: If OTG is not in use for 5-10 minutes, the phone will automatically shut down! After recording the video, you do not need to unplug the receiver to play the video!

Packing List

Packaging List Content

(1) Charging Case
(2) Microphone Transmitter
(3) Receiver
(4) Charging Cable
(5) User Manual

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.