



Mibro OpenEar Pro


User Manual

User Manual

Thank you for purchasing this product, before using, please read carefully and strictly follow the instructions and precautions and keep it in a safe place for reference.

Note: Please fully charge it with the charging case before the first use when you receive the product.


Product Overview



- ① Multi-function Button ② Tone hole ③ Noise-canceling microphone & headset status indicators
- ④ Tone hole ⑤ Microphone ⑥ Charging Pin ⑦ Soundhole ⑧ Charging compartment status indicator
- ⑨ USB-C Charge input


Initial use

- For the first time use, please tear off the protective film on the charging pin of the headset, then put the headset into the charging box and close the lid, open the box again and you can use it




Charging

- Earphone into charging compartment, automatic charging
- When the charging compartment is connected to the USB-C charging cable, the charging compartment light blinks for normal charging.




On/Off

- Open the cover, the earphone charging light blinks to indicate power on
- Close the cover, the earphone will be turned off



Wearing Style

- Distinguish between left and right ears
- Rotate backward following the contours of the ear
- Adjust the earphone to fit comfortably



Download APP



"Mibro Fit "App

- Please scan the QR code to download the Mibro Fit App.
- Please use the Mibro Fit App to manually scan the code for pairing.

App Connection Function

- Real-time display of earphones battery level;
- Finding earphones;
- EQ customization;
- Touch function customization;
- Earphones software OTA;
- Earphones operating instructions.

Connecting the APP for the first time

- Open the lid, the earphones will be turned on automatically.
- In Mibro Fit App, click "Add Device" and select "Open Headset" to bind the device.




Connecting your phone's Bluetooth for the first time

- Open the lid, the earphones will be turned on automatically.
- Turn on your phone's system Bluetooth, search for the Bluetooth name "Mibro OpenEar Pro" and click on it to pair.



Dual-device connection

- With the earphones in the box and keeping the lid open, press and hold the touch buttons of both earphones for 5 seconds at the same time, at this time the earphones will disconnect from the current device with Bluetooth connection and can be paired with the second device.
- Once the earphone is successfully paired with the second device, you need to manually reconnect the earphone once on the first device to switch the sound between the two devices.



Device A is in connected status


Press and hold dual earphones for 5 seconds

After Device B is successfully connected


Click to reconnect Device A

Unbind and disconnect

- Delete this device in Mibro Fit




- Cell phone Bluetooth ignores this device



Auto-reconnect


- Open the lid and connect back automatically



Key presses


- The following illustration shows the default button function of the headset, you can also customize the button function operation through the Mibro Fit App.

Answer/hang up Left/Right
Double-tap on ear




Previous Three strikes to the left ear.

Game Mode Double click on the left ear






Next song. Three strikes to the right ear.

Play/Pause Double-tap right ear



Wake up voice assistant Long press
left and right ear



Basic Parameters

Earbuds Basic Parameters:

BT Model XPEJ011

BT Version BT5.4

BT Range $\leq 10\text{m}/33\text{ft}$

Weight About 7.2g (Per Earbud)

Battery Capacity 60mAh (Per Earbud)

Charging Time About 1 hours

Play Time About 6 hours

Waterproof IPX4

Stand By About 60 hours

Input $5\text{V} \Rightarrow 100\text{mA}$

Battery Type Lithium ion polymer

Charge Box Basic Parameters:

Battery Capacity 500mAh

Input $5\text{V} \Rightarrow 500\text{mA}$

Output $5\text{V} \Rightarrow 200\text{mA}$

Charging Time About 2 hours

Battery Type Lithium ion polymer

Weight About 46g

Packing List

Charging case x1 pcs, earphones x2 pcs, charging cable x1 pcs, manual x1 book.



Safety Instructions

Before using and operating the equipment, read and observe the following precautions to ensure optimal performance and to avoid dangerous or illegal situations.

- Product information and certification labels are located inside the charging case.
- To prevent possible hearing damage, do not use this product at high volume levels for extended periods of time.
- Please observe the relevant regulations in your region or country and do not use this product while driving.
- Do not disassemble, hit, crush, put into fire or high temperature environment, avoid crushing or cutting the battery mechanically, which may lead to explosion.
- The product contains a non-removable lithium battery, please do not replace the battery yourself to avoid damage to the battery or the device. The battery can only be replaced by an authorized service center and must be replaced with the same type of battery; replacing the battery with an incorrect type will damage the protective measures, resulting in fire, explosion, battery leakage, etc. Do not continue to use the battery if it is severely inflated.
- Replacing the battery with an incorrect type will damage the protective measures (e.g. fire, explosion, battery leakage, etc.). Do not continue to use the battery if it is severely inflated.
- Do not dispose of the old batteries in the household garbage. Dispose of this equipment and the used batteries according to local laws and regulations.
- Do not use this product in thunderstorms, which can cause the equipment to work abnormally and increase the risk of electric shock.
- Do not subject the battery to extremely high temperatures or extremely low air pressure, which may cause an explosion or leakage of flammable liquids or gases.
- This product is not a toy, the product body and accessories contain small parts may cause children to suffocate or cause other injuries, please place the product out of reach of children. If symptoms such as redness and swelling appear on the skin at the site of contact, discontinue use immediately and consult a physician.
- The Bluetooth® word mark and logo are registered trademarks of the Bluetooth SIG, Inc. and the mibro brand has been granted the right to use such marks.



Name and content of hazardous substances

Part name	Hazardous substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Earbuds	○	○	○	○	○	○
Battery	×	○	○	○	○	○
Charge Box	○	○	○	○	○	○
Charge Cable	×	○	○	○	○	○

This table is prepared in accordance with SJ/T 11364-2014.

- Indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit specified in GB/T 26572.
 - ×
- It means that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit specified in GB/T 26572.

This product meets the ROHS environmental protection requirements: there is no mature technology in the world to replace or reduce the lead content of some electronic components of circuit components, steel and copper alloys.



The numbers in this logo indicate that the product (except batteries) has an environmental protection use period of 10 years under normal use.

The Eco-Friendly Use Period markings on the components take precedence over any conflicting or different Eco-Friendly Use Period markings on the product. All environmental protection use periods for this product are the safe years of use without leakage of toxic or hazardous substances when the product is used under the conditions of use specified in the product manual.

Performance faults and after-sales regulations

Name	Performance Fault Table
Mibro OpenEar Pro	● No sound during the use of the earphone ● The other party can't hear the sound during a call ● Unable to charge, charging indicator does not light up.

Non warranty regulations

1. Wear and dirt caused by users' use, such as scratches and color changes; As well as damage caused by contact with chemical reagents, sharp objects, falling, extrusion and deformation.
2. Unauthorized maintenance, collision, misuse, negligence, abuse, water ingress, accidents, and failures caused by the use of non-standard accessories of the product.
3. Tearing, altering labels, forging anti-counterfeiting marks, etc.
4. Damage caused by force majeure.
5. Non compliance with performance faults listed in the performance fault table.

If you need after-sales service, please contact Mibro customer service:

Website: www.mibrofit.com

Email: service@mibrofit.com

Attention:

The illustrations of the product, accessories and other illustrations in the manual are schematic diagrams for users' reference only. Due to the updating and upgrading of this product, there may be differences between the actual product and the schematic diagram, so please refer to the actual product! Please keep the manual and proof of purchase.

- Mibro brand owns the final right to interpret the goods.

One. Why is the headset touch function sometimes unresponsive?

1. The touch area may not be touched correctly resulting in no response, please refer to the diagrams in the “User's Manual”;
2. The speed of continuous touch is too slow, please make sure to touch 2 or 3 times to complete the operation quickly and continuously;
3. Dirty fingers or too much liquid, resulting in the touch area is not sensitive, please keep the finger surface and the headset press prompt area clean, then press the headset to prompt the area clean, then press the headset to prompt the area.
Please keep the surface of the finger and the headset press prompt area clean, and then touch operation.

Two.No sound can be heard from the headset, or the sound from the left and right headset is not consistent.

1. Confirm that the headset is in working condition;
2. Confirm that the volume of the headset is appropriate;
3. Confirm that the headset is normally connected to the phone;
4. Please adjust the left and right headphones to wear exactly the same;
5. Please put the headset back into the charging case, and then take it out after 5 seconds to reconnect it for use;
6. Please check whether the headset power is too low, please put the faulty headset back to the charging box fully charged and then take out to use.

Three. the headset call effect is not good

1. The effective use of the headset distance of 10 meters, please make sure that the headset in the effective use of the distance, and the headset and cell phone between the obstacles blocking;

2. Check whether the microphone hole is blocked by dust or foreign objects;
3. Please make sure that the volume of the headset is adjusted too low/mute;
4. Please check whether the headset battery is too low, low battery will affect the performance of the headset.

Four. equipment maintenance

1. If the product with lithium battery is not used for a long time, please make sure it is charged at least once every three months;
2. Keep the product dry, do not put in a wet place, so as not to affect the internal circuitry of the product;
3. Avoid using the product during intense exercise or sweating to prevent sweat from penetrating into the product and damaging the product.
Avoid using the product during intense exercise or sweating to prevent sweat from penetrating into the product and damaging it;
4. Do not place the product in the sun or high temperature places.
High temperatures can shorten the life of electronic.High temperatures can shorten the life of electronic components, damage batteries, and deform some plastic parts;
5. Do not attempt to disassemble the product, which may damage the product if not done by a professional;
6. Do not use strong chemicals, cleaning agents to clean the headset;



网 址: www.mibrofit.com

邮 箱: service@mibrofit.com

制造商: 甄十信息科技(上海)有限公司

地 址: 上海市闵行区紫星路588号2幢4015室

Web: www.mibrofit.com

Support: service@mibrofit.com

Manufacturer: ZhenShi Information Technology (Shanghai) Co., Ltd.

Address: Room 4015, Building 2, No.588 Zixing Road, Minhang District,
Shanghai, China

Exporter: ZhenShi Information Technology (Shenzhen) Co., Ltd.

Address: RM1401-1403,1408, Tower E, Galaxy World, Minzhi Street,
Longhua District, Shenzhen, China



扫一扫查看更多语言的用户手册
Scan for user manuals in more languages



V0.3