



CHEF-STACK/CONV INSTRUCTIONS

CHEF'S **COMBI**™


1. Rotate the convection oven onto the left side as shown to access the threaded holes on the bottom.



2. Install caster supports to oven.
3. Install casters to supports/oven.



4. Rotate oven onto casters.



CHEF-STACK/CONV INSTRUCTIONS

CHEF'S **COMBI**™

5. Loosen screws from the rear of the top cover of the convection oven approx 1/4".

6. Place support plate on the top of the convection oven ensuring flanges fit over the screws on the rear of the convection oven.

7. Tighten screws on rear of the convection oven onto the support plate.

8. Install the Chef'sCombi oven onto the support plate. The inner pins are for the CHEF-61 model and the outer pins are for the CHEF-62 model.

9. Place oven in location and connect per provided oven instructions.

