




EMEET OfficeCore M0 Plus



E1103 User Manual

CONTENTS

English.....01

日本語.....06

V0.5



×1




×1



×2

Overview



- ① Mute button
- ② Volume down
- ③ Bluetooth button
- ④ Power button
- ⑤ Battery indicator
- ⑥ Volume up
- ⑦ Answer/End phone call
- ⑧ Status indicator
- ⑨ Type-C port
- ⑩ Daisy Chain port
- ⑪ MIC hole

Button Controls

⏻	press and hold	Power on/off
	In power-on state, press	Display battery level
⏮ / ⏭	Press	Volume up/down
☎	Press	Answer/End phone call
	Incoming call, press and hold	End phone call
🔇	Press	Mic mute/unmute
📶	Press and hold	Search Bluetooth
	Press	Bluetooth closed
		Bluetooth reconnected

Status LED

1. Status indicators

Status	LED	
USB connection	Steady green	●
Search Bluetooth	Flash blue	☀
Bluetooth connection	Steady blue	●
Bluetooth closed	Steady white	●

2. Volume Indicator

Status	LED	
Volume display	The light is in blue for 2 seconds.	● ● ● ● ●
Battery level display	The light is in green for 2 seconds.	● ● ● ● ●
Low battery alarm	Flash red for 2 seconds.	☀ ○ ○ ○ ○
The MIC is muted.	Steady red	● ● ● ● ●
Caller display	Flash blue	☀ ☀ ☀ ☀ ☀

Operating Instructions

1. On/Off button

Press and hold the power button “⏻” for 2 seconds to power the product on or off.

2. Connecting

(a) The product will power on automatically after it's connected to a PC via a USB cable.



b) After the product is turned on, it will connect mobile devices such as PC or mobile phones through Bluetooth pairing.

• Note: When the product is turned on, it will reconnect to the last connected device via Bluetooth (if enabled on the device). The product cannot be found if its Bluetooth is closed.



3. Battery Display

Press the power button when the product is powered on to check the battery level.

Battery	Color	Display
0%-5%	red	● ○ ○ ○ ○
5%-25%	green	● ○ ○ ○ ○
25%-50%	green	● ● ○ ○ ○
50%-75%	green	● ● ● ○ ○
75%-100%	green	● ● ● ● ○
100%	green	● ● ● ● ●

4. Volume Display

10%	 ○ ○ ○ ○
20%	● ○ ○ ○ ○
30%	●  ○ ○ ○
40%	● ● ○ ○ ○
50%	● ●  ○ ○
60%	● ● ● ○ ○
70%	● ● ●  ○
80%	● ● ● ● ○
90%	● ● ● ● 
100%	● ● ● ● ●

5. Daisy Chain Cable

Daisy Chain can be carried out by connecting the ports of two products using a Daisy Chain cable.

• Note : Please use the EMEET dedicated Daisy Chain cable to connect the devices. Daisy Chain cables need to be purchased separately.

Product Parameters

· Note : In case of any changes in the specifications, the information on our official website shall prevail.

Charging input	5V = 1A
Output rating	3W
Bluetooth version	5.0
Bluetooth range	10m
Product size	116*116*40mm

Download Application

Visit www.emeeet.com to download the eMeet Link PC desktop app for software updates.

· Note : The device can operate normally even if eMeetLink is not downloaded.



Windows

Download

* For Windows 7/8/10 and above




macOS

Download

* For Mac 10.14 and above

各部分の名称



- ① ミュートボタン
- ② 音量ダウンボタン
- ③ Bluetoothボタン
- ④ 電源ボタン
- ⑤ 音量LED
- ⑥ 音量アップボタン
- ⑦ 通話ボタン
- ⑧ ステータスLED
- ⑨ USB-Cポート
- ⑩ AUXポート
- ⑪ マイク

ボタンの操作

⏻	長押し	電源オン/オフ
	電源オンの状態で、押す	バッテリー残量表示
+ / -	押す	音量の上げ下げ
☎	押す	着信に応答 / 通話を終了
	長押し	着信を拒否
🔇	押す	マイクミュート / ミュート解除
📶	長押し	Bluetoothペアリングモードに入り
	押す	Bluetoothをオフにする
		Bluetooth再接続

LED表示

1.ステータスLED

ステータス	LED	
USB で PCと接続中	緑色の点灯	●
Bluetooth ペアリングモードに入る	青色の点滅	☀
Bluetooth 接続完了	青色の点灯	●
Bluetoothをオフにする	白色の点灯	●

2.音量LED

ステータス	LED	
音量表示	2秒間青色の点灯	● ● ● ● ●
バッテリー残量表示	2秒間緑色の点灯	● ● ● ● ●
要充電	2秒間赤色の点滅	☀ ○ ○ ○ ○
マイクがミュート	赤色の点灯	● ● ● ● ●
着信	青色の点滅	☀ ☀ ☀ ☀ ☀


操作の説明

1.電源オン/オフ

電源ボタン “**⏻**” を2秒間押したままにして、本製品の電源をオン／オフします。

2.接続

(a) USBケーブルでPCに接続すると、電源が自動的にオンになります。



(b) 本製品がオンになったら、BluetoothペアリングによりPCまたは携帯電話などのモバイル機器に接続されます。

・注意:本製品の電源をオンにすると、前回接続された機器が利用可能な場合は、その機器に自動的に接続されます。(Bluetoothがオンの状態で)。



3.バッテリー残量の表示

電源がオンの状態で電源ボタンを押すとバッテリー残量を表示します。

バッテリー	LED	色
0%-5%	赤色	● ○ ○ ○ ○
5%-25%	緑色	● ○ ○ ○ ○
25%-50%	緑色	● ● ○ ○ ○
50%-75%	緑色	● ● ● ○ ○
75%-100%	緑色	● ● ● ● ○
100%	緑色	● ● ● ● ●

4. 音量表示

10%	
20%	
30%	
40%	
50%	
60%	
70%	
80%	
90%	
100%	

5. 有線Daisy Chain

Daisy Chain ケーブル(別売り) を使用して、2台製品のAUXポートに接続すると、有線スカード接続が可能になります。

・注意: EMEET専用のDaisy Chain ケーブルを使用して、2台の製品を連結してください。Daisy Chain ケーブルは別途購入する必要があります。

製品パラメーター

・注意:仕様に変更があった場合、公式ウェブサイトの情報が優先されます。

充電入力	5V ≒ 1A
出力定格	3W
Bluetoothバージョン	5.0
Bluetooth範囲	10m
製品サイズ	116*116*40mm

アプリケーションのダウンロード

ソフトウェアの更新のために、www.emeet.comにアクセスして、eMeet Link PCデスクトップアプリをダウンロードします。

・注意: 本製品は、eMeetLinkがダウンロードされていない場合でも、正常に動作します。



Windows

Download

* For Windows 7/8/10 and above



macOS

Download

* For Mac 10.14 and above