




Mag Wallet 2


Please read these instructions carefully before using the wallet and keep them in a safe place.

Product parameters

Product model: Tag Wallet
Pairing name: Tag Wallet
Bluetooth chip: Bluetooth 5.2
Working frequency: 2402MHz – 2480MHz
Effective Sound distance: Open & barrier-free space 30 meters
Battery capacity: 540mAh
Battery specification: Li-MnO₂ Battery/3.0V
Standby time: Max 36 Month
Play sound: Buzz
Waterproof Feature: Splash-proof design
Function: Phone stand/Wallet/ Works with Apple Find My / RFID Blocking

* The above data comes from laboratory measurements, but the data may vary or error due to changes in the objective environment.

What's in the box



Mag Wallet 2 x 1



Metal ring x1
Compatible with non-MagSafe cases

A

Getting Started

Power On

Press the Find My "U" button once, and the wallet will play a loud buzz.

Power Off

Press the Find My "U" button three times quickly, holding it down on the third press until the wallet plays a buzz and powers off.

Reset

Press the Find My "U" button five times quickly, holding it down on the fifth press until the wallet plays a buzz.

How to Remove the Wallet from Find My App?



Open the Find My app > Tap "Items" > Select the wallet (You renamed) > Tap "Remove Item" (confirm when prompted), then the wallet plays a buzz, and the wallet will leave pairing mode.

* When performing the above operation, please place the wallet next to your device.

Find Your Mag Wallet 2

Once your wallet is set up, The wallet have built-in speaker that deliver louder tones, so it's even easier to locate it.

1. Open the Find My app, then tap Items.
2. Tap the item that's connected to your wallet, then tap Directions.
3. Follow the onscreen instructions and move around the space until your iPhone connects to your wallet.
4. Follow the distance and direction information that your iPhone displays. When you get close to the wallet, you can tap "Play Sound" to hear a series of beeps that helps you find your wallet.



Works with
Apple Find My

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements.

System Requirements and Compatibility

- Apple ID
- iPhone and iPod touch models with iOS 14.5 or later
- iPad models with iPadOS 14.5 or later

Important: Not Compatible with the Following Devices

- iPhone 12 mini and iPhone 13 mini
- Android devices

Precaution

1. Avoid exposing the wallet to direct sunlight, high temperatures, or humid environments for extended periods.
2. Keep the product away from sharp objects, chemicals (e.g., perfumes, detergents), and abrasive surfaces.
3. Do not overload the card slots with more cards than recommended (max. 1 card per slot).
4. The product is equipped with a non-removable battery embedded internally, this battery does not need to be replaced. When disposing of the product, please follow local environmental regulations for battery-containing waste.
5. Do not attempt to disassemble this product to make any modifications, as it does not contain any repairable parts.
6. Store it in a dry, well-ventilated place when not in use; avoid pressing heavy objects on it to preserve its shape.

CE RoHS



Made in China

B

FCC WARNING

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference;
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.