

electro-harmonix

Bluetooth Speaker

EC-BTA1 AC Only – 34W Hi-Fi Powered Speaker

Thank you for purchasing the Electro-Harmonix Bluetooth Speaker AC Only. It may only be powered with an AC line voltage (100V-240V) connected to the AC connector on the rear panel. Total available output power is 34W.

Power Up

To power up your speaker, attach the supplied AC cable to the AC port on the rear of the speaker. Attach the other end of the AC cable to your wall outlet.

Turn the VOLUME knob clockwise, past its off/click position. The blue LED blinks and then lights solid.

Bluetooth Pairing

Once powered up, if the board has not been paired with any nearby devices, it should present itself for pairing. The speaker will have a Bluetooth name such as *EHX Apollo*.

If the speaker does not present itself for pairing, press and hold the push button until the Blue LED starts to blink—about 3 seconds. The board should now make itself available to be paired with a new device.

The blue LED continues to blink until a Bluetooth connection is made at which point the blue LED goes solid and the speaker is ready for playback.

Audio Playback

Once the speaker has been paired with a device, you may begin audio playback from the device. The speaker has three knobs and a multi-function button, controlling the following parameters:

VOL audio playback level

BASS low frequency EQ

TREBLE high frequency EQ

Push Button

- Press and release to play/pause audio.
- Double-click to advance to the next track.
- Triple-click to return to the beginning of the current track or, if the current track is within its first 4 seconds, skip to the previous track.
- Press and hold for 3 seconds to enter pairing mode.

AUX Audio Input

The rear panel includes a stereo 1/8" input. Connect the Auxiliary input to the stereo output of a device to listen to audio with a wired connection instead of Bluetooth.

AUX Input Without a Bluetooth Connection

Normally both Bluetooth and Auxiliary connections are live at the same time so you could mix wireless and wired audio together. If you prefer to only hear the Auxiliary input do the following:

- Power down the speaker by turning the VOL knob down to its minimum position, where it clicks into the off position.
- Press and hold the push button
- While continuing to hold down the button, power up the speaker by turning the VOL knob clockwise into the powered position.
- Once you see the LED light, release the button.

Power Down

Turn the VOL knob down to its full counterclockwise position, until you hear it click. The blue LED shuts off.

IMPORTANT SAFETY INSTRUCTIONS

- Read and keep these instructions.
- Heed all warnings.
- Protect the power cord from being walked on or pinched.
- Unplug this amplifier during lightning storms or when unused for long periods of time.
- Where the mains plug or appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
- Do not expose this apparatus to dripping or splashing and ensure that no object filled with liquids is placed on the equipment.
- This amplifier is capable of producing very high sound pressure levels which may cause temporary or permanent hearing damage. Use care when adjusting volume levels during use.
- Refer all servicing and maintenance to qualified service personnel. Changes and modifications not expressly approved by EHX can void the warranty.
- Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- **DO NOT** attempt to open the chassis. There are no user serviceable parts.
- Follow all instructions.
- Clean only with a dry cloth.

CONSIGNES DE SÉCURITÉ IMPORTANTES

- Lire et conserver ces instructions.
- Tenir compte de tous les avertissements.
- Protéger le cordon d'alimentation pour éviter qu'il ne soit piétiné ou pincé.
- Débrancher cet amplificateur en cas d'orage ou lorsqu'il n'est pas utilisé pendant de longues périodes.
- Lorsque la fiche secteur ou le coupleur d'appareil est utilisé comme dispositif de déconnexion, le dispositif de déconnexion doit être facilement accessible.
- Ne pas installer l'appareil à proximité de sources de chaleur telles que des radiateurs, registres de chaleur, poêles ou autres appareils (y compris amplificateurs) produisant de la chaleur.
- Aucune source de flamme nue, telle qu'une bougie allumée, ne doit être placée sur l'appareil.
- **AVERTISSEMENT :** Pour réduire le risque d'incendie ou d'électrocution, ne pas exposer cet appareil à la pluie ou à l'humidité.
- Garder cet appareil à l'abri des gouttes et des éclaboussures et s'assurer qu'aucun objet rempli de liquide n'est placé sur l'appareil.
- Cet amplificateur est capable de produire des niveaux de pression sonore très élevés qui peuvent provoquer des lésions auditives temporaires ou permanentes. Soyez prudent lorsque vous réglez les niveaux de volume pendant l'utilisation.
- Confier toutes les opérations de réparation et d'entretien à un personnel qualifié. Les changements et modifications non expressément approuvés par EHX peuvent annuler la garantie.
- Le service après-vente devient nécessaire lorsque l'appareil a été endommagé de manière quelconque, par exemple si le cordon d'alimentation ou la fiche est endommagé(e), si un liquide a été renversé ou si des objets sont tombés dans l'appareil, si l'appareil a été exposé à la pluie ou à l'humidité, s'il ne fonctionne pas normalement ou s'il a subi une chute.
- **NE PAS** essayer d'ouvrir le boîtier. Il n'y a pas de pièces réparables par l'utilisateur.
- Suivre toutes les instructions.
- Nettoyer uniquement avec un chiffon sec.

WARNING:
TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK DO NOT
EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.



The lightning flash with arrowhead symbol within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

Le symbole de l'éclair avec flèche dans un triangle équilatéral sert à avertir l'utilisateur de la présence dans le boîtier de l'appareil de "tensions dangereuses" non isolées suffisamment élevées pour présenter un risque d'électrocution aux personnes.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operation and maintenance (servicing) instructions in the literature accompanying the product.

Le point d'exclamation dans un triangle équilatéral sert à avertir l'utilisateur de la présence d'instructions d'utilisation et d'entretien importantes dans la documentation accompagnant le produit.

NOTICES

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment under FCC rules.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed operated with minimum distance 20cm between the radiator & your body.

Canadian IC Statement:

English: This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Français: L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: 1) L'appareil ne doit pas produire de brouillage; 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20cm de distance entre la source de rayonnement et votre corps.