




XG92说明书

55 mm

80 mm

<p style="text-align: center;">Smart glasses User manual</p>  <p style="text-align: center;">XG92</p>	<p>Product diagram</p>  <p>Packing list</p> 	<p>Product specifications</p> <p>Product model: XG92 Wireless version: V6.0 Charging time: about 60 minutes Battery capacity: 50mAh Transmission distance: about 10 meters Standby time: 30 hours Speaker unit: 14.2mm Bluetooth protocol: A2DP/AVDTP/AVRCP/RFCOMM/HFP/HSP/SPP/HID</p> <p>Functional operation instructions</p> <p>(1) Power on Press and hold the touch button for 1 second to turn on the phone, and the "TONE sound" white and green light will flash alternately.</p> <p>(2) Shutdown Press and hold the touch button for 2 seconds to turn off the machine. The white light will flash 3 times and turn off when prompted with "TONE tone".</p> <p>(3) Play/Pause Click the control key</p> <p>(4) Switch songs Double-click the left ear: previous song; Double-click the right ear: next song</p> <p>(5) Volume up/down Three-click control key: volume-</p> <p>(6) Answer phone calls Click the left/right ear touch button</p> <p>(7) Reject incoming calls Long press the left/right ear touch button for 2s</p> <p>(8) Hang up the call Click the left/right ear touch button</p>	<p>(9) Siri voice function Press and hold the touch button for 2 seconds and release to wake up Siri function</p> <p>(10) Low battery warning When the battery power is lower than 3.2V, the low-voltage prompt sound will cycle once for 30s. When the battery power is lower than 3.0V, the low-voltage shuts down. The "TONE" white light flashes once every 5 seconds</p> <p>Pairing method</p> <p>(1) Bluetooth connection a: Listen to both sides at the same time; you need to press and hold the left and right touch buttons at the same time for 1s to turn on the glasses, and the glasses will enter the pairing state; search "XG92" on the mobile phone's Bluetooth, and you can use it after connecting b: Listen alone on one side; just press and hold the touch button on one side for 1 second to turn on the glasses, and the glasses will enter the pairing state; search for "XG92" on your phone's Bluetooth, connect and use</p> <p>(2) Phone pairing successful The device displays the connection is successful, and the "TONE" is prompted to turn off</p> <p>(3) Pairing time In pairing mode, it is not paired with the phone, and the glasses are automatically turned off and the white and green lights are flashing alternately.</p> <p>(4) Disconnect The phone is actively disconnected from the headphones, prompting "TONE sound, white and green lights flash alternately</p> <p>(5) Automatic reconnection Device, prompt "When the TONE phone Bluetooth is turned on, the headset will automatically return to the paired last time after the headset is turned on.</p> <p>Charging Operation</p> <p>(1) Earphone charging Input DC: 5V power supply charging, the white light is always on</p> <p>(2) Earphones fully charged Turn off the headphones after full charge; turn off the green light for 20 seconds</p>	<p>pay attention to</p> <ol style="list-style-type: none">Before using the product, please read this user manual carefully and keep it properlyFor first use, please fully charge this product firstIf the product is not used for a long time (more than 1 month), please charge itIf the phone cannot search for Bluetooth earphones, please confirm whether the Bluetooth earphones are in "pairing status". If pairing or connection is not made for a long time, the Bluetooth earphone pairing function will be turned off. Please turn on the Bluetooth earphones again to "pairing status"; if there is an error in the mobile program, please restart the phone; if there is an error in the Bluetooth earphone program, please restart the Bluetooth earphones <p>warning</p> <ol style="list-style-type: none">Do not dismantle, repair or modify headphones for any reason, otherwise it may cause electronic components to break down or even completely damage this product due to fireDo not place the device in an environment where the temperature is too low or too high (below 0 °C or above 45 °C)Please avoid using device indicator lights near the eyes of children or animalsDo not use this device in thunderstorm weather, as thunderstorms can cause the device to malfunction and increase the risk of electric shockDo not wipe this product with oil or other volatile liquidsDo not wet the device when it comes into contact with liquid	<p>FCC Warning: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.</p> <p>Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.</p> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.</p>
---	--	--	---	---	--