



SP2 Earphone User Manual



THE PACKAGING ILLUSTRATION IS FOR REFERENCE ONLY;
THE ACTUAL PRODUCT SHALL PREVAIL.

Important Note ✓

Important Note: When placing the earbuds into the charging case, please pay attention to the left and right directions of the earbuds. Incorrect placement may cause the earbuds to get stuck in the charging case and cannot be taken out, affecting use.



Attention ✓

Please keep this manual properly for future reference.
Read the precautions carefully before use and use the product correctly.

Product Diagram ✓



English

Pairing ✓

Automatic pairing between earphone

Take out both earbuds from the charging case, the earbuds will automatically power on and complete interconnection, with a voice prompt "Pairing" at this time.

Earphone and mobile phones

1. First use: Take out both earbuds, they will enter the pairing mode after automatic interconnection; for single-ear use, if no paired device is found after taking out the earbud, it will automatically enter the single-unit pairing mode.
2. Turn on the Bluetooth settings of your mobile phone and search for the Bluetooth signal named "SP2".
3. Click the corresponding signal to pair, and a voice prompt "Connected" will be heard after successful pairing.
4. For subsequent use, taking out both earbuds from the charging case will automatically reconnect to the last paired mobile phone; taking out a single earbud will synchronously reconnect to the TWS earbud and the paired mobile phone.

On/Off ✓

Power On

Method 1: Take the earbuds out of the charging case, the earbuds will power on automatically with a voice prompt "Power ON".

Power Off

Method 1: Place the earbuds into the charging case, the earbuds will power off automatically with a voice prompt "Power Off".
Method 2: In the unconnected state, the earbuds will power off automatically after 5 minutes with a voice prompt "Power Off".

Listen to Music ✓

Function	Operation
Play/Pause	Tap either earbud twice gently
Volume+	Tap the right earbud once gently
Volume-	Tap the left earbud once gently
Previous Track	Tap the left earbud three times gently
Next Track	Tap the right earbud three times gently
Game Mode Switch	Tap either earbud four times in Music Mode
Music Mode Switch	Tap either earbud four times in Game Mode

Call ✓

Function	Operation
Answer a Call	Tap either earbud twice gently
Hang Up	Tap either earbud twice gently
Reject a Call	Press and hold either earbud for 2 seconds

Reset ✓

- 1.Delete the pairing record of "SP2" in the Bluetooth settings of your mobile phone.
- 2.Tap the left and right earbuds six times simultaneously, the earbuds will power off automatically and clear all pairing records with a voice prompt "Power Off".
- 3.Take out the earbuds again, they will automatically enter the pairing mode and can be reconnected to the mobile phone

Charging ✓

Earbuds Charging

Put the earbuds into the charging case, the charging case will automatically charge the earbuds. The indicator light of the charging case will stay on for 4 seconds and then go out during charging.

Charging Case Charging

Use a compliant charging cable to connect to the charging interface. The blue light flashes during charging, and stays on after full charging; when the remaining power is low, the white light flashes at 1Hz for 4 seconds and then goes out.

Voice Assistant ✓

In the power-on state (except during calls), press and hold the left earbud for 2 seconds to wake up the mobile phone's voice assistant (supported by the device), with a voice prompt "DU".

Voice Prompts ✓

Status	Voice Prompt
Power On	Power ON
Power Off	Power Off
Earbuds Interconnection	Paring
Paired Successfully	Connected
Disconnected	Dis Connected
Music Mode	Music Mode
Game Mode	Game Mode
Maximum Volume	"DU"
Low Battery	Low Battery
Wake Up Voice Assistant	"DU"

Products parameter ✓

Parameter Name	Parameter Details
Product Name	Imiki FunClip
Product Model	IMIKI SP2
Driver Diameter	11mm

Transmission Distance	more than 10 meters effective wireless range
Audio Codec	SBC, AAC
Frequency Response	20Hz~20KHz
Single Battery Life	About 4.5 hours for music playback at 80% volume
Total Battery Life	About 21 hours including charging case supply at 80% volume

Precautions ✓

- 1.Try to use an appropriate volume. Listening at high volume for a long time may cause permanent hearing damage.
- 2.Keep the product and accessories out of reach of children. Children should use the product under adult supervision.
- 3.Do not immerse the product in water. Avoid using it while swimming, showering or in the rain.
- 4.Avoid using it in humid, dusty or strong magnetic field environments to prevent internal circuit failures.
- 5.The storage temperature range is -10°C~45°C, the operating temperature range is 0°C~40°C, and the humidity should be below 70%; do not place it in direct sunlight for a long time (such as window sills, car dashboards).
- 6.Do not disassemble, modify the product or insert foreign objects, otherwise the product may be damaged.
- 7.If not used for a long time, store the product in a dry and ventilated place, away from corrosive substances, fire sources and heat sources, and charge it once every 3 months to extend its service life.
- 8.Clean the product with non-abrasive cleaners. Do not use strong chemical solvents.
- 9.Do not throw the product into fire to avoid explosion risk.

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This Equipment generates,uses and can radiate radio frequency energy and,if not installed and used in accordance with the instructions,may cause harmful interference to radio communications.However,there is no guarantee that interference will not occur in a Particular installation.If this quipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.